

Melody[™]

Instruction and Reference Guide

Model BLMY



FOR THE LOVE OF SEWING

To register your machine warranty and receive Baby Lock product updates and offers, go to www.babylock.com/profile. If you have questions with registration, visit your Authorized Baby Lock Retailer.

Baby Lock Consumer Helpline: 800-313-4110

www.babylock.com

CONGRATULATIONS ON CHOOSING OUR MACHINE

Your machine is the most advanced computerized household sewing machine. To fully enjoy all the features incorporated, we suggest that you study the manual.

PLEASE READ BEFORE USING THIS MACHINE

For safe operation

1. Be sure to keep your eye on the needle while sewing. Do not touch the handwheel, thread take-up lever, needle, or other moving parts.
2. Remember to turn off the power switch and unplug the cord when:
 - Operation is completed
 - Replacing or removing the needle or any other parts
 - A power failure occurs during use
 - Maintaining the machine
 - Leaving the machine unattended.
3. Do not store anything on the foot controller.
4. Plug the machine directly into the wall. Do not use extension cords.

For a longer service life

1. When storing this machine, avoid direct sunlight and high humidity locations. Do not use or store the machine near a space heater, iron, halogen lamp, or other hot objects.
2. Use only neutral soaps or detergents to clean the case. Benzene, thinner, and scouring powders can damage the case and machine, and should never be used.
3. Do not drop or hit the machine.
4. Always consult the operation manual when replacing or installing any assemblies, the presser feet, needle, or other parts to assure correct installation.

For repair or adjustment

In the event a malfunction occurs or adjustment is required, first follow the troubleshooting table in the back of the operation manual to inspect and adjust the machine yourself. If the problem persists, please consult your local authorized Baby Lock retailer.

The contents of this manual and specifications of this product are subject to change without notice. For additional product information and updates, visit our web site at www.babylock.com

FOR USERS IN AC INPUT 220-240V COUNTRIES AND MEXICO

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

IMPORTANT SAFETY INSTRUCTIONS

Please read these safety instructions before attempting to use the machine.

DANGER - To reduce the risk of electric shock:

1 **Always** unplug the machine from the electrical outlet immediately after using, when cleaning, when making any user servicing adjustments mentioned in this manual, or if you are leaving the machine unattended.

WARNING - To reduce the risk of burns, fire, electric shock, or injury to persons.

2 **Always** unplug the machine from the electrical outlet when removing covers, lubricating, or when making any adjustments mentioned in the instruction manual:

- To unplug the machine, switch the machine to the symbol “O” position to turn it off, then grasp the plug and pull it out of the electrical outlet. **Do not** pull on the cord.
- Plug the machine directly into the electrical outlet. Do not use an extension cord.
- **Always** unplug your machine if the power is cut.

3 **Never** operate this machine if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or water is spilled on the unit. Return the machine to the nearest authorized retailer or service center for examination, repair, electrical or mechanical adjustment. While the machine is stored or in use if you notice anything unusual, such as an odor, heat, discoloration or deformation, stop using the machine and immediately unplug the power cord.

4 **Always** keep your work area clear:

- Never operate the machine with any air openings blocked. Keep ventilation openings of the sewing machine and foot control free from the build up of lint, dust, and loose cloth.
- **Do not** store objects on the foot controller.
- **Do not** use extension cords. Plug the machine directly into the electrical outlet.
- **Never** drop or insert **any** object into **any** opening.
- **Do not** operate where aerosol (spray) products are being used or where oxygen is being administered.
- **Do not** use the machine near a heat source, such as a stove or iron; otherwise, the machine, power cord or garment being sewn may ignite, resulting in fire or an electric shock.

5 Special care is required when sewing:

- **Always** pay close attention to the needle. Do not use bent or damaged needles.
- Keep fingers away from **all** moving parts. Special care is required around the machine needle.
- Switch the sewing machine to the symbol “O” position to turn it off when making any adjustments in the needle area.
- **Do not** use a damaged or incorrect needle plate, as it could cause the needle to break.
- **Do not** push or pull the fabric when sewing, and follow careful instruction when freehand stitching so that you do not deflect the needle and cause it to break.

6 This machine is **not** a toy:

- Your close attention is necessary when the machine is used by or near children.
- Do not use outdoors.

7 For a longer service life:

- When storing this machine, avoid direct sunlight and high humidity locations. Do not use or store the machine near a space heater, iron, halogen lamp, or other hot objects.
- Use only neutral soaps or detergents to clean the case. Benzene, thinner, and scouring powders can damage the case and machine, and should never be used.
- Always consult the operation manual when replacing or installing any assemblies, the presser feet, needle, or other parts to assure correct installation.

8 For repair or adjustment:

- If the Light unit (light-emitting diode) is damaged, it must be replaced by authorized retailer.
- In the event a malfunction occurs or adjustment is required, first follow the troubleshooting table in the back of the operation manual to inspect and adjust the machine yourself. If the problem persists, please consult your local authorized Baby Lock retailer.

Use this machine only for its intended use as described in this manual.

Use accessories recommended by the manufacturer as contained in this manual.

The contents of this manual and specifications of this product are subject to change without notice.

For additional product information, visit our web site at www.babylock.com

SAVE THESE INSTRUCTIONS

This machine is intended for household use.

Contents

IMPORTANT SAFETY INSTRUCTIONS	1
Introduction	6
Sewing Machine Features	6
Accessories	7
Included accessories	7
Optional accessories	8
Names of Machine Parts and Their Functions	9
Front view	9
Needle and presser foot section	10
Right-side/rear view	10
Operation buttons	11
Operation panel	12

GETTING READY 13

Turning the Machine On/Off.....	14
Power supply precautions	14
Turning on the machine	15
Turning off the machine	15
Understanding the LCD Screens.....	16
Changing the Machine Settings	17
Changing the settings	17
Adjusting the brightness of the LCD	19
Changing the screen language.....	19
Winding/Installing the Bobbin.....	20
Bobbin precautions	20
Winding the bobbin	20
Installing the bobbin	24
Upper Threading	26
Threading the upper thread	26
Threading the needle	29
Threading the needle manually (without using the needle threader)	31
Using the twin needle	31
Pulling up the bobbin thread.....	34
Replacing the Needle	35
Needle precautions	35
Needle types and their uses.....	36
Checking the needle	37
Replacing the needle.....	37
Replacing the Presser Foot	39
Presser foot precautions	39
Replacing the presser foot	39
Adjusting the pressure of the presser foot	41
Removing the presser foot holder	41
Using the walking foot	42
Sewing Cylindrical or Large Pieces.....	44
Stitching cylindrical pieces.....	44
Sewing large pieces of fabric.....	44

Sewing	48
General sewing procedure	48
Positioning the fabric	49
Starting to sew	50
Securing the stitching	52
Cutting the thread	53
Adjusting the Thread Tension	55
Thread tension	55
Changing the tension of the upper thread	56
Adjusting the Stitch Width and Length	57
Adjusting the stitch width	57
Adjusting the stitch length	58
Useful Functions	59
Changing the needle stop position	59
Automatically sewing reverse/reinforcement stitches	59
Automatically cutting the thread	61
Saving stitch settings	62
Hands-free raising and lowering of the presser foot	63
Useful Sewing Tips	64
Trial sewing	64
Changing the sewing direction	64
Sewing curves	64
Sewing thick fabrics	65
Sewing thin fabrics	65
Sewing stretch fabrics	65
Sewing leathers or vinyl fabrics	66
Sewing an even seam allowance	66

Selecting Stitching	68
Selecting stitch types and patterns	68
Selecting stitching	70
Overcasting Stitches	74
Sewing overcasting stitches using overcasting foot "G"	74
Sewing overcasting stitches using zigzag foot "J"	75
Sewing overcasting stitches using the optional side cutter	76
Basic Stitching	78
Basting	78
Basic stitching	79
Blind Hem Stitching	80
Buttonhole Stitching/Button Sewing	82
Buttonhole sewing	83
Button sewing	87
Zipper Insertion	89
Inserting a centered zipper	89
Inserting a side zipper	91
Zipper/piping Insertion	94
Inserting a centered zipper	94
Inserting a piping	95
Sewing Stretch Fabrics and Elastic Tape	96
Stretch stitching.....	96
Elastic attaching	96

Appliqué, Patchwork and Quilt Stitching	98
Appliqué stitching	99
Patchwork (crazy quilt) stitching	100
Hand quilting stitch.....	100
Piecing.....	100
Quilting	102
Free-motion quilting.....	103
Satin stitching using the sewing speed controller	104
Reinforcement Stitching	106
Triple stretch stitching	106
Bar tack stitching.....	106
Darning.....	108
Eyelet Stitching.....	110
Horizontal Stitching	111
Decorative Stitching.....	113
Fagoting	114
Scallop stitching.....	115
Smocking	115
Shell tuck stitching	116
Joining	117
Heirloom stitching	117
Sewing the Various Built-In Decorative Patterns.....	120
Sewing beautiful patterns	120
Sewing patterns.....	120
Combining patterns.....	121
Repeat sewing patterns.....	122
Checking the selected pattern	122
Changing the pattern size	123
Changing the stitch density	124
Changing the pattern length	125
Shifting patterns	126
Mirror imaging the pattern	127
Saving patterns.....	128
Retrieving a pattern	128
Realigning the pattern	129

APPENDIX


131

Stitch Settings.....	132
Utility stitches	132
Other stitches.....	138
Care and Maintenance	143
Cleaning the machine surface	143
Cleaning the race.....	143
Troubleshooting	145
Error messages	149
Nothing appears in the LCD.....	150
Operation beep.....	150
Cancelling the operation beep	150
Index	152

Introduction

Thank you for purchasing this sewing machine. Before using this sewing machine, carefully read the “Important Safety Instructions” (page 1), and then study this manual for the correct operation of the various functions. In addition, after you have finished reading this manual, store it where it can quickly be accessed for future reference.

Sewing Machine Features




- ① **Easy upper threading**
Since the spool can be installed at the front of the sewing machine, the upper thread can easily be threaded. In addition, the needle can be threaded with a simple operation (page 26).
- ② **Full auto upper thread tension**
The thread tension is adjusted automatically.
- ③ **Automatic thread-cutting**
The sewing machine can be set to automatically cut the thread at the end of the stitching (page 61).
- ④ **One-touch lower threading**
You can start sewing without pulling up the bobbin thread (page 24).
- ⑤ **Simple bobbin-winding**
The bobbin can quickly and easily be wound with thread (page 20).
- ⑥ **Built-in stitches**
You can select from the built-in stitches available, including utility stitches, character stitches and decorative stitches (page 70).
- ⑦ **Knee lifter**
Use the knee lifter to raise and lower the presser foot with your knee, leaving both hands free to handle the fabric (page 63).

Accessories

After opening the box, check that the following accessories are included. If any item is missing or damaged, contact your retailer.

Included accessories

The following items should also be included in the box.




Note


(For U.S.A. only)

- Foot controller: Model N5V
This foot controller can be used on this machine model BLMY.
- The screw for the presser foot holder is available through your authorized retailer.
(Part code: XA4813-051)
- The organized accessory tray is available through your authorized retailer.
(Part code: XC4489-051)

■ Attaching the stitch pattern plate

The stitch pattern plate shows the stitch numbers and the patterns available with each stitch mode. Attach the stitch pattern plate to the handle as shown in the illustration below.






No.	Part Name	Part Code	No.	Part Name	Part Code
1	Buttonhole foot "A"	XC2691-023	20	Cleaning brush	X59476-021
2	Overcasting foot "G"	XE6305-101	21	Eyelet punch	XZ5051-001
3	Monogramming foot "N"	XD0810-031	22	Screwdriver (large)	XC8349-021
4	Zipper foot "I"	X59370-021	23	Screwdriver (small)	X55468-021
5	Zigzag foot "J" (on machine)	XC3021-031	24	Spool cap (large)	130012-024
6	Blind stitch foot "R"	XE2650-001	25	Spool cap (medium)(2)	XE1372-001
7	Button fitting foot "M"	XE2643-001	26	Spool cap (small)	130013-124
8	Walking foot	XE1678-201	27	Extra spool pin	XC4654-051
9	Quilting foot	XE8786-001	28	Spool net	XA5523-020
10	Stitch guide foot "P"	X51804-001	29	Foot controller	XC6651-221
11	Adjustable zipper/piping foot	103561-002	30	Extension table	XD1103-051
12	Non stick foot	XA4783-001	31	Knee lifter	XA6941-052
13	Open toe foot	XA7869-001	32	Operation manual	XE8909-001
14	1/4 inch quilting foot	XA3805-021	33	Quick reference guide	XE8910-001
15	Quilting guide	X59819-021	34	Hard case	XC9701-053
16	Seam ripper	X54243-051	35	Accessory bag	XC4487-021
17	Bobbin (4)	X52800-120	36	Disc-shaped screwdriver	XC1074-051
18	Needle set	X58358-021	37	Stitch pattern plate	XE8907-001
19	Twin needle	X59296-121			

Optional accessories

The following are available as optional accessories.



1. Side cutter

Part code: FA10

2. 1/4 inch quilting foot with guide

Part code: ESG-QGF




Memo

- Visit your Baby Lock retailer for a complete listing of optional accessories available for your machine.

Names of Machine Parts and Their Functions


The names of the various parts of the sewing machine and their functions are described below. Before using the sewing machine, carefully read these descriptions to learn the names of the machine parts.

Front view




- ① **Thread guide plate**
Pass the thread under the thread guide plate.
- ② **Thread guide cover**
Pass the thread behind the thread guide cover when threading the upper thread.
- ③ **Spool pin**
Place a spool of thread on the spool pin.
- ④ **Bobbin winding thread guide and pretension disk**
Pass the thread under this thread guide and around the pretension disk when winding the bobbin thread.
- ⑤ **Top cover**
Open the top cover to place the spool of thread on the spool pin.
- ⑥ **Bobbin winder**
Use the bobbin winder when winding the bobbin.
- ⑦ **Operation panel**
Use for stitch selection and various stitch functions. (page 12)
- ⑧ **Knee lifter mounting slot**
Insert the knee lifter into the knee lifter mounting slot.
- ⑨ **Operation buttons and sewing speed controller**
Use these buttons and the slide to operate the sewing machine. (page 11)
- ⑩ **Flat bed attachment with accessory compartment**
Store presser feet and bobbins in the accessory compartment of the flat bed attachment. When sewing cylindrical pieces, remove the flat bed attachment.
- ⑪ **Thread cutter**
Pass the threads through the thread cutter to cut them.
- ⑫ **Needle threader lever**
Use the needle threader to thread the needle.
- ⑬ **Thread take-up lever check window**
Look through the window to check the position of the take-up lever.

Needle and presser foot section



- ① **Buttonhole lever**
The buttonhole lever is used with the one-step buttonhole foot to create buttonholes.
- ② **Thread guide disk**
Pass the thread through the thread guide disk when using the needle threader to thread the needle.
- ③ **Needle bar thread guide**
Pass the upper thread through the needle bar thread guide.
- ④ **Needle plate**
The needle plate is marked with guides to help sew straight seams.
- ⑤ **Needle plate cover**
Remove the needle plate cover to clean the bobbin case and race.
- ⑥ **Bobbin cover**
Open the bobbin cover to set the bobbin.
- ⑦ **Feed dogs**
The feed dogs feed the fabric in the sewing direction.
- ⑧ **Presser foot**
The presser foot applies pressure consistently on the fabric as sewing takes place. Attach the appropriate presser foot for the selected stitch.
- ⑨ **Presser foot holder**
The presser foot is attached onto the presser foot holder.

Right-side/rear view



- ① **Presser foot dial**
Use the presser foot dial to adjust the amount of pressure that the presser foot applies to the fabric.
- ② **Handle**
Carry the sewing machine by its handle when transporting the machine.
- ③ **Handwheel**
Turn the handwheel toward you to raise and lower the needle. The handwheel should be turned towards you (counterclockwise).
- ④ **Air vent**
The air vent allows the air surrounding the motor to circulate. Do not cover the air vent while the sewing machine is being used.
- ⑤ **Main power switch**
Use the main power switch to turn the sewing machine ON and OFF.
- ⑥ **Foot controller jack**
Insert the plug on the end of the foot controller cable into the foot controller jack.
- ⑦ **Power supply jack**
Insert the plug on the power cord into the power supply jack.
- ⑧ **Feed dog position switch**
Use the feed dog position switch to lower the feed dogs.
- ⑨ **Presser foot lever**
Raise and lower the presser foot lever to raise and lower the presser foot.




Memo

- Refer to pages 9 through 12 while you are learning to use your machine.

Operation buttons

The operation buttons help you to easily perform various basic sewing machine operations.



① “Start/Stop” button /

Press the “Start/Stop” button to start or stop sewing. The machine sews at a slow speed at the beginning of sewing while the button is depressed. When sewing is stopped, the needle is lowered in the fabric. For details, refer to “Starting to sew” (page 50).

The button lights up in green, red or orange, depending on how the sewing machine is being operated.

Green: When the machine is ready to start sewing or while it is sewing

Red: When the machine is not ready to start sewing

Orange: When the bobbin winder shaft is moved to the right for winding the bobbin thread onto the bobbin

② “Reverse/Reinforcement Stitch” button

Press the “Reverse/Reinforcement Stitch” button to sew reverse stitches or reinforcement stitches. Reverse stitches are sewn by keeping the button pressed down to sew in the opposite direction. Reinforcement stitches are sewn by sewing 3 to 5 stitches on top of each other. For details, refer to “Securing the stitching” (page 52).

③ “Needle Position” button

Press the “Needle Position” button to raise or lower the needle. Pressing the button twice sews one stitch.

④ “Thread Cutter” button

Press the “Thread Cutter” button after stopping sewing to cut both the upper and the bobbin threads. For details, refer to “Cutting the thread” (page 53).

⑤ Sewing speed controller

Slide the sewing speed controller to adjust the sewing speed.

CAUTION


- Do not press  (“Thread Cutter” button) after the threads have already been cut, otherwise the needle may break, the threads may become tangled or damage to the machine may occur.

Note

- Do not press  (“Thread Cutter” button) if there is no fabric under the presser foot or while the machine is sewing, otherwise damage to the machine may occur.
- When cutting thread thicker than #30, nylon thread or other special threads, use the thread cutter on the side of the machine. For details, refer to “Cutting the thread” (page 53).

Operation panel

The operation panel, located on the front at the right of the sewing machine, consists of the LCD (liquid crystal display) and keys for specifying various sewing settings.



① LCD (liquid crystal display)

Settings for the selected stitch and error messages for incorrect operations appear in the LCD. Use keys ② and ⑦ through ⑱, described below, to display various items and select the settings. For details, refer to “Understanding the LCD Screens” (page 16).

② Settings key

Press this key to select sewing settings, such as for left/right mirror imaging, or other settings such as the operation beep.

③ Needle stop position key

Press this key to select where the needle is positioned when the sewing machine is stopped.

④ Automatic thread cutting key

Press this key to select the automatic thread cutting setting. Press this key again to cancel the setting.

⑤ Automatic reverse/reinforcement stitch key

Press this key to select the automatic reverse/reinforcement stitching setting. Press this key again to cancel the setting.

⑥ Needle mode selection key (single/twin)

Press this key to select the twin needle sewing setting. Each time this key is pressed, the setting switches between that for single needle sewing and for twin needle sewing.

⑦ Thread tension keys

The thread tension is usually set automatically. Press  or  to adjust the thread tension setting.

⑧ Stitch width keys

Press  or  to adjust the stitch width setting.

⑨ Stitch length keys

Press  or  to adjust the stitch length setting.

■ Stitch mode keys (⑩-⑬)

⑩ Preset utility stitch/saved pattern key

Press this key to select the utility stitch assigned to a numeric key or to retrieve a pattern that has been saved. Each time this key is pressed, the machine switches between the preset utility stitch mode and the saved pattern mode.

⑪ Utility stitch key

Press this key to select a straight stitch, zigzag stitch, buttonhole, blind hem stitch, or other stitches commonly used in garment sewing. Use the numeric keys to type in the number of the desired stitch.

⑫ Decorative stitch key

Press this key to select a decorative stitch, satin stitch, cross-stitch or decorative satin stitch. Each time this key is pressed, the stitch group switches between  and .

⑬ Character stitch key

Press this key to select a character stitch. Each time this key is pressed, the font switches to one of the three available.

⑭ Manual memory key

Press this key to save the adjusted thread tension and stitch width and length settings.

⑮ Reset key

Press this key to reset the selected stitch to its original settings.

⑯ Memory key

Press this key to save stitch patterns, such as combined patterns, in the sewing machine's memory.

⑰ OK key

Press this key to apply the selection or perform the operation.

⑱ Cancel/clear key

Press this key to cancel the operation and return to the previous screen.

In addition, pressing this key removes the last pattern added when combining characters or decorative stitches.

⑲ Numeric keys

Use these keys to quickly select one of the ten most often used stitches. When selecting other stitches, use these keys to type in the number of the desired stitch.

**1**

GETTING READY

The various preparations required before starting to sew are described in this chapter.

Turning the Machine On/Off.....	14
Power supply precautions	14
Turning on the machine	15
Turning off the machine	15
Understanding the LCD Screens.....	16
Changing the Machine Settings	17
Changing the settings	17
Adjusting the brightness of the LCD	19
Changing the screen language	19
Winding/Installing the Bobbin.....	20
Bobbin precautions	20
Winding the bobbin	20
Installing the bobbin	24
Upper Threading	26
Threading the upper thread.....	26
Threading the needle.....	29
Threading the needle manually (without using the needle threader).....	31
Using the twin needle	31
Pulling up the bobbin thread.....	34
Replacing the Needle	35
Needle precautions	35
Needle types and their uses.....	36
Checking the needle.....	37
Replacing the needle	37
Replacing the Presser Foot	39
Presser foot precautions	39
Replacing the presser foot.....	39
Adjusting the pressure of the presser foot	41
Removing the presser foot holder	41
Using the walking foot	42
Sewing Cylindrical or Large Pieces.....	44
Stitching cylindrical pieces.....	44
Sewing large pieces of fabric.....	44

Turning the Machine On/Off

This section explains how to turn the sewing machine on and off.

Power supply precautions

Be sure to observe the following precautions concerning the power supply.

WARNING

- Use only regular household electricity for the power source. Using other power sources may result in fire, electric shock, or damage to the machine.
 - Make sure that the plugs on the power cord are firmly inserted into the electrical outlet and the power supply jack on the machine.
 - Do not insert the plug on the power cord into an electrical outlet that is in poor condition.
- Turn off the main power and remove the plug in the following circumstances:
 - When you are away from the machine
 - After using the machine
 - When the power fails during use
 - When the machine does not operate correctly due to a bad connection or a disconnection
 - During electrical storms


CAUTION

- Use only the power cord included with this machine.
- Do not use extension cords or multi-plug adapters with many other appliances plugged in to them. Fire or electric shock may result.
- Do not touch the plug with wet hands. Electric shock may result.
- When unplugging the machine, always turn off the main power first. Always grasp the plug to remove it from the outlet. Pulling on the cord may damage the cord, or lead to fire or electric shock.
- Do not allow the power cord to be cut, damaged, modified, forcefully bent, pulled, twisted, or bundled. Do not place heavy objects on the cord. Do not subject the cord to heat. These things may damage the cord and cause fire or electric shock. If the cord or plug is damaged, take the machine to your authorized retailer for repairs before continuing use.
- Unplug the power cord if the machine is not to be used for a long period of time. Otherwise a fire may result.

Turning on the machine


Prepare the included power cord.

- 1 Make sure that the sewing machine is turned off (the main power switch is set to “○”), and then plug the power cord into the power supply jack on the right side of the machine.
- 2 Insert the plug of the power cord into a household electrical outlet.



① Power supply jack

- 3 Press the right side of the main power switch on the right side of the machine (set it to “I”).




► The sewing lamp and the LCD come on when the machine is turned on.

Turning off the machine

When you are finished using the sewing machine, turn it off. In addition, before transporting the sewing machine to another location, be sure to turn it off.

- 1 Make sure that the machine is not sewing.
- 2 Press the left side of the main power switch on the right side of the machine (set it to “○”).



► The sewing lamp and the LCD go off when the machine is turned off.


- 3 Unplug the power cord from the electrical outlet.
Grasp the plug when unplugging the power cord.
- 4 Unplug the power cord from the power supply jack.

Note

- If a power outage occurs while the sewing machine is being operated, turn off the sewing machine and unplug the power cord. When restarting the sewing machine, follow the necessary procedure to correctly operate the machine. (For U.S.A. only)
- This appliance has a polarized plug (one blade wider than the other). To reduce the risk of electrical shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not modify the plug in any way.

Understanding the LCD Screens

The LCD screen, located on the front at the right of the sewing machine, displays the settings for the selected stitch and error messages if operations are performed incorrectly. When the sewing machine is turned on, the LCD comes on and the following screen appears.



- ① Presser foot that should be used
- ② Stitch mode
- ③ Selected stitch
- ④ Stitch length (mm)
- ⑤ Stitch width (mm)
- ⑥ Upper thread tension



Memo

- For details on the error messages that appear when an operation is performed incorrectly, refer to “Error messages” (page 149).


Changing the Machine Settings

Various sewing machine operations and sewing settings can be changed.

Changing the settings

The general procedure for changing machine settings is described below.

- 1 Turn on the sewing machine.




▶ The LCD comes on.

- 2 Press  (Settings key) in the operation panel.



▶ The settings screen appears.




- 3 Press  or  (Stitch length keys) until the stitch or machine attribute that you wish to set is displayed.



① Stitch length keys



- 4 Press  or  (Stitch width keys) until the desired setting is selected.



▶ The setting is changed.

- 5 Press  (OK key) or  (Cancel/clear key).

▶ The initial stitch screen appears again.

■ List of stitch or machine attributes

The stitch or machine attributes that can be set are listed below. For details on each attribute, refer to the corresponding reference page.

Attribute	Icon	Details	Reference
Check pattern		Allows combined patterns to be checked.	page 122
Mirror imaging		Mirror images patterns along a vertical axis.	page 127
Pattern length		Adjusts the length of satin stitches.	page 125
Pattern size		Sets the size of patterns to be large or small.	page 123
Repeated/ single sewing		Specifies whether the pattern will be sewn once or repeatedly.	page 122
Stitching density		Specifies the sewing density of the stitching.	page 124
Initial needle position		Select the straight stitch that is automatically selected when the machine is turned on.	-
Stitch width control		Allows the stitch width to be adjusted with the sewing speed controller.	page 104
Language	ENGLISH	Allows the language used in the screens to be changed.	page 19
Buzzer		Specifies whether or not a beep is sounded with each operation.	page 150
LCD brightness		Adjusts the brightness of the LCD.	page 19
Vertical pattern adjustment		Adjusts the up and down position of the pattern.	page 129
Horizontal pattern adjustment		Adjusts the left and right position of the pattern.	page 129




Memo

- The icon shown highlighted above is the default setting.
- The default display language is English.

Adjusting the brightness of the LCD

The brightness of the LCD can be adjusted.


- 1 Press  (Settings key) in the operation panel, and then press  or  (Stitch length keys) until  is displayed.




- ▶ The screen for changing the brightness of the LCD appears.



- 2 To make the LCD brighter, press  (Stitch width key). To make the LCD darker, press  (Stitch width key).



- ▶ The brightness of the LCD is changed.




- 3 Press  (OK key) or  (Cancel/clear key).

- ▶ The initial stitch screen appears again.


Changing the screen language

The language used in the screens that are displayed can be changed to one of the many available.

- 1 Press  (Settings key) in the operation panel, and then press  or  (Stitch length keys) until the language is displayed.




- ▶ The screen for changing the language of the screens appears.




- 2 Press  or  (Stitch width keys) until the desired language is selected.

The language can be changed to one of the available: English, French, German, Dutch, Spanish, Italian, Danish, Norwegian, Finnish, Swedish, Portuguese, Russian, Japanese, Korean or others.



- ▶ The language of the screens is changed.



- 3 Press  (OK key) or  (Cancel/clear key).

- ▶ The initial stitch screen appears again.

Winding/Installing the Bobbin


This section describes how to wind the thread onto the bobbin, and then insert the bobbin thread.

Bobbin precautions

Be sure to observe the following precautions concerning the bobbin.


! CAUTION

- Only use the bobbin (part code: X52800-150) designed specifically for this sewing machine. Use of any other bobbin may result in injuries or damage to the machine.
- The included bobbin was designed specifically for this sewing machine. If bobbins from other models are used, the machine will not operate correctly. Use only the included bobbin or bobbins of the same type (part code: X52800-150).



Winding the bobbin

Wind the thread around the bobbin to prepare the bobbin thread.




① Bobbin winder




Memo

- The order that the machine should be threaded for winding the bobbin is indicated by a broken line on the sewing machine. Be sure to thread the machine as indicated.


- 1 Turn on the sewing machine.



- 2 Open the top cover.




- 3 Place the bobbin on the bobbin winder shaft so that the spring on the shaft fits into the notch in the bobbin. Press down on the bobbin until it snaps into place.




- ① Notch
② Bobbin winder shaft spring

- 4 Slide the bobbin winder in the direction of the arrow until it snaps into place.



-  /  ("Start/Stop" button) lights up in orange.


- 5 Remove the spool cap that is inserted onto the spool pin.



- ① Spool pin
② Spool cap

- 6 Place the spool of thread for the bobbin onto the spool pin.


Slide the spool onto the pin so that the spool is horizontal and the thread unwinds to the front at the bottom.



- If the spool is not positioned so that the thread unwinds correctly, the thread may become tangled around the spool pin.



- 7 Slide the spool cap onto the spool pin.

Slide the spool cap as far as possible to the right, as shown, with the rounded side on the left.




! CAUTION

- If the spool or the spool cap is not positioned correctly, the thread may become tangled around the spool pin and the needle may break.
- Three spool cap sizes are available (large, medium and small), allowing you to choose a spool cap that best fits the size of spool being used. If the spool cap is too small for the spool being used, the thread may catch on the slit in the spool and the needle may break.



**Memo**

- When sewing with fine, cross-wound thread, use the small spool cap, and leave a small space between the cap and the spool.




- ① Spool cap (small)
- ② Spool (cross-wound thread)
- ③ Space

- When using thread that winds off quickly, such as transparent nylon thread or metallic thread, place the spool net over the spool before placing the spool of thread onto the spool pin.

If the spool net is too long, fold it to fit the size of the spool.


When the spool net is used, the tension of the upper thread will slightly increase. Be sure to check the thread tension. For details, refer to “Adjusting the Thread Tension” (page 55).



- ① Spool net
- ② Spool
- ③ Spool cap
- ④ Spool pin

8


While holding the thread near the spool with your right hand, as shown, pull the thread with your left hand, and then pass the thread behind the thread guide cover and to the front.



- ① Thread guide cover

9



Pass the thread under the thread guide plate, and then pull it to the right.



- ① Thread guide plate

10

Pass the thread under the hook on the thread guide, and then wind it counterclockwise under the pretension disk.




- ① Thread guide and pretension disk

**Note**

- Make sure that the thread passes under the pretension disk.


- 11 While holding the thread with your left hand, wind the thread that was pulled out clockwise around the bobbin five or six times with your right hand.



Note

- Make sure that the thread between the spool and the bobbin is pulled tight.
- Be sure to wind the thread clockwise around the bobbin, otherwise the thread will become wrapped around the bobbin winder shaft.

- 12 Pass the end of the thread through the guide slit in the bobbin winder seat, and then pull the thread to the right to cut it.



- ① Guide slit in bobbin winder seat (with built-in cutter)


- The thread is cut to a suitable length.



CAUTION


- Be sure to cut the thread as described. If the bobbin is wound without cutting the thread using the cutter built into the slit in the bobbin winder seat, the thread may become tangled in the bobbin and the needle may bend or break when the bobbin thread starts to run out.

- 13 Slide the sewing speed controller to the right to increase the bobbin winding speed and slide left to decrease.



- ① Sewing speed controller

- 14 Press  /  (“Start/Stop” button) once.



- ① “Start/Stop” button


- When the bobbin winding becomes slow, press  /  (“Start/Stop” button) once to stop the machine.



CAUTION

- When the bobbin winding becomes slow, stop the machine, otherwise the sewing machine may be damaged.


- 15 Use scissors to cut the end of the thread wound around the bobbin.



- 16 Slide the bobbin winder shaft to the left.



17 Remove the bobbin from the shaft.



Memo


- When the sewing machine is started or the handwheel is turned after winding the bobbin, the machine will make a clicking sound; this is not a malfunction.

Installing the bobbin


Install the bobbin wound with thread.

CAUTION

- Use a bobbin that has been correctly wound with thread, otherwise the needle may break or the thread tension will be incorrect.




- The bobbin was designed specifically for this sewing machine. If bobbins from other models are used, the machine will not operate correctly. Use only the included bobbin or bobbins of the same type (part code: X52800-150).



Memo

- The order that the bobbin thread should be passed through the bobbin case is indicated by marks around the bobbin case. Be sure to thread the machine as indicated.

1 Slide the bobbin cover latch to the right.




- ① Bobbin cover
- ② Latch

▶ The bobbin cover opens.


2 Remove the bobbin cover.

3 Hold the bobbin with your right hand and hold the end of the thread with your left.



- Be careful not to drop the bobbin.

4 Insert the bobbin into the bobbin case so that the thread unrolls to the left.



- Be sure to insert the bobbin correctly.


CAUTION

- Be sure to install the bobbin so that the thread unwinds in the correct direction, otherwise the thread may break or the thread tension will be incorrect.




Memo

- The order that the bobbin thread should be passed through the bobbin case is indicated by marks around the bobbin case. Be sure to thread the machine as indicated.




- 5** Lightly hold down the bobbin with your right hand, and then guide the thread as shown with your left hand.



! CAUTION

- When installing the bobbin, be sure to hold it down with your finger. If the bobbin is not correctly installed, the thread tension will be incorrect.

- 6** Pass the thread through the slot as shown, and then pull the thread out toward the front.




① Cutter

- ▶ The cutter cuts the thread.


☀ Note

- Make sure that the thread is correctly inserted through the tension-adjusting spring of the bobbin case. If it is not inserted correctly, reinsert the thread.



① Tension-adjusting spring

- 7** Reattach the bobbin cover. Insert the tab in the lower-left corner of the bobbin cover, and then lightly press down on the right side.



- ▶ The lower threading is finished.


Next, thread the upper thread. Continue with the procedure in “Upper Threading” (page 26).

🔔 Memo

- You can begin sewing without pulling up the bobbin thread. If you wish to pull up the bobbin thread before starting to sew, pull up the thread according to the procedure in “Pulling up the bobbin thread” (page 34).

Upper Threading

In this section, the procedures for positioning the spool for the upper thread and threading the needle are described.



CAUTION

- When threading the upper thread, carefully follow the instructions. If the upper threading is not correct, the thread may become tangled and the needle may bend or break.




Memo

- The order that the machine should be threaded is indicated by a solid line on the sewing machine. Be sure to thread the machine as indicated.


Threading the upper thread

Set the spool of thread on the spool pin, and then thread the machine.

- 1 Turn on the sewing machine.



- 2 Raise the presser foot lever to raise the presser foot.




- ① Presser foot lever

Note


- If the presser foot is not raised, the sewing machine cannot be threaded.

- 3** Press  ("Needle Position" button) once or twice to raise the needle.




① "Needle Position" button

- ▶ The needle is correctly raised when the mark on the handwheel is at the top, as shown below. Check the handwheel and, if this mark is not at this position, press  ("Needle Position" button) until it is.




① Mark on handwheel

- 4** Open the top cover.




- 5** Remove the spool cap that is inserted onto the spool pin.




① Spool pin
② Spool cap

- 6** Place the spool of thread onto the spool pin. Slide the spool onto the pin so that the spool is horizontal and the thread unwinds to the front at the bottom.





- 7** Slide the spool cap onto the spool pin. Slide the spool cap as far as possible to the right, as shown, with the rounded side on the left.




CAUTION

- If the spool or the spool cap is not positioned correctly, the thread may become tangled around the spool pin and the needle may break.
- Three spool cap sizes are available (large, medium and small), allowing you to choose a spool cap that best fits the size of spool being used. If the spool cap is too small for the spool being used, the thread may catch on the slit in the spool and the needle may break.




- 8** While holding the thread lightly with your right hand, pull the thread with your left hand, and then pass the thread behind the thread guide cover and to the front.




① Thread guide cover

- 9** Pass the thread under the thread guide plate, and then pull it up.



① Thread guide plate

- 10** While using your right hand to lightly hold the thread passed under the thread guide plate, pass the thread through the thread path in the order shown below.




① Shutter



Note


- If the presser foot has been lowered and the shutter is closed, the machine cannot be threaded. Be sure to raise the presser foot and open the shutter before threading the machine. In addition, before removing the upper thread, be sure to raise the presser foot and open the shutter.

- This machine is equipped with a window that allows you to check the position of the take-up lever. Look through this window and check that the thread is correctly fed through the take-up lever.



- 11** Pass the thread behind the needle bar thread guide.

The thread can easily be passed behind the needle bar thread guide by holding the thread in your left hand, then feeding the thread with your right hand, as shown.



① Needle bar thread guide

Next, use the needle threader to thread the needle. Continue with the procedure in “Threading the needle” (page 29).

Threading the needle


This section describes how to thread the needle.



Memo


- The needle threader can be used with sewing machine needles 75/11 through 100/16.
- Thread with a thickness of 130/20 or thicker cannot be used with the needle threader.
- The needle threader cannot be used with the wing needle or the twin needle.
- If the needle threader cannot be used, refer to “Threading the needle manually (without using the needle threader)” (page 31).

- 1** Pull the end of the thread passed through the needle bar thread guide to the left, and then pass the thread through the thread guide disk from the front.



① Thread guide disk

- 2** Cut the thread with the thread cutter on the left side of the machine.




① Thread cutter



Note


- If the thread is pulled through and cannot be cut correctly, lower the presser foot so that the thread is held in place before cutting the thread. If this operation is performed, skip step 3.
- When using thread that quickly winds off the spool, such as metallic thread, it may be difficult to thread the needle if the thread is cut.

Therefore, instead of using the thread cutter, pull out about 80 mm (approx. 3 inches) of thread after passing it through the thread guide disks (marked “7”).




① 80 mm (3 inches) or more

- 3** Lower the presser foot lever to lower the presser foot.



① Presser foot lever


- 4 Lower the needle threader lever on the left side of the machine until it clicks, and then slowly return the lever to its original position.



- ① Needle threader lever
- ▶ The thread is passed through the eye of the needle.

Note


- If the needle was not completely threaded, but a loop in the thread was formed in the eye of the needle, carefully pull the loop through the eye of the needle to pull out the end of the thread.



CAUTION

- When pulling out the thread, do not pull it with extreme force, otherwise the needle may break or bend.

- 5 Raise the presser foot lever, pass the end of the thread through the presser foot, and then pull out about 5 cm (2 inches) of thread toward the rear of the machine.



- ① 5 cm (2 inches)

- ▶ The upper threading is finished. Now that the upper threading and the lower threading are finished, you are ready to begin sewing.

Note

- If the needle is not raised, the needle threader cannot thread the needle. Be sure to press  ("Needle Position" button) to raise the needle before using the needle threader.


Threading the needle manually (without using the needle threader)

When using special thread, thread with a thickness of 130/20 or thicker, the wing needle or the twin needle which cannot be used with the needle threader, thread the needle as described below.

1 Thread the machine to the needle bar thread guide.


- For details, refer to “Upper Threading” (page 26).

2 Lower the presser foot lever.



① Presser foot lever

3 Pass the thread through the eye of the needle from front to back.




4 Raise the presser foot lever, pass the end of the thread through the presser foot, and then pull out about 5 cm (2 inches) of thread toward the rear of the machine.

Using the twin needle

With the twin needle, you can sew two parallel lines of the same stitch with two different threads. Both upper threads should have the same thickness and quality. Be sure to use the twin needle, the extra spool pin and the spool cap.

For details on the stitches that can be sewn with the twin needle, refer to “Stitch Settings” (page 132).



! CAUTION

- Only use the twin needle (part code: X59296-151). Use of any other needle may bend the needle or damage the machine.
- Never use bent needles. Bent needles can easily break, possibly resulting in injuries.

1 Install the twin needle.


- For details on installing a needle, refer to “Replacing the needle” (page 37).

2 Thread the upper thread for the left needle eye.

- For details, refer to steps ① through ⑪ of “Threading the upper thread” (page 26).

3 Manually thread the left needle with the upper thread.


- Pass the thread through the eye of the needle from the front.



- The needle threader cannot be used with the twin needle. If the needle threader is used with the twin needle, the sewing machine may be damaged.


4 Insert the extra spool pin onto the bobbin winder shaft.

Insert the extra spool pin so that it is perpendicular to the bobbin winder shaft.




① Bobbin winder shaft

5 Swing down the spool pin so that it is horizontal.




6 Place the upper thread spool for the needle on the right side onto the extra spool pin, and then secure it with the spool cap.

The thread should unroll from the top front of the spool.



① Spool cap
② Spool

7 Thread the upper thread for the right side in the same way that the upper thread for the left side was threaded.




① Thread guide cover

- For details, refer to step 8 through 10 of “Threading the upper thread” (page 26).

8 Without passing the thread through the needle bar thread guide, manually thread the right needle.

Pass the thread through the eye of the needle from the front.



- The needle threader cannot be used with the twin needle. If the needle threader is used with the twin needle, the sewing machine may be damaged.


9 Attach zigzag foot “J”.

- For details on changing the presser foot, refer to “Replacing the presser foot” (page 39).

! CAUTION

- When using the twin needle, be sure to attach zigzag foot “J”, otherwise the needle may break or the machine may be damaged.

10 Turn on the sewing machine.




- ▶ The LCD comes on.


Pulling up the bobbin thread

When making gathers or before free-motion quilting, first pull up the bobbin thread as described below.

- 1 **Insert the bobbin into the bobbin case.**
 - Refer to steps 1 through 5 of “Installing the bobbin” (page 24).
- 2 **Pass the bobbin thread through the slot.**
Do not cut the thread with the cutter.




- 3 **While lightly holding the upper thread with your left hand with the needle in the up-position, press \oplus (“Needle Position” button) twice to lower and raise the needle.**




- ① “Needle Position” button
- ▶ The bobbin thread is looped around the upper thread and can be pulled up.


- 4 **Carefully pull the upper thread upward to pull out the end of the bobbin thread.**



- 5 **Pull out about 10-15 cm (4-5 inches) of the bobbin thread under the presser foot toward the rear of the machine.**



- 6 **Reattach the bobbin cover.**
Insert the tab in the lower-left corner of the bobbin cover, and then lightly press down on the right side.



Replacing the Needle

This section provides information on sewing machine needles.

Needle precautions

Be sure to observe the following precautions concerning the handling of the needle. Failure to observe these precautions is extremely dangerous, for example, if the needle breaks and fragments are dispersed. Be sure to read and carefully follow the instructions below.



CAUTION

- **Only use home sewing machine needles. Use of any other needle may bend the needle or damage the machine.**
- **Never use bent needles. Bent needles can easily break, possibly resulting in injuries.**

Needle types and their uses

The sewing machine needle that should be used depends on the fabric and thread thickness. Refer to the following table when choosing the thread and needle appropriate for the fabric that you wish to sew.

Fabric Type/Application		Thread		Size of Needle
		Type	Weight	
Medium weight fabrics	Broadcloth	Cotton thread	60–80	75/11–90/14
	Taffeta	Synthetic thread		
	Flannel, Gabardine	Silk thread	50	
Thin fabrics	Lawn	Cotton thread	60–80	65/9–75/11
	Georgette	Synthetic thread		
	Challis, Satin	Silk thread	50	
Thick fabrics	Denim	Cotton thread	30–50	90/14–100/16
	Corduroy	Synthetic thread	50	
	Tweed	Silk thread		
Stretch fabrics	Jersey	Thread for knits	50–60	Ball point needle (golden colored) 75/11–90/14
	Tricot			
Easily frayed fabrics		Cotton thread	50–80	65/9–90/14
		Synthetic thread		
		Silk thread	50	
For top-stitching		Synthetic thread	30	90/14–100/16
		Silk thread		



Memo

- The smaller the thread number, the thicker the thread, and the larger the needle number, the thicker the needle.
- Use the ball point needle when sewing on stretch fabrics or fabrics where skipped stitches easily occur.
- Use a 90/14 to 100/16 needle with transparent nylon threads, regardless of the fabric being sewn.
- A 75/11 needle is already installed when the sewing machine is purchased.




CAUTION

- **The appropriate fabric, thread and needle combinations are shown in the table above. If the combination of the fabric, thread and needle is not correct, particularly when sewing thick fabrics (such as denim) with thin needles (such as 65/9 to 75/11), the needle may bend or break. In addition, the stitching may be uneven or puckered or there may be skipped stitches.**

Checking the needle


Sewing with a bent needle is extremely dangerous since the needle may break while the machine is being operated.

Before using the needle, place the flat side of the needle on a flat surface and check that the distance between the needle and the flat surface is even.



- ① Flat side
- ② Needle type marking


■ Correct needle



- ① Flat surface

■ Incorrect needle

If the distance between the needle and the flat surface is not even, the needle is bent. Do not use a bent needle.




- ① Flat surface

Replacing the needle


Replace the needle as described below. Use the screwdriver and a needle that has been determined to be straight according to the instructions in "Checking the needle".

- 1 Press ("Needle Position" button) once or twice to raise the needle.



- ① "Needle Position" button

- 2 Turn off the sewing machine.



! CAUTION


- Before replacing the needle, be sure to turn off the sewing machine, otherwise injuries may occur if / ("Start/Stop" button) is accidentally pressed and the machine starts sewing.

- 3 Place fabric or paper under the presser foot to cover the hole in the needle plate.

☀ Note


- Before replacing the needle, cover the hole in the needle plate with fabric or paper to prevent the needle from falling into the machine.

- 4** Lower the presser foot lever.




① Presser foot lever

- 5** Hold the needle with your left hand, and then use a screwdriver to turn the needle clamp screw toward you (counterclockwise) to remove the needle.




① Screwdriver
② Needle clamp screw

- Do not apply a strong force when loosening or tightening the needle clamp screw, otherwise certain parts of the sewing machine may be damaged.




- 6** With the flat side of the needle toward the rear of the machine, insert the needle until it touches the needle stopper.




① Needle stopper

- 7** While holding the needle with your left hand, use the screwdriver to tighten the needle clamp screw.



Install the twin needle in the same way.



! CAUTION

- Be sure to insert the needle until it touches the needle stopper and securely tighten the needle clamp screw with the screwdriver, otherwise the needle may break or damage may result.

Replacing the Presser Foot

The presser foot presses down on the fabric.

Presser foot precautions

Be sure to observe the following precautions concerning the presser feet.


CAUTION

- Use the presser foot appropriate for the type of stitch that you wish to sew, otherwise the needle may hit the presser foot, causing the needle to bend or break.
- Only use presser feet designed specifically for this sewing machine. Use of any other presser foot may result in injuries or damage to the machine.

Replacing the presser foot


Replace the presser foot as described below. For details on using the side cutter "S", refer to "Sewing overcasting stitches using the optional side cutter" (page 76).

- 1 Press  ("Needle Position" button) once or twice to raise the needle.



- ① "Needle Position" button
▶ The needle is raised.


- 2 Turn off the sewing machine.



CAUTION


- Before replacing the presser foot, be sure to turn off the sewing machine, otherwise injuries may occur if  /  ("Start/Stop" button) is accidentally pressed and the machine starts sewing.

- 3 Raise the presser foot lever.



- ① Presser foot lever
▶ The presser foot is raised.

- 4** Press the black button at the back of the presser foot holder.




- ① Black button
② Presser foot holder

► The presser foot holder releases the presser foot.


- 5** Place a different presser foot below the holder so that the presser foot pin is aligned with the notch in the holder.

Position the presser foot so the letter indicating the presser foot type (A, G, I, J, M, N or R) is positioned to be read.



- ① Presser foot holder
② Notch
③ Pin


- 6** Slowly lower the presser foot lever so that the presser foot pin snaps into the notch in the presser foot holder.



- ① Presser foot lever

► The presser foot is attached.

- 7** Raise the presser foot lever to check that the presser foot is securely attached.



Note

- When a stitch is selected, the icon for the presser foot that should be used appears in the screen. Check that the correct presser foot is attached before starting to sew. If the wrong presser foot is installed, turn off the sewing machine, attach the correct presser foot, and then select the desired stitch again.



Buttonhole foot "A"



Overcasting foot "G"



Zigzag foot "J"



Button fitting foot "M"



Monogramming foot "N"



Blind stitch foot "R"




Side cutter "S"

- For details on the presser foot that should be used with the selected stitch, refer to "Stitch Settings" (page 132).

Adjusting the pressure of the presser foot

The presser foot pressure (the amount of pressure applied to the fabric by the presser foot) can be adjusted. For best results, increase the pressure when sewing thin fabrics, and decrease the pressure when sewing thick fabrics.


1 Lower the presser foot lever.



① Presser foot lever

2 Turn the presser foot pressure dial at the back of the machine to adjust the pressure of the presser foot.

The presser foot pressure can be set to one of four levels (between 1 and 4). The larger the setting, the stronger the pressure. Use setting 1 or 2 for thick fabrics, use setting 3 or 4 for thinner fabrics.



- ① Strong
- ② Weak

3 When you are finished sewing, reset the dial to 3 (standard).

Removing the presser foot holder


Remove the presser foot holder when cleaning the sewing machine or when installing a presser foot that does not use the presser foot holder, such as the quilting foot. Use the screwdriver to remove the presser foot holder.

■ Removing the presser foot holder

1 Remove the presser foot.

- For details, refer to “Replacing the presser foot” (page 39).


2 Use the screwdriver to loosen the presser foot holder screw.




- ① Screwdriver
- ② Presser foot holder
- ③ Presser foot holder screw

■ Attaching the presser foot holder

1 Align the presser foot holder with the lower-left side of the presser bar.



2 Hold the presser foot holder in place with your right hand, and then tighten the screw using the screwdriver in your left hand.



- ① Screwdriver


☀ Note

- If the presser foot holder is not correctly installed, the thread tension will be incorrect.

Using the walking foot

With the walking foot, both pieces of fabric are fed evenly by the feed dogs and the teeth on the presser foot. This is useful when sewing fabrics that are hard to feed such as vinyl and leather and when sewing fabrics that easily slip such as velvets or when quilting.

Use the screwdriver to attach the walking foot.




■ Attaching the walking foot

① Remove the presser foot holder.


- For details, refer to “Removing the presser foot holder” (page 41).

② Hook the connecting fork of the walking foot onto the needle clamp screw.



- ① Connecting fork
- ② Needle clamp screw

③ Lower the presser foot lever, insert the presser foot holder screw, and then tighten the screw with the screwdriver.



- ① Presser foot holder screw

! CAUTION


- Be sure to securely tighten the screw with the screwdriver, otherwise the needle may touch the presser foot, causing it to bend or break.
- Before starting to sew, slowly turn the handwheel toward you (counterclockwise) and check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.

☀ Note

- When sewing with the walking foot, sew at a speed between slow and medium.

■ Removing the walking foot


① Press (“Needle Position” button) once or twice to raise the needle.




- ① “Needle Position” button

▶ The needle is raised.

② Turn off the sewing machine.




③ Raise the presser foot lever.



- ① Presser foot lever

▶ The presser foot is raised.

4 With a screwdriver, loosen the presser foot holder screw, and then remove the walking foot.



① Presser foot holder screw

5 Attach the presser foot holder.

- For details, refer to “Removing the presser foot holder” (page 41).



Memo

- Only the straight stitch (with reinforcement stitching) and the zigzag stitch can be used with the walking foot. For details on the stitches, refer to “Stitch Settings” (page 132).


Sewing Cylindrical or Large Pieces

When sewing cylindrical or large pieces of fabric, remove the flat bed attachment.

Stitching cylindrical pieces


Removing the flat bed attachment makes it easier to sew cylindrical pieces such as cuffs and pant legs.

- 1 Pull the flat bed attachment off to the left.




- ▶ With the flat bed attachment removed, free-arm sewing is possible.

- 2 Slide the part that you wish to sew onto the arm, and then sew from the top.




- 3 When you are finished with free-arm sewing, install the flat bed attachment back in its original position.




Sewing large pieces of fabric

The extension table makes sewing large pieces of fabric easier.




- 1 Open up the legs at the bottom of the extension table.

Pull out the four legs until they snap into place.




- 2 Pull the flat bed attachment off to the left.



- ▶ With the flat bed attachment removed, free-arm sewing is possible.


- 3 Install the extension table.

Keeping the extension table level, fully slide it into place. The lower right corner section of the extension table extends over the front section of the sewing machine bed.



- ① Lower right corner
- ② Sewing machine bed


- 4 Turn the screw at the bottom of each leg to adjust their height so the extension table will be level with the sewing machine bed.



! CAUTION

- Do not move the sewing machine while the extension table is attached, otherwise damage or injuries may occur.


- 5 When you are finished using the extension table, remove it. While slightly lifting up the extension table, pull it off to the left.




- 6 Install the flat bed attachment back in its original position.

🔔 Memo

- With the legs folded up, the extension table can be stored attached to the hard case.



- The knee lifter can be stored attached to the bottom of the extension table.



2

SEWING BASICS

The necessary preparations for sewing are described in this chapter.

Sewing.....	48
General sewing procedure	48
Positioning the fabric	49
Starting to sew	50
Securing the stitching.....	52
Cutting the thread	53
Adjusting the Thread Tension	55
Thread tension	55
Changing the tension of the upper thread	56
Adjusting the Stitch Width and Length	57
Adjusting the stitch width	57
Adjusting the stitch length.....	58
Useful Functions.....	59
Changing the needle stop position	59
Automatically sewing reverse/reinforcement stitches	59
Automatically cutting the thread.....	61
Saving stitch settings	62
Hands-free raising and lowering of the presser foot.....	63
Useful Sewing Tips	64
Trial sewing.....	64
Changing the sewing direction	64
Sewing curves	64
Sewing thick fabrics	65
Sewing thin fabrics.....	65
Sewing stretch fabrics	65
Sewing leathers or vinyl fabrics.....	66
Sewing an even seam allowance	66

Sewing

Basic sewing operations are described below.

Before operating the sewing machine, read the following precautions.

! CAUTION

- While the machine is in operation, pay special attention to the needle location. In addition, keep your hands away from all moving parts such as the needle and handwheel, otherwise injuries may occur.
- Do not pull or push the fabric too hard while sewing, otherwise injuries may occur or the needle may break.
- Never use bent needles. Bent needles can easily break, possibly resulting in injuries.
- Make sure that the needle does not strike basting pins, otherwise the needle may break or bend.

General sewing procedure


Follow the basic procedures below to sew.

1	Turn on the machine.	Turn on the sewing machine. For details on turning on the machine, refer to "Turning on the machine" (page 15).
↓		
2	Select the stitch.	Select the stitch appropriate for the area to be sewn. For details on selecting a stitch, refer to "Selecting stitching" (page 70).
↓		
3	Attach the presser foot.	Attach the presser foot appropriate for the stitch. For details on replacing the presser foot, refer to "Replacing the presser foot" (page 39).
↓		
4	Position the fabric.	Place the area to be sewn under the presser foot. Be sure that the fabric pieces are sewn in the correct order and that the right and wrong sides of the fabric are aligned correctly. For details on positioning the fabric, refer to "Positioning the fabric" (page 49).
↓		
5	Start sewing.	Start sewing. For details on starting to sew, refer to "Starting to sew" (page 50).
↓		
6	Cut the thread.	Cut the thread at the end of sewing. The thread may also be cut automatically. For details on cutting the thread, refer to "Cutting the thread" (page 53).

Positioning the fabric


Be sure that the fabric pieces are sewn in the correct order and that the right and wrong sides of the fabric are aligned correctly.

1 Turn on the sewing machine.



The straight stitch (left needle position) is automatically selected.

2 Press (“Needle Position” button) once or twice to raise the needle.





① “Needle Position” button


3 Place the fabric under the presser foot.

- If the seam allowance is positioned on the right side, sewing in a straight line is easier and the extra fabric does not get in the way.

4 While holding the end of the thread and the fabric with your left hand, turn the handwheel toward you (counterclockwise) with your right hand to lower the needle to the starting point of the stitching.




5 Lower the presser foot lever.



① Presser foot lever

► The fabric is now positioned to be sewn.



Memo

- To adjust the pressure that the presser foot applies to the fabric, refer to “Adjusting the pressure of the presser foot” (page 41).

Starting to sew

Once you are ready to start sewing, you can start the sewing machine. The sewing speed can be adjusted using either the sewing speed controller or the foot controller.



Note


Important:

- When the foot controller is plugged in,  /  ("Start/Stop" button) cannot be used to start or stop sewing.

Using the operation buttons


Sewing can be started and stopped using the operation button  /  ("Start/Stop" button).

- Slide the sewing speed controller to the left or right to select the desired sewing speed.**
Slide the sewing speed controller to the left to sew at a slower speed, or slide the speed controller to the right to sew at a faster speed.




① Sewing speed controller

- Press  /  ("Start/Stop" button) once.**



① "Start/Stop" button

- ▶ The machine starts sewing.



- If you continue to hold  /  ("Start/Stop" button) after the sewing starts, the machine will sew at a slow speed.

- When the end of the stitching is reached, press  /  ("Start/Stop" button) once.**


- ▶ The machine stops sewing with the needle down (in the fabric).

- When you are finished sewing, raise the needle, and then cut the threads.**


- ▶ For details, refer to "Cutting the thread" (page 53).

Using the foot controller


Sewing can be started and stopped using the foot controller.



- Turn off the sewing machine.**
When connecting the foot controller, be sure to turn off the sewing machine in order to prevent the machine from accidentally being started.




- ② Insert the foot controller plug into its jack on the side of the sewing machine.




① Foot controller jack

- ③ Turn on the sewing machine.



- ④ Slide the sewing speed controller to the left or right to select the desired sewing speed.

Slide the sewing speed controller to the left to sew at a slower speed, or slide the speed controller to the right to sew at a faster speed.




① Sewing speed controller

- The speed set using the sewing speed controller will be the foot controller's maximum sewing speed.

- ⑤ Once you are ready to start sewing, slowly press down on the foot controller.

Pressing down on the foot controller increases the sewing speed; releasing the pressure on the foot controller decreases the sewing speed.



- Slowly press down on the foot controller. Pressing it down hard starts sewing too quickly.

▶ The machine starts sewing.

- ⑥ When the end of the stitching is reached, completely release the foot controller.

▶ The machine stops sewing with the needle lowered (in the fabric).

- ⑦ When you are finished sewing, raise the needle, and then cut the threads.

- For details, refer to "Cutting the thread" (page 53).



Memo

- When the foot controller is plugged in,  ("Start/Stop" button) cannot be used to start or stop sewing.
- When sewing is stopped, the needle remains lowered (in the fabric). The machine can be set so that the needle will stay up when sewing is stopped. For details on setting the machine so that the needle stays up when sewing is stopped, refer to "Changing the needle stop position" (page 59).


CAUTION

- Do not allow thread or dust to accumulate in the foot controller, otherwise a fire or an electric shock may occur.
- Do not place objects on the foot controller, otherwise damage to the machine or injuries may occur.
- If the machine is not to be used for a long period of time, unplug the foot controller, otherwise a fire or an electric shock may occur.

Securing the stitching


When sewing with the straight stitch, for example, at the end of an opening or where seams do not overlap, use reverse stitching or reinforcement stitching to secure the end of the thread.

- 1 Lower the needle into the fabric at the beginning of the stitching, and then lower the presser foot lever.



- 2 Press  /  ("Start/Stop" button) or press down on the foot controller.


At this time, if  /  ("Start/Stop" button) is held down, the machine sews at a low speed.



- ① "Start/Stop" button

- For details, refer to "Starting to sew" (page 50).
- ▶ The machine starts sewing.

- 3 After sewing 3 to 5 stitches, press  ("Reverse/Reinforcement Stitch" button). Keep  ("Reverse/Reinforcement Stitch" button) held down until you reach the beginning of the stitching.



- ① "Reverse/Reinforcement Stitch" button


- ▶ While  ("Reverse/Reinforcement Stitch" button) is held down, reverse stitches are sewn.

- 4 After sewing back to the beginning of the stitching, release  ("Reverse/Reinforcement Stitch" button).

- ▶ The machine stops sewing.


- 5 Press  /  ("Start/Stop" button), or press down on the foot controller.

- ▶ The machine starts sewing in the normal sewing direction



- 6 When the end of the stitching is reached, press  ("Reverse/Reinforcement Stitch" button). Keep  ("Reverse/Reinforcement Stitch" button) held down until 3 to 5 reverse stitches are sewn.

- ▶ While  ("Reverse/Reinforcement Stitch" button) is held down, reverse stitches are sewn.



- 7** After 3 to 5 reverse stitches have been sewn, release  (“Reverse/Reinforcement Stitch” button).

▶ The machine stops sewing.


- 8** Press  /  (“Start/Stop” button), or press down on the foot controller.

At this time, if  /  (“Start/Stop” button) is held down, the machine sews at a slow speed.

▶ The machine starts sewing in the normal sewing direction.

- 9** After sewing to the end of the stitching, the sewing machine stops.


Press  /  (“Start/Stop” button) or release foot controller.



- ① Beginning of stitching
② End of stitching

■ Sewing reinforcement stitches

When sewing stitches other than straight or zigzag stitches that are secured with reverse stitching, pressing  (“Reverse/Reinforcement Stitch” button) sews reinforcement stitches, 3 to 5 stitches on top of each other.



- ① Reverse stitching
② Reinforcement stitching



Memo


- Whether reverse stitches or reinforcement stitches are sewn depends on the stitch that is selected. For details, refer to “Stitch Settings” (page 132).

Cutting the thread

When you have finished sewing, cut the threads. The threads can be cut in either of two ways.

■ Using (“Thread Cutter” button)


- 1** When you wish to finish the stitching, press  (“Thread Cutter” button) once.



- ① “Thread Cutter” button

▶ The threads are cut and the needle is raised.

- 2** Raise the presser foot lever.



- ① Presser foot lever



CAUTION

- Do not press  (“Thread Cutter” button) after the threads have already been cut, otherwise the needle may break, the threads may become tangled or damage to the machine may occur.



Note

- Do not press  (“Thread Cutter” button) if there is no fabric under the presser foot or while the machine is sewing, otherwise damage to the machine may occur.




Memo

- The machine can be set so that the threads will be cut when sewing is finished. For details on setting the machine so that the threads are cut automatically, refer to “Automatically cutting the thread” (page 61).

■ Using the manual thread cutter

When sewing with thread thicker than #30, nylon or metallic threads, or other special threads, use the thread cutter on the side of the machine to cut the threads.


- ① When you wish to finish the stitching and the sewing machine is stopped, press  (“Needle Position” button) once to raise the needle.



① “Needle Position” button


► The needle is raised.

- ② Raise the presser foot lever.



① Presser foot lever

- ③ Pull the fabric to the left side of the machine, and then pass the threads through the thread cutter to cut them.



① Thread cutter

Adjusting the Thread Tension


The tensions of the upper thread and of the bobbin thread (thread tension) should be adjusted so that they are equal.

Thread tension

You may need to change the thread tension, depending on the fabric and thread being used.

■ Correct thread tension


The upper thread and the bobbin thread should cross near the center of the fabric. Only the upper thread should be visible from the right side of the fabric, and only the bobbin thread should be visible from the wrong side of the fabric.



- ① Wrong side of fabric
- ② Right side of fabric
- ③ Upper thread
- ④ Bobbin thread

■ Upper thread is too tight


If the bobbin thread is visible from the right side of the fabric, the upper thread is too tight.



- ① Wrong side of fabric
- ② Right side of fabric
- ③ Upper thread
- ④ Bobbin thread
- ⑤ The bobbin thread is visible from the right side of the fabric.

■ Upper thread is too loose

If the upper thread is visible from the wrong side of the fabric, the upper thread is too loose.




- ① Wrong side of fabric
- ② Right side of fabric
- ③ Upper thread
- ④ Bobbin thread
- ⑤ The upper thread is visible from the wrong side of the fabric.

Changing the tension of the upper thread

The tension of the upper thread can be changed using thread tension keys.

1 Turn on the sewing machine.



▶ The LCD comes on.


2 Select a stitch.

▶ A screen containing settings for the selected stitch appears.




- For details on selecting a stitch, refer to “Selecting stitching” (page 70).
- Immediately after the stitch is selected, the standard settings (highlighted) appear.

3 To increase the thread tension, press (Thread tension key). To decrease the thread tension, press (Thread tension key).



▶ The tension of the upper thread is changed.



- If the setting is changed, the highlighting on the setting is erased.
- Now you can begin sewing. Sew trial stitches to check the thread tension, and then change the setting if necessary.



Memo

- To reset the thread tension to its standard setting, select the same stitch again or change the setting to the highlighted value.
- Press (Reset key) to return the stitch width, stitch length, and upper thread tension to their default settings.
- The settings can be saved so that they will always be specified each time the utility stitch is selected. For details, refer to “Saving stitch settings” (page 62).



Note

- If the upper thread is not threaded correctly or the bobbin is not installed correctly, it may not be possible to set the correct thread tension. If the correct thread tension cannot be achieved, rethread the upper thread and insert the bobbin correctly.


Adjusting the Stitch Width and Length

The zigzag width (pattern width) and stitch length of utility stitches can be adjusted. Normally, when a stitch is selected, the appropriate width and length are automatically selected. For details on the range of values within which the width and length can be set, refer to “Stitch Settings” (page 132).

Adjusting the stitch width

The stitch width (zigzag width) can be adjusted to make the stitch wider or narrower.

1 Turn on the sewing machine.



- ▶ The LCD comes on.


2 Select a stitch.

- ▶ A screen containing settings for the selected stitch appears.




- For details on selecting a stitch, refer to “Selecting stitching” (page 70).
- Immediately after the stitch is selected, the standard settings (highlighted) appear.

3 To make the stitch width narrower, press ◀ (Stitch width key). To make the stitch width wider, press ▶ (Stitch width key).



- ▶ The stitch width is changed.



- If the setting is changed, the highlighted value is erased.

Memo

- To reset the stitch width to its standard setting, select the same stitch again or change the setting to the highlighted value.
- Press (Reset key) to return the stitch width, stitch length, and upper thread tension to their default settings.
- If the straight stitch (left needle position or triple stretch stitch) was selected, changing the stitch width changes the needle position. Increasing the width moves the needle to the right; reducing the width moves the needle to the left.
- The settings can be saved so that they will always be specified each time the utility stitch is selected. For details, refer to “Saving stitch settings” (page 62).
- The sewing machine can be set so that the stitch width can easily be changed with the sewing speed controller. For details, refer to “Satin stitching using the sewing speed controller” (page 104).
- indicates that the setting cannot be adjusted.


CAUTION

- After adjusting the stitch width, slowly turn the handwheel toward you and check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.

Adjusting the stitch length

The stitch length can be adjusted to make the stitch longer or shorter.

1 Turn on the sewing machine.



► The LCD comes on.


2 Select a stitch.

► A screen containing settings for the selected stitch appears.




- For details on selecting a stitch, refer to “Selecting stitching” (page 70).
- Immediately after the stitch is selected, the standard settings (highlighted) appear.

3 To make the stitch length shorter, press (Stitch length key). To make the stitch length longer, press (Stitch length key).



► The stitch length is changed.



- If the setting is changed, the highlighted value is erased.



Memo

- To reset the stitch length to its standard setting, select the same stitch again or change the setting to the highlighted value.
- Press (Reset key) to return the stitch width, stitch length, and upper thread tension to their default settings.
- The settings can be saved so that they will always be specified each time the utility stitch is selected. For details, refer to “Saving stitch settings” (page 62).
- indicates that the setting cannot be adjusted.

! CAUTION

- If the stitches are bunched together, increase the stitch length. Continuing to sew with the stitches bunched together may result in the needle bending or breaking.


Useful Functions

Functions useful in improving sewing efficiency are described below.

Changing the needle stop position

When the sewing machine is purchased, it is set to leave the needle lowered in the fabric when sewing is stopped. However, the machine can be set to instead leave the needle raised when sewing is stopped.


1 Turn on the sewing machine.



▶ The LCD comes on.

2 Press (Needle stop position key).

▶  (Needle stop position key) lights up, and the machine is now set to stop with the needle in the raised position.




- To return the machine to the setting where the needle is stopped in the lowered position, press  (Needle stop position key) until the key is no longer lit.
- Even after the sewing machine is turned off, the needle stop position setting is not cancelled.

Automatically sewing reverse/reinforcement stitches

The sewing machine can be set to automatically sew reverse or reinforcement stitches at the beginning and end of the stitching. Whether reverse stitches or reinforcement stitches are sewn depends on the stitch that is selected. For details, refer to “Stitch Settings” (page 132).

1 Turn on the sewing machine.



▶ The LCD comes on.


2 Select a stitch.



- For details on selecting a stitch, refer to “Selecting stitching” (page 70).

3 Press (Automatic reverse/reinforcement stitch key).


This step is not necessary if a stitch such as those for sewing buttonholes and bar tacks is selected where reinforcement stitches are automatically sewn.



▶  (Automatic reverse/reinforcement stitch key) lights up, and the sewing machine is set for automatic reverse/reinforcement stitching.

- To turn automatic reverse/reinforcement stitching off, press  (Automatic reverse/reinforcement stitch key) until the key is no longer lit.
- When the sewing machine is turned off, the automatic reverse/reinforcement stitching setting is cancelled.

4 Position the fabric under the presser foot, and then press / (“Start/Stop” button) once.




① “Start/Stop” button

▶ After reverse/reinforcement stitches are sewn, the machine starts sewing.


5 After reaching the end of the stitching, press (“Reverse/Reinforcement Stitch” button) once.

This step is not necessary if a stitch such as those for sewing buttonholes and bar tacks is selected where reinforcement stitches are automatically sewn.



① “Reverse/Reinforcement Stitch” button

▶ After reverse/reinforcement stitches are sewn, the sewing machine stops.




Memo

- Reverse/reinforcement stitches **WILL NOT** be sewn until  (“Reverse/Reinforcement Stitch” button) is pressed.  /  (“Start/Stop” button) may be pressed to stop stitching when needed such as for pivoting corners.

Automatically cutting the thread

The sewing machine can be set to automatically cut the threads at the end of the stitching. This is called “programmed thread-cutting”. If programmed thread-cutting is set, automatic reverse/reinforcement stitching is also set. This setting is convenient if a stitch for sewing buttonholes or bar tacks is selected.

1 Turn on the sewing machine.




► The LCD comes on.

2 Select a stitch.



• For details on selecting a stitch, refer to “Selecting stitching” (page 70).


3 Press (Automatic thread cutting key).



►  (Automatic thread cutting key) and  (Automatic reverse/reinforcement stitch key) light up, and the sewing machine is set for programmed thread-cutting and automatic reverse/reinforcement stitching.

- To turn off programmed thread-cutting, press  (Automatic thread cutting key) until the key is no longer lit.
- When the sewing machine is turned off, the programmed thread-cutting setting is cancelled.

4 Position the fabric under the presser foot, and then press / (“Start/Stop” button) once.




① “Start/Stop” button

► After reverse/reinforcement stitches are sewn, the machine starts sewing.

5 After reaching the end of the stitching, press (“Reverse/Reinforcement Stitch” button) once.

This step is not necessary if a stitch such as those for sewing buttonholes and bar tacks is selected where reinforcement stitches are automatically sewn.



① “Reverse/Reinforcement Stitch” button

► After reverse/reinforcement stitches are sewn, the sewing machine stops and cuts the thread.



 The thread is cut here.

Memo


- Reverse/reinforcement stitches **WILL NOT** be sewn and the thread will not automatically be cut until  (“Reverse/Reinforcement Stitch” button) is pressed.  /  (“Start/Stop” button) may be pressed to stop stitching when needed such as for pivoting corners.

Saving stitch settings


Adjusted thread tension and stitch width and length settings can be saved so that they will be specified each time the stitch is selected. The various settings can be saved for each utility stitch.

1 Select the stitch, and then adjust the thread tension and stitch width and length.

To adjust the thread tension, press or (Thread tension keys). To adjust the stitch width, press or (Stitch width keys). To adjust the stitch length, press or (Stitch length keys).



- ① Thread tension keys
- ② Stitch width keys
- ③ Stitch length keys



- ① Upper thread tension
- ② Stitch width (mm)
- ③ Stitch length (mm)

- For details on selecting a stitch, refer to “Selecting stitching” (page 70).
- For details on changing the thread tension, refer to “Changing the tension of the upper thread” (page 56).
- ▶ The thread tension and stitch width and length are changed.

2 Press (Manual memory key).

- ▶ “Saving...” appears while the settings for the thread tension, stitch width and stitch length are being saved.
- ▶ After the settings for the thread tension, stitch width and stitch length are saved, the initial stitch screen appears again.
- The next time that the stitch is selected, the saved settings are the first ones that are displayed.
- To clear the saved settings and return the thread tension and stitch width and length to their default settings, press (Reset key). To use the default settings the next time that the stitch is selected, press (Manual memory key) to save the settings.


Hands-free raising and lowering of the presser foot

Using the knee lifter, you can raise and lower the presser foot with your knee, leaving both hands free to handle the fabric.




■ Installing the knee lifter

- 1 Turn off the sewing machine.



- 2 Insert the knee lifter into its jack on the front of the sewing machine in the lower-right corner.

Align the tabs on the knee lifter with the notches in the jack, and then insert the knee lifter as far as possible.



- 1 Tabs
- 2 Notches




Note

- If the knee lifter is not fully inserted into its jack, it may fall out while the sewing machine is operating.

■ Using the knee lifter

- 1 Stop the sewing machine.
 - Do not use the knee lifter while the sewing machine is operating.
- 2 With your knee, press the knee lifter to the right.
Keep the knee lifter pressed to the right.



- ▶ The presser foot is raised.

- 3 Release the knee lifter.

- ▶ The presser foot is lowered.

! CAUTION

- While sewing, keep your knee away from the knee lifter. If the knee lifter is pressed while the sewing machine is operating, the needle may break or the machine may be damaged.

Useful Sewing Tips

Various ways to achieve better results for your sewing projects are described below. Refer to these tips when sewing your project.

Trial sewing

After you have set up the machine with the thread and needle appropriate for the type of fabric being sewn, the machine automatically sets the thread tension and stitch length and width for the stitch that is selected. However, a trial piece of fabric should be sewn since, depending on the type of fabric and stitching being sewn, the desired results may not be achieved.

For the trial sewing, use a piece of fabric and thread that are the same as those used for your project, and check the thread tension and stitch length and width. Since the results differ depending on the type of stitching and the number of layers of fabric sewn, perform the trial sewing under the same conditions that will be used with your project.


Changing the sewing direction

1 When the stitching reaches a corner, stop the sewing machine.

Leave the needle lowered (in the fabric). If the needle remained up when the machine stopped sewing, press  (“Needle Position” button) to lower the needle.

2 Raise the presser foot lever, and then turn the fabric.


Turn the fabric using the needle as a pivot.




3 Lower the presser foot lever and continue sewing.

Sewing curves

Stop sewing, and then slightly change the sewing direction to sew around the curve. For details on sewing with an even seam allowance, refer to “Sewing an even seam allowance” (page 66).




When sewing along a curve while using a zigzag stitch, select a shorter stitch length in order to obtain a finer stitch.



Sewing thick fabrics


■ If the fabric does not fit under the presser foot

If the fabric does not fit easily under the presser foot, raise the presser foot lever even higher to bring the presser foot to its highest position.



■ If thick seams are being sewn and the fabric does not feed at the beginning of stitching


Zigzag foot “J” is equipped with a feature that keeps the presser foot level.



① Sewing direction

① When you encounter a seam that is too thick to feed under the foot, raise the presser foot lever.

② Press the black button (presser foot holding pin) on the left side of zigzag foot “J”. Keep the button held in and lower the presser foot.




① Presser foot holding pin



Note

- The presser foot needs to be in a level position before pressing the black button (presser foot holding pin) on the left side of zigzag foot “J”.

③ Release the button. The foot will lock in place level with the seam, allowing the fabric to feed.




► Once the trouble spot has been passed, the foot will return to its normal position.

! CAUTION

- If fabric more than 6 mm (15/64 inch) thick is sewn or if the fabric is pushed with too much force, the needle may bend or break.

Sewing thin fabrics


When sewing thin fabrics, the stitching may become misaligned or the fabric may not feed correctly. If this occurs, place thin paper or stabilizer material under the fabric and sew it together with the fabric. When you have finished sewing, tear off any excess paper.



① Stabilizer material or paper

Sewing stretch fabrics


First, baste the pieces of fabric together, and then sew without stretching the fabric.



① Basting

Sewing leathers or vinyl fabrics

When sewing the fabrics that may stick to the presser foot such as leathers or coated fabrics, change the presser foot to the non stick foot.




① Leather

Sewing an even seam allowance

To sew an even seam, start sewing so that the seam allowance is to the right of the presser foot, and the edge of the fabric is aligned with either the right edge of the presser foot or a marking on the needle plate.

■ Aligning the fabric with the presser foot


Sew while keeping the right edge of the presser foot a fixed distance from the edge of the fabric.



① Seam
② Presser foot

■ Aligning the fabric with the stitch guide foot


Sew while keeping the right edge of the fabric aligned with a desired position of markings on the stitch guide foot.



① Seam
② Stitch guide foot
③ Markings

■ Aligning the fabric with a needle plate marking

The markings on the needle plate show the distance from the needle position of a seam sewn with the straight stitch (left needle position). Sew while keeping the edge of the fabric aligned with a marking in the needle plate. The distance between the markings in the upper scale is 1/8 inch (3 mm) and the distance between the markings in the grid is 5 mm (3/16 inch).



① Seam
② Presser foot
③ Centimeters
④ Inches
⑤ Needle plate
⑥ 16 mm (5/8 inch)

3

UTILITY STITCHES

The various stitches and their applications are described in this chapter.

Selecting Stitching.....	68	Reinforcement Stitching.....	106
Selecting stitch types and patterns....	68	Triple stretch stitching.....	106
Selecting stitching.....	70	Bar tack stitching.....	106
Overcasting Stitches.....	74	Darning.....	108
Sewing overcasting stitches		Eyelet Stitching.....	110
using overcasting foot “G”.....	74	Horizontal Stitching.....	111
Sewing overcasting stitches		Decorative Stitching.....	113
using zigzag foot “J”.....	75	Fagoting.....	114
Sewing overcasting stitches		Scallop stitching.....	115
using the optional side cutter.....	76	Smocking.....	115
Basic Stitching.....	78	Shell tuck stitching.....	116
Basting.....	78	Joining.....	117
Basic stitching.....	79	Heirloom stitching.....	117
Blind Hem Stitching.....	80	Sewing the Various Built-In	
Buttonhole Stitching/Button Sewing....	82	Decorative Patterns.....	120
Buttonhole sewing.....	83	Sewing beautiful patterns.....	120
Button sewing.....	87	Sewing patterns.....	120
Zipper Insertion.....	89	Combining patterns.....	121
Inserting a centered zipper.....	89	Repeat sewing patterns.....	122
Inserting a side zipper.....	91	Checking the selected pattern.....	122
Zipper/piping Insertion.....	94	Changing the pattern size.....	123
Inserting a centered zipper.....	94	Changing the stitch density.....	124
Inserting a piping.....	95	Changing the pattern length.....	125
Sewing Stretch Fabrics		Shifting patterns.....	126
and Elastic Tape.....	96	Mirror imaging the pattern.....	127
Stretch stitching.....	96	Saving patterns.....	128
Elastic attaching.....	96	Retrieving a pattern.....	128
Appliqué, Patchwork		Realigning the pattern.....	129
and Quilt Stitching.....	98		
Appliqué stitching.....	99		
Patchwork (crazy quilt) stitching....	100		
Hand quilting stitch.....	100		
Piecing.....	100		
Quilting.....	102		
Free-motion quilting.....	103		
Satin stitching using the sewing			
speed controller.....	104		

Selecting Stitching

You can select any of the various types of stitching available.

Selecting stitch types and patterns


A stitch can be selected from the following types available.

Stitch patterns can be selected through either direct select (by pressing the key for a specific stitch) or number selection (by entering the number for the stitch pattern).

For details on the types of stitches available, refer to "Stitch Settings" (page 132).

■ Direct selection

After pressing  (Preset utility stitch/saved pattern key) to select the stitch mode, press the numeric key assigned with the desired stitch. With direct selection, there are two stitch modes: preset utility stitch mode  and saved pattern mode . When the machine is turned on or when the  (Preset utility stitch/saved pattern key) is pressed, the machine enters preset utility stitch mode, indicated by  in the lower-left corner of the screen. To enter saved pattern mode, indicated by  in the lower-left corner of the screen, press the  (Preset utility stitch/saved pattern key). Each press of  (Preset utility stitch/saved pattern key) switches the mode between the preset utility stitch mode  and saved pattern mode .



- ① Preset utility stitch/saved pattern key
- ② Numeric keys

□ Preset utility stitch


 The most frequently used utility stitches have been assigned to the numeric keys. These stitches can be selected simply by pressing the key.

□ Saved patterns

 Frequently used patterns and combined patterns can be saved on the machine's memory and easily retrieved using  (Preset utility stitch/saved pattern key) and the numeric keys. For details, refer to "Saving patterns" (page 128).

■ Number selection

After pressing  (Utility stitch key),  (Decorative stitch key) or  (Character stitch key) to select the stitch mode, use the numeric keys to type in the number for the desired stitch.



- ① Utility stitch key
- ② Decorative stitch key
- ③ Character stitch key
- ④ Numeric keys

□ Utility stitches (No.01-71)

 There are 71 utility stitches, including straight stitches, overcasting stitches and buttonhole stitches.

□ **Decorative stitches**

There are two decorative stitch modes: decorative stitch 1 mode  and decorative stitch 2 mode .

If  (Decorative stitch key) is pressed once, decorative stitch 1 mode  is selected. If  (Decorative stitch key) is pressed twice, decorative stitch 2 mode  is selected. Each press of  (Decorative stitch key) switches the mode between decorative stitch 1 mode  and decorative stitch 2 mode .

Decorative stitches (No.01-40)

There are 40 decorative stitches, including hearts, leaves and flowers.

Satin stitches (No.41-56)

There are 16 satin stitches.

Step patterns (No.57-58)

Satin stitches (No.41-56) can be shifted to the left or right by half the width of the pattern, allowing you to create a step-shaped pattern. Select stitch No. 57 or 58 to specify how the patterns are shifted. For details, refer to “Shifting patterns” (page 126).

Cross-stitches (No.59-68)

There are 10 types of cross-stitches.

Decorative satin stitches (No.69-79)

There are 11 decorative satin stitches.

Utility decorative stitches (No.01–39)

Some utility stitches can be used as decorative stitches. There are 39 of these stitches.

□ **Character stitches**

There are three character stitch modes: Gothic font mode , Script font mode  and outline style mode .

If  (Character stitch key) is pressed once, Gothic font mode  is selected. If  (Character stitch key) is pressed twice, Script font mode  is selected. If  (Character stitch key) is pressed three times, outline style mode  is selected. Each press of  (Character stitch key) switches the mode between the Gothic font mode , Script font mode  and outline style mode .

Gothic font (No.01-97)

There are 97 characters, including letters, symbols and numbers, in the Gothic font.

Script font (No.01-97)

There are 97 characters, including letters, symbols and numbers, in the Script font.

Outline style (No.01-97)

There are 97 characters, including letters, symbols and numbers, in the outline style.

Selecting stitching


Using the operation panel keys, select the desired stitch. Ten of the most often used utility stitches can quickly be selected with the numeric keys.

Right after turning the power on, the straight stitch (left needle position) is selected.

The machine can also be set to select the straight stitch (center needle position). For details, refer to "Changing the settings" (page 17).

1 Determine the stitch that you wish to use.

- For the numbers of the various stitches, refer to the stitch pattern plate and "Stitch Settings" (page 132).



① Stitch pattern plate

2 Determine which presser foot should be used with the selected stitch.


The presser feet are stored in the accessory compartment.

- For details on the stitches that can be sewn with the twin needle, refer to "Stitch Settings" (page 132).

3 Attach the presser foot.

- For details, refer to "Replacing the presser foot" (page 39).

4 Turn on the sewing machine.



- The straight stitch (left needle position) is shown selected in the LCD.

5 After selecting the stitch mode, select the stitch pattern.

With direct selection

With direct selection, there are two stitch modes: preset utility stitch mode  and saved pattern mode .

1 Press (Preset utility stitch/saved pattern key) to select the stitch mode.

: Preset utility stitch

The 10 stitch patterns printed on the numeric keys can be selected directly.

When  appears in the lower-left corner of the screen when the machine is turned on or when the  (Preset utility stitch/saved pattern key) is pressed.

: Saved patterns

The 10 stitch patterns saved with the numeric keys can be selected directly.

When  appears in the lower-left corner of the screen when  (Preset utility stitch/saved pattern key) is pressed.

- When a direct selection mode is selected,  (Preset utility stitch/saved pattern key) lights up.

- After the icon for the selected stitch mode appears in the center of the screen, a screen for selecting the stitch appears with the icon for the stitch mode in the lower-left corner. However, when the machine is turned on,  appears only in the lower-left corner of the screen and does not appear in the center of the screen.

- Example: preset utility stitch



2 Press the key assigned with the stitch to select the stitch.

- Continue with step 6 (on page 72).

With number selection

There are three modes of stitches that can be selected by number: utility stitch mode , decorative stitch mode  and character stitch mode .

In addition, there are two decorative stitch modes

: decorative stitch 1 mode  and decorative stitch 2 mode . There are three character stitch modes : Gothic font mode , Script font mode  and outline style mode .

1 Press the stitch mode key for the stitch that you wish to use.

Utility stitches

: 71 utility stitches are available.

Decorative stitches

1: 79 stitches, including decorative stitches, satin stitches, step patterns, cross stitch and decorative satin stitches, are available.

When  (Decorative stitch key) is pressed once.

2: 39 utility decorative stitches are available.

When  (Decorative stitch key) is pressed twice.

Character stitches

: Gothic font
97 letter, symbol and numbers are available.

When  (Character stitch key) is pressed once.

: Script font
97 letter, symbol and numbers are available.


When  (Character stitch key) is pressed twice.

: Outline style
97 letter, symbol and numbers are available.

When  (Character stitch key) is pressed three times.

- ▶ A pressed key lights up.
- ▶ After the icon for the selected stitch mode appears in the center of the screen, a screen for selecting the stitch appears with the icon for the stitch mode in the lower-left corner.

- Example: decorative stitches 



Memo


- When pressing a stitch mode key multiple times, continue pressing the key after the icon for the stitch mode appears in the lower-left corner of the screen.

2 Use the numeric keys to type in the two-digit number for the desired stitch.

For stitches 01 through 09, the stitch can also be selected by using the numeric keys to type in a one-digit number, then pressing **OK** (OK key).

▶ After the entered number appears in the center of the screen, the stitch is selected.

□ Example



- For the numbers of the various stitches, refer to the stitch pattern plate and “Stitch Settings” (page 132).
- If the first number (tens when entering two-digit numbers, ones when entering one-digit numbers) was incorrectly entered, press **↵** (Cancel/clear key) to erase the entered number.
- If an incorrect two-digit number was entered, an error beep is sounded, and the entered number is cleared.

6 If necessary, specify the setting for automatic reverse/reinforcement stitching and adjust the stitch length, etc.

- For details on sewing with each of the utility stitches, begin on page 74.



Note

- When a stitch is selected, the icon for the presser foot that should be used appears in the screen. Check that the correct presser foot is attached before starting to sew. If the wrong presser foot is installed, turn off the sewing machine, attach the correct presser foot, and then select the desired stitch again.



Memo

- For details on adjusting the stitch width and length, refer to “Adjusting the Stitch Width and Length” (page 57).

■ To select a different stitch

Check the icon in the lower-left corner of the screen for the current mode.



The current mode is indicated.

- To select a stitch in the same mode as the current one
 - In the utility stitch mode, simply type in the number for the desired stitch.
 - In the decorative stitch mode and character stitch mode, press **↵** (Cancel/clear key) to cancel the stitch, and then type in the number for the desired stitch.
 - However, if the currently selected stitch was sewn at least one time, typing in a stitch number switches to the new stitch, even if the previous stitch was not canceled.




Memo

- Patterns can be combined by selecting a different decorative stitch while a stitch is selected. For details, refer to “Saving patterns” (page 128).

- To select a stitch in a different mode as the current one
 - After selecting a different mode, type in the number for the desired stitch. (Refer to steps 5 on pages 70 through 72.)

When switching from the utility stitch mode to the decorative stitch or character stitch mode or the other way around, all stitches that have been selected are erased so that a new stitch can be selected. In order to prevent stitches from incorrectly being erased, the following confirmation message appears.



- To erase the stitch and select a different one, press  (OK key), and then change the stitch mode.
- To stop the current stitch from being erased, press  (Cancel/clear key) to return to the previous screen.



Memo

- After changing stitch settings such as the stitch length and width or after combining patterns, the stitch pattern can be saved with its current settings. For details, refer to “Saving patterns” (page 128).
-

Overcasting Stitches

Sew overcasting stitches along the edges of cut fabric to prevent fabric from fraying. Fifteen stitches are available for overcasting. The procedure for sewing overcasting stitch is explained according to the presser foot that is used.

Sewing overcasting stitches using overcasting foot “G”

Three stitches can be used to sew overcasting with overcasting foot “G”.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Overcasting stitch	11 	5 	Preventing fraying in medium weight and thin fabrics	3.5 (1/8)	2.5–5.0 (3/32–3/16)	2.0 (1/16)	1.0–4.0 (1/16–3/16)	G
	12 	6 	Preventing fraying in thick fabrics and fabrics that fray easily	5.0 (3/16)	2.5–5.0 (3/32–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	
	13 	–		5.0 (3/16)	3.5–5.0 (1/8–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	

1 Attach overcasting foot “G”.




- For details, refer to “Replacing the presser foot” (page 39).

2 Select a stitch.


- For details, refer to “Selecting stitching” (page 70).

3 Position the fabric with the edge of the fabric against the guide of the presser foot, and then lower the presser foot lever.



① Guide

4 Sew with the edge of the fabric against the presser foot guide.



① Needle drop point

! CAUTION


- After adjusting the stitch width, slowly turn the handwheel toward you (counterclockwise) and check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.

Sewing overcasting stitches using zigzag foot “J”

Seven stitches can be used to sew overcasting stitches with zigzag foot “J”.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Zigzag stitch (center needle position)	07	4	Preventing fraying (center baseline/reverse stitching)	3.5 (1/8)	0.0–7.0 (0–1/4)	1.4 (1/16)	0.0–4.0 (0–3/16)	J
Zigzag stitch (right needle position)	08	–	Preventing fraying (right baseline/reinforcement stitching)	3.5 (1/8)	2.5–5.0 (3/32–3/16)	1.4 (1/16)	0.3–4.0 (1/64–3/16)	
2-point zigzag stitch	09	–	Preventing fraying in thick fabrics and stretch fabrics	5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	
3-point zigzag stitch	10	8		5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	
Overcasting stitch	14	–	Preventing fraying in stretch fabrics	5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.5–4.0 (1/32–3/16)	
	15	–	Preventing fraying in thick fabrics and stretch fabrics	5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.5–4.0 (1/32–3/16)	
	16	–	Preventing fraying in stretch fabrics	4.0 (3/16)	0.0–7.0 (0–1/4)	4.0 (3/16)	1.0–4.0 (1/16–3/16)	

1 Attach zigzag foot “J”.




- For details, refer to “Replacing the presser foot” (page 39).


2 Select a stitch.

- For details, refer to “Selecting stitching” (page 70).

3 Sew along the edge of the fabric with the needle dropping off the edge at the right.



- ① Needle drop point



- ① Needle drop point




Memo

- For best results when sewing stretch fabrics, decrease the pressure of the presser foot. For details, refer to “Adjusting the pressure of the presser foot” (page 41).

Sewing overcasting stitches using the optional side cutter


Using the optional side cutter, seam allowances can be finished while the edge of the fabric is cut off. Five stitches can be used to sew overcasting stitches with the side cutter.

Stitch Name	Pattern 	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
			Auto	Manual	Auto	Manual	
Overcasting stitch	63 	Sewing straight stitches while cutting the fabric	0.0 (0)	0.0–2.5 (0–3/32)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	S
	64 	Sewing zigzag stitches while cutting the fabric	3.5 (1/8)	3.5–5.0 (1/8–3/16)	1.4 (1/16)	0.0–4.0 (0–3/16)	
	65 	Preventing fraying in thin and medium weight fabrics while cutting the fabric	3.5 (1/8)	3.5–5.0 (1/8–3/16)	2.0 (1/16)	1.0–4.0 (1/16–3/16)	
	66 	Preventing fraying in thick fabrics while cutting the fabric	5.0 (3/16)	3.5–5.0 (1/8–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	
	67 	Preventing fraying in thick fabrics while cutting the fabric	5.0 (3/16)	3.5–5.0 (1/8–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	




- 1 Remove the presser foot.**
 - For details, refer to “Replacing the presser foot” (page 39).
- 2 Lower the presser foot lever, and then manually thread the needle.**
 - The needle threader cannot be used. If the needle threader is used with the side cutter, the sewing machine may be damaged.
- 3 Raise the presser foot lever.**

- 4 Hook the connecting fork of the side cutter onto the needle clamp screw.**



- ① Connecting fork
- ② Needle clamp screw

- 5 Position the side cutter so that side cutter pin is aligned with the notch in the presser foot holder, and then slowly lower the presser foot lever.**




- ① Notch in presser foot holder
- ② Pin

► The side cutter is attached.

6 Raise the presser foot lever to check that the side cutter is securely attached.

7 Pass the upper thread under the side cutter, and then pull it out toward the rear of the sewing machine.




8 Select a stitch.

- For details, refer to “Selecting stitching” (page 70).

CAUTION


- After adjusting the stitch width, slowly turn the handwheel toward you (counterclockwise) and check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.

9 Make a cut of about 2 cm (3/4 inch) long in the fabric at the beginning of the stitching.



① 2 cm (3/4 inch)


10 Position the fabric in the side cutter. The cut in the fabric should be positioned over the guide plate of the side cutter.




① Guide plate

- If the fabric is not positioned correctly, the fabric will not be cut.

11 Lower the presser foot lever, and then start sewing.



- ▶ A seam allowance is cut while the stitching is sewn.
- If the stitching is sewn in a straight line, the seam allowance will be about 5 mm (3/16 inch).



① 5 mm (3/16 inch)

Memo

- The side cutter can cut as much as one layer of 13-oz. denim.
- After using the side cutter, clean it by removing any lint or dust.
- If the side cutter can no longer cut fabric, use a rag to apply a small amount of oil to the cutting edge of the cutter.

Basic Stitching


Straight stitches are used for sewing plain seams. Five stitches are available for basic stitching.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Basting stitch	06 	—	Temporarily securing	0.0 (0)	0.0–7.0 (0–1/4)	20 (3/4)	5-30 (3/16-1-3/16)	J
Straight stitch (left needle position)	01 	1 	Basic stitching and sewing gathers or pintucks (left baseline/reverse stitching)	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2-5.0 (1/64–3/16)	
	02 	—	Basic stitching and sewing gathers or pintucks (left baseline/reinforcement stitching)	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2-5.0 (1/64–3/16)	
Straight stitch (center needle position)	03 	2 	Basic stitching and sewing gathers or pintucks (center baseline/reverse stitching)	3.5 (1/8)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2-5.0 (1/64–3/16)	
Triple stretch stitch	04 	9 	Reinforcing seams and sewing stretch fabrics	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.5–4.0 (1/16–3/16)	

Basting

Sew basting with a stitch length between 5 mm (3/16 inch) and 30 mm (1-3/16 inches).

1 Attach zigzag foot “J”.




- For details, refer to “Replacing the presser foot” (page 39).

2 Select stitch 06 .

- For details, refer to “Selecting stitching” (page 70).

3 Start sewing.

- For details, refer to “Starting to sew” (page 50).




① 5-30 mm (3/16-1-3/16 inches)

Basic stitching

1 Baste or pin together the fabric pieces.

2 Attach zigzag foot “J”.



- For details, refer to “Replacing the presser foot” (page 39).

3 Select a stitch.

- For details, refer to “Selecting stitching” (page 70).

4 Lower the needle into the fabric at the beginning of the stitching.

5 Start sewing.

- For details, refer to “Starting to sew” (page 50).
- For details on sewing reverse/reinforcement stitches, refer to “Securing the stitching” (page 52).


6 When sewing is finished, cut the thread.

- For details, refer to “Cutting the thread” (page 53).




Changing the needle position

The needle position used as the baseline is different for the straight stitch (left needle position) and the straight stitch (center needle position).




- ① Straight stitch (left needle position)
- ② Straight stitch (center needle position)

When the stitch width of the straight stitch (left needle position) is set to its standard setting (0.0 mm), the distance from the needle position to the right side of the presser foot is 12 mm (1/2 inch). If the stitch width is changed (between 0 and 7.0 mm (1/4 inch)), the needle position will also change. By changing the stitch width and sewing with the right side of the presser foot aligned with the edge of the fabric, a seam allowance can be sewn with a fixed width.



- ① Stitch width setting
- ② Distance from the needle position to the right side of the presser foot
- ③ 12.0 mm (1/2 inch)
- ④ 10.0 mm (3/8 inch)
- ⑤ 6.5 mm (1/4 inch)
- ⑥ 5.0 mm (3/16 inch)



- For details, refer to “Adjusting the stitch width” (page 57).


Blind Hem Stitching

Secure the bottoms of skirts and pants with a blind hem. Two stitches are available for blind hem stitching.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Blind hem stitch	17 		Blind hem stitching on medium weight fabrics	00 (0)	3← - 3→	2.0 (1/16)	1.0-3.5 (1/16-1/8)	R
	18 	-	Blind hem stitching on stretch fabrics	00 (0)	3← - 3→	2.0 (1/16)	1.0-3.5 (1/16-1/8)	


Sew a blind hem according to the following procedure.

- 1** Fold the fabric along the desired edge of the hem, and then baste it about 5 mm (3/16 inch) from the edge of the fabric.



- ① Wrong side of fabric
- ② Basting stitching
- ③ Desired edge of hem
- ④ 5 mm (3/16 inch)

- 2** Fold back the fabric along the basting, and then position the fabric with the wrong side facing up.



- ① Wrong side of fabric
- ② Basting

- 3** Attach blind hem foot “R”.




- For details, refer to “Replacing the presser foot” (page 39).

- 4** Select a stitch.


- For details, refer to “Selecting stitching” (page 70).

- 5** Position the fabric with the edge of the folded hem against the guide of the presser foot, and then lower the presser foot lever.





- ① Wrong side of fabric
- ② Fold of hem
- ③ Guide

6 Adjust the stitch width until the needle slightly catches the fold of the hem.





① Needle drop point



① Stitch width

■ **If the needle catches too much of the hem fold**



The needle is too far to the left.
Press **▶** (of the Stitch width keys) to decrease the stitch width so that the needle slightly catches the fold of the hem.



① Wrong side of fabric
② Right side of fabric

■ **If the needle does not catch the hem fold**

The needle is too far to the right.
Press **◀** (of the Stitch width keys) to increase the stitch width so that the needle slightly catches the fold of the hem.




① Wrong side of fabric
② Right side of fabric

• For details on changing the stitch width, refer to “Adjusting the Stitch Width and Length” (page 57).

7 Sew with the fold of the hem against the presser foot guide.

8 Remove the basting stitching.



① Wrong side of fabric
② Right side of fabric



Memo

● For best results when sewing stretch fabrics, decrease the pressure of the presser foot. For details, refer to “Adjusting the pressure of the presser foot” (page 41).

3


Buttonhole Stitching/Button Sewing

Buttonholes can be sewn and buttons can be sewn on. Eleven stitches are available for sewing one-step buttonholes and one stitch for sewing on buttons.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Buttonhole stitch	48 	—	Horizontal buttonholes on thin and medium weight fabrics	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	A
	49 	—	Horizontal buttonholes on areas that are subject to strain	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	
	50 	—	Horizontal buttonholes on thick fabrics	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	
	51 		Buttonholes with bar tacks on both ends for stabilized fabrics	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	
	52 	—	Buttonholes for stretch or knit fabrics	6.0 (15/64)	3.0–6.0 (1/8–15/64)	1.0 (1/16)	0.5–2.0 (1/32–1/16)	
	53 	—	Buttonholes for stretch fabrics	6.0 (15/64)	3.0–6.0 (1/8–15/64)	1.5 (1/16)	1.0–3.0 (1/16–1/8)	
	54 	—	Bound buttonholes	5.0 (3/16)	0.0–6.0 (0–15/64)	2.0 (1/16)	0.2–4.0 (1/64–3/16)	
	55 	—	Keyhole buttonholes for thick or plush fabrics	7.0 (1/4)	3.0–7.0 (1/8–1/4)	0.5 (1/32)	0.3–1.0 (1/64–1/16)	
	56 	—	Keyhole buttonholes for medium weight and thick fabrics	7.0 (1/4)	3.0–7.0 (1/8–1/4)	0.5 (1/32)	0.3–1.0 (1/64–1/16)	
	57 	—	Horizontal buttonhole for thick or plush fabrics	7.0 (1/4)	3.0–7.0 (1/8–1/4)	0.5 (1/32)	0.3–1.0 (1/64–1/16)	
Button-sewing stitch	61 	—	Button sewing	3.5 (1/8)	2.5–4.5 (3/32–3/16)	—	—	M


Buttonhole sewing

The maximum buttonhole length is about 28 mm (1-1/8 inches) (diameter + thickness of the button). Buttonholes are sewn from the front of the presser foot to the back, as shown below.




① Reinforcement stitching

The names of parts of buttonhole foot “A”, which is used for sewing buttonholes, are indicated below.




- ① Button guide plate
- ② Presser foot scale
- ③ Pin
- ④ Marks on buttonhole foot
- ⑤ 5 mm (3/16 inch)

1 Use chalk to mark on the fabric the position and length of the buttonhole.




① Marks on fabric

2 Pull out the button guide plate of buttonhole foot “A”, and then insert the button that will be put through the buttonhole.




■ If the button does not fit in the button guide plate

Add together the diameter and thickness of the button, and then set the button guide plate to the calculated length. (The distance between the markings on the presser foot scale is 5 mm (3/16 inch).)



- ① Presser foot scale
- ② Length of buttonhole (Diameter + thickness of button)
- ③ 5 mm (3/16 inch)

Example: For a button with a diameter of 15 mm (9/16 inch) and a thickness of 10 mm (3/8 inch), the button guide plate should be set to 25 mm (1 inch) on the scale.



- ① 10 mm (3/8 inch)
- ② 15 mm (9/16 inch)

► The size of the buttonhole is set.


3 Attach buttonhole foot "A".

- For details, refer to "Replacing the presser foot" (page 39).

4 Select a stitch.

- For details, refer to "Selecting stitching" (page 70).



5 Position the fabric with the front end of the buttonhole mark aligned with the red marks on the sides of the buttonhole foot, and then lower the presser foot lever.



- ① Mark on fabric
- ② Red marks on buttonhole foot


Pass the upper thread down through the hole in the presser foot.

- When lowering the presser foot, do not push in the front of the presser foot, otherwise the buttonhole will not be sewn with the correct size.




- ① Do not reduce the gap.

6 Pull down the buttonhole lever as far as possible.




- ① Buttonhole lever

The buttonhole lever is positioned behind the bracket on the buttonhole foot.



- ① Buttonhole lever
- ② Bracket

- 7** Gently hold the end of the upper thread in your left hand, and then start sewing.




- ▶ Once sewing is completed, the machine automatically sews reinforcement stitches, then stops.

- 8** Cut the threads, raise the presser foot lever, and then remove the fabric.


- 9** Raise the buttonhole lever to its original position.

- 10** Insert a pin along the inside of one bar tack at the end of the buttonhole stitching to prevent the stitching from being cut.




① Pin

- 11** Use the seam ripper to cut towards the pin and open the buttonhole.



① Seam ripper

For keyhole buttonholes, use the eyelet punch to make a hole in the rounded end of the buttonhole, and then use the seam ripper to cut open the buttonhole.



① Eyelet punch



- When using the eyelet punch, place thick paper or some other protective sheet under the fabric before punching the hole in the fabric.

! CAUTION

- When opening the buttonhole with the seam ripper, do not place your hands in the cutting direction, otherwise injuries may result if the seam ripper slips.

■ Changing the density of the stitching



Adjust the stitch length.



- For details, refer to “Adjusting the stitch length” (page 58).
- If the fabric does not feed (for example, if it is too thick), decrease the density of the stitching.

■ **Changing the stitch width**

Adjust the stitch width.



- For details, refer to “Adjusting the stitch width” (page 57).




Memo

- Before sewing buttonholes, check the stitch length and width by sewing a trial buttonhole on a scrap piece of fabric.

■ **Sewing buttonholes on stretch fabrics**

When sewing buttonholes on stretch fabrics, use a gimp thread.

- 1 Hook the gimp thread onto the part of buttonhole foot “A” shown in the illustration so that it fits into the grooves, and then loosely tie it.




- 2 Attach buttonhole foot “A”.
 - For details, refer to “Replacing the presser foot” (page 39).

- 3 Select stitch ⁵² or ⁵³.

- 4 Adjust the stitch width to the thickness of the gimp thread.

- 5 Lower the presser foot lever and the buttonhole lever, and then start sewing.

- 6 When sewing is finished, gently pull the gimp thread to remove any slack.



- 7 Use a handsewing needle to pull the gimp thread to the wrong side of the fabric, and then tie it.


- 8 With a seam ripper, cut the middle part of the gimp thread remaining at the top end of the buttonhole.

Trim off any excess of the gimp thread.


Button sewing

Buttons can be sewn on with the sewing machine. Buttons with 2 or with 4 holes can be attached.

- 1 Measure the distance between the holes in the button to be attached.




- 2 Raise the presser foot lever, and then slide the drop feed lever, located at the rear of the machine on the base, to  (to the left as seen from the rear of the machine).



- 1 Drop feed lever (as seen from the rear of the machine)

- ▶ The feed dogs are lowered.

- 3 Attach button-sewing foot “M”.




- For details, refer to “Replacing the presser foot” (page 39).

- 4 Select stitch .

- For details, refer to “Selecting stitching” (page 70).
- Since the end of the thread will be tied off later, do not set the sewing machine for programmed-thread cutting.

- 5 Adjust the stitch width so that it is the same as the distance between the holes in the button.


- 6 Place the button into button-sewing foot “M”.




- 1 Button

- ▶ The button is held in place.

- When attaching four-hole buttons, first sew the two holes closest to you. Then, slide the button so that the needle goes into the two holes toward the rear of the sewing machine, and then sew them in the same way.



- 7 Turn the handwheel toward you (counterclockwise) to check that the needle correctly goes into the two holes of the button. If it seems as if the needle will hit the button, remeasure the distance between the holes in the button. Adjust the stitch width to the distance between the button holes.




CAUTION

- When sewing, be sure that the needle does not touch the button, otherwise the needle may bend or break.

8 Start sewing.

Set the sewing speed controller to the left (so that the speed will be slow).




- ▶ The sewing machine automatically stops after sewing reinforcement stitches.
- If additional strength is needed to secure the button, perform the button-sewing operation twice.
- Do not press  (“Thread Cutter” button).

9 Use scissors to cut the upper thread and the bobbin thread at the beginning of the stitching.

Pull the upper thread at the end of the stitching to the wrong side of the fabric, and then tie it with the bobbin thread.



10 When you are finished attaching the button, slide the drop feed lever to  (to the right as seen from the rear of the machine) to raise the feed dogs.



① Drop feed lever (as seen from the rear of the machine)




Memo

- The feed dog position switch is normally set to the right side (as seen from the rear of machine).
- The feed dogs come up when you start sewing again.

■ Attaching a shank to a button

To sew the button with a shank, attach the button with space between it and the fabric, and then wind the thread by hand. This attaches the button securely.

1 Place the button into button-sewing foot “M”, and then pull the shank lever toward you.



① Shank lever

2 After sewing is finished, cut the upper thread with plenty of excess, wind it around the thread between the button and the fabric, and then tie it to the upper thread at the beginning of the stitching.

Tie together the ends of the bobbin thread at the end and at the beginning of the stitching on the wrong side of the fabric.



3 Cut off any excess thread.

Zipper Insertion


A zipper can be sewn in place.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Straight stitch (center needle position)			Attaching zippers Sewing concealed seams and pintucks	3.5 (1/8)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	

There are many methods for inserting zippers. The procedures for inserting a centered zipper and a side zipper are described below.

Inserting a centered zipper

Stitching is sewn on both pieces of fabric butted against each other.




- ① Right side of fabric
- ② Stitching
- ③ End of zipper opening

1 Attach zigzag foot “J” and sew straight stitches up to the zipper opening.

With the right sides of the fabric facing each other, sew reverse stitches after reaching the zipper opening.


- For details, refer to “Basic stitching” (page 79).

2 Using a basting stitch, continue sewing to the edge of the fabric.




- ① Basting stitching
- ② Reverse stitches
- ③ Wrong side of fabric
- ④ End of zipper opening

3 Press open the seam allowance from the wrong side of the fabric.




- ① Wrong side of fabric

4 Align the seam with the center of the zipper, and then baste the zipper in place.



- ① Wrong side of fabric
- ② Basting stitching
- ③ Zipper

- 5** Attach the presser foot holder to the right pin of zipper foot “I”.



- ① Pin on the right side
- ② Needle drop point

- For details, refer to “Replacing the presser foot” (page 39).



- 6** Select stitch ⁰³ .

- For details, refer to “Selecting stitching” (page 70).

! CAUTION

- When using zipper foot “I”, be sure to select the straight stitch (center needle position), and slowly turn the handwheel toward you (counterclockwise) to check that the needle does not touch the presser foot. If a different stitch is selected or the needle hits the presser foot, the needle may bend or break.

- 7** Topstitch around the zipper.



- ① Stitching
- ② Right side of fabric
- ③ Basting stitching
- ④ End of zipper opening


! CAUTION

- When sewing, be sure that the needle does not touch the zipper, otherwise the needle may bend or break.

- 8** Remove the basting stitching.

Inserting a side zipper

Stitching is sewn on only one piece of fabric. Use this type of zipper application for side openings and back openings.



- ① Stitching
- ② Right side of fabric
- ③ End of zipper opening


The following procedure will describe how to stitch on the left side, as shown in the illustration.

1 Attach zigzag foot “J” and sew straight stitches up to the zipper opening.

With the right sides of the fabric facing each other, sew reverse stitches after reaching the zipper opening.


- For details, refer to “Basic stitching” (page 79).

2 Using a basting stitch, continue sewing to the edge of the fabric.




- ① Basting stitching
- ② Reverse stitches
- ③ Wrong side of fabric
- ④ End of zipper opening

3 Press open the seam allowance from the wrong side of the fabric.




- ① Wrong side of fabric

4 Press the seam allowance so that the right side (the side that will not be stitched) has an extra 3 mm (1/8 inch).



- ① Wrong side of fabric
- ② 3 mm (1/8 inch)


5 Align the zipper teeth with the pressed edge of the fabric having the extra 3 mm (1/8 inch), and then baste or pin the zipper in place.



- ① Zipper teeth
- ② Basting stitching

6 Attach the presser foot holder to the right pin of zipper foot “I”.

If the stitching will be sewn on the right side, attach the presser foot holder to the left pin of the zipper foot.



- ① Pin on the right side
- ② Needle drop point

- For details, refer to “Replacing the presser foot” (page 39).


7 Select stitch ⁰³ .

- For details, refer to “Selecting stitching” (page 70).

! CAUTION

● When using zipper foot “I”, be sure to select the straight stitch (center needle position), and slowly turn the handwheel toward you (counterclockwise) to check that the needle does not touch the presser foot. If a different stitch is selected or the needle hits the presser foot, the needle may bend or break.


8 Sew the zipper to the piece of fabric with the extra 3 mm (1/8 inch), starting from the base of the zipper.




! CAUTION

● When sewing, be sure that the needle does not touch the zipper, otherwise the needle may bend or break.

9 When you are about 5 cm (2 inches) from the end of the zipper, stop the sewing machine with the needle lowered (in the fabric), raise the presser foot lever, and then open the zipper and continue sewing.




10 Close the zipper, turn over the fabric, and then baste the other side of the zipper to the fabric.



① Basting stitching

11 Attach the presser foot holder to the other pin of zipper foot “I”.


If the presser foot holder was attached to the right pin in step **6**, change it to the left pin.



① Pin on the left side
② Needle drop point

12 **Topstitch around the zipper.**

Sew reverse stitches at the end of the zipper opening and align the zipper teeth with the side of the presser foot.




① Right side of fabric
② End of zipper opening
③ Reverse stitches
④ Beginning of stitching
⑤ Basting stitching

! CAUTION

● When sewing, be sure that the needle does not touch the zipper, otherwise the needle may bend or break.

13 When you are about 5 cm (2 inches) from the end of the zipper, stop the sewing machine with the needle lowered (in the fabric), raise the presser foot lever, and then open the zipper and continue sewing.

14 Remove the basting stitching.



Zipper/piping Insertion


A zipper and piping can be sewn in place.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Straight stitch (left needle position)	01 		Attaching zippers Sewing concealed seams and piping	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	

There are many methods for inserting zippers and pipings. The procedures for inserting a centered zipper and a piping are described below, with the adjustable zipper/piping foot.

Inserting a centered zipper


- 1 Refer to step 1–4 of “Inserting a centered zipper” (page 89).
- 2 Remove the presser foot and presser foot holder (page 41) to attach the screw-on adjustable zipper/piping foot.



Note



- Use a screw driver to securely tighten the screw that holds the presser foot. If the screw is loose, the needle may break and cause injuries.

- 3 Select stitch 01 .
- 4 Loosen the positioning screw on the back of the presser foot.




① Positioning screw

- 5 Slide the presser foot over either the left or right feed dog.



Left sewing position



Right sewing position

- 6 Change the needle position so that the needle does not touch the presser foot. For details, refer to “Adjusting the stitch width” (page 57).




① Needle drop point

CAUTION



- After adjusting the needle position, slowly turn the handwheel toward you and check the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.

- Securely tighten the positioning screw with a screwdriver.



① Positioning screw

- Topstitch around the zipper.



① Stitching
② Right side of fabric
③ Basting stitching
④ End of zipper opening


! CAUTION

- When sewing, be sure that the needle does not touch the zipper, otherwise the needle may bend or break.

- Remove the basting stitching.

Inserting a piping


- Place the piping between two fabric pieces turned inside out, as shown below.




① Fabric
② Piping
③ Fabric

- Refer to the steps of attaching the adjustable zipper/piping foot (page 94).

- Sew along the piping.



- After sewing, turn fabric pieces.



Sewing Stretch Fabrics and Elastic Tape


Stretch fabrics can be sewn and elastic tape can be attached.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Stretch stitch	05 		Stretch fabrics	1.0 (1/16)	1.0–3.0 (1/16–1/8)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	J
2-point zigzag stitch	09 	–	Attaching elastic	5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	
3-point zigzag stitch	10 			5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	
Elastic-attaching stitch	34 	–	Attaching elastic to stretch fabrics	4.0 (3/16)	0.0–7.0 (0–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	

Observe the corresponding precautions when performing each of the following stitching operations.

Stretch stitching

1 Attach zigzag foot “J”.




- For details, refer to “Replacing the presser foot” (page 39).

2 Select stitch 05 .

- For details, refer to “Selecting stitching” (page 70).

3 Sew the fabric without stretching it.




Elastic attaching

When elastic tape is attached to the cuff or waist of a piece of clothing, the finished dimensions will be that of the stretched elastic tape. therefore, it is necessary that a suitable length of the elastic tape be used.


1 Pin the elastic tape to the wrong side of the fabric.

Pin the elastic tape to the fabric at a few points to make sure that the tape is uniformly positioned on the fabric.



- ① Elastic tape
- ② Pin

2 Attach zigzag foot “J”.





- For details, refer to “Replacing the presser foot” (page 39).

3 Select a stitch.

- For details, refer to “Selecting stitching” (page 70).

4 Sew the elastic tape to the fabric while stretching the tape so that it is the same length as the fabric.

While pulling the fabric behind the presser foot with your left hand, pull the fabric at the pin nearest the front of the presser foot with your right hand.



CAUTION

- When sewing, be sure that the needle does not touch any pins, otherwise the needle may bend or break.

Appliqué, Patchwork and Quilt Stitching


The stitches that can be used for sewing appliqués, patchwork and quilts are described below.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Zigzag stitch	07 		Attaching appliqués (center baseline/reverse stitching)	3.5 (1/8)	0.0–7.0 (0–1/4)	1.4 (1/16)	0.0–4.0 (0–3/16)	J
	24 	–	Appliqué quilting, free-motion quilting, satin stitching	3.5 (1/8)	0.0–7.0 (0–1/4)	1.4 (1/16)	0.0–4.0 (0–3/16)	
Appliqué stitch	19 	–	Attaching appliqués	3.5 (1/8)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.6–4.0 (1/16–3/16)	
	25 	–	Attaching appliqués and binding	1.5 (1/16)	0.5–5.0 (1/32–3/16)	1.8 (1/16)	1.0–4.0 (1/16–3/16)	
Piecing straight stitch	21 	–	Piecing straight stitching (with a seam allowance of 6.5 mm (1/4 inch) from the right edge of the presser foot)	5.5 (7/32)	0.0–7.0 (0–1/4)	2.0 (1/16)	0.2–5.0 (1/64–3/16)	
	22 	–	Piecing straight stitching (with a seam allowance of 6.5 mm (1/4 inch) from the left edge of the presser foot)	1.5 (1/16)	0.0–7.0 (0–1/4)	2.0 (1/16)	0.2–5.0 (1/64–3/16)	
Joining stitch	28 	–	Patchwork stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	1.2 (1/16)	0.2–4.0 (1/64–3/16)	
	29 	–		5.0 (3/16)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	
	30 	–		5.0 (3/16)	0.0–7.0 (0–1/4)	1.2 (1/16)	0.2–4.0 (1/64–3/16)	
Mock hand quilting stitch	23 	–	Straight stitch quilting that looks hand quilting	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	
Quilting stippling	26 	–	Stippling	7.0 (1/4)	1.0–7.0 (1/16–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	

Appliqué stitching


For best results, use the included open toe foot.

- 1 Cut out the appliqué, leaving a seam allowance of between 3 and 5 mm (1/8 and 3/16 inch).




① Seam allowance

- 2 Place a pattern made of thick paper or stabilizer on the back of the appliqué, and then fold over the seam allowance using an iron.




- Remove the thick paper after pressing the seam allowance.

- 3 Turn the fabric over, and then baste or pin it onto the fabric that it will be attached to.



① Basting stitching

- 4 Attach the open toe foot.




- For details, refer to “Replacing the presser foot” (page 39).


- 5 Select a stitch.

- For details, refer to “Selecting stitching” (page 70).

- 6 Turn the handwheel toward you (counterclockwise), and then begin sewing around the edge of the appliqué, making sure that the needle drops just outside of the appliqué.





When sewing around corners, stop the machine with the needle in the fabric just outside of the appliqué, raise the presser foot lever, and then turn the fabric as needed to change the sewing direction.



Patchwork (crazy quilt) stitching

- 1 Fold the edge of the top piece of fabric and place it over the lower piece.
- 2 Sew the two pieces of fabric together so the pattern spans over both pieces.



Hand quilting stitch

You can duplicate the look of a hand quilted stitch by using monofilament thread in the needle, 50 to 60 weight cotton thread in the bobbin, and increasing the needle tension.


The needle tension will need to be determined by the thickness of your batting.

Piecing

Sewing together two pieces of fabric is called “piecing”. The fabric pieces should be cut with a 6.5 mm (1/4 inch) seam allowance. Sew a piecing straight stitch 6.5 mm (1/4 inch) from either the right side or the left side of the presser foot.

- 1 Baste or pin along the seam allowance of the fabric that you wish to piece together.

- 2 Attach zigzag foot “J”.



- For details, refer to “Replacing the presser foot” (page 39).


- 3 Select stitch ²¹ or ²².

- For details, refer to “Selecting stitching” (page 70).

- 4 Sew with the side of the presser foot aligned with the edge of the fabric.

■ For a seam allowance on the right side


Align the right side of the presser foot with the edge of the fabric, and sew using stitch



- ① 6.5 mm (1/4 inch)

■ **For a seam allowance on the left side**

Align the left side of the presser foot with the edge of the fabric, and sew using stitch



① 6.5 mm (1/4 inch)



Memo


- To change the width of the seam allowance (the needle position), adjust the stitch width.

■ **Using the 1/4 inch quilting foot**

If the 1/4 inch quilting foot is used, seams can be sewn with a seam allowance of 6.4 mm (1/4 inch).

① **Baste or pin along the seam allowance of the fabric that you wish to piece together.**

② **Attach the 1/4 inch quilting foot.**




- For details, refer to "Replacing the presser foot" (page 39).

③ **Select stitch ⁰³**




④ **Align the mark at the upper edge of the 1/4 inch quilting foot with the upper edge of the fabric.**

Align the right edge of the fabric with the right edge of the narrow part of the 1/4 inch quilting foot.



- ① Mark on 1/4 inch quilting foot
- ② Beginning of stitching

When sewing with a seam allowance, align the left edge of the narrow part of the 1/4 inch quilting foot with the fabric edge.




- ① Seam (3.2 mm (1/8 inch))


⑤ **Start sewing.**

⑥ **When the end of the stitching is reached, stop the sewing machine.**

Sew until the mark at the lower edge of the 1/4 inch quilting foot aligns with the lower edge of the fabric.




- ① 6.4mm (1/4 inch)
- ② End of stitching
- ③ Mark on 1/4 inch quilting foot



Quilting

Sandwiching batting between the top and bottom layers of fabric is called “quilting”. Quilts can easily be sewn using the walking foot and the quilting guide.

- 1 **Baste the fabric to be quilted.**
- 2 **Attach the walking foot.**
 - For details, refer to “Using the walking foot” (page 42).
- 3 **Select a stitch.**
 - For details, refer to “Selecting Stitching” (page 68).
- 4 **Place one hand on each side of the presser foot, and hold fabric taut while sewing.**



Note

- When sewing with the walking foot, sew at a speed between slow and medium.

■ Using the quilting guide

Use the quilting guide to sew parallel stitches that are equally spaced.




- 1 **Insert the stem of the quilting guide into the hole at the rear of the walking foot or presser foot holder.**


- Walking foot



- Presser foot holder




- 2 **Adjust the stem of the quilting guide so that the guide aligns with the seam that has already been sewn.**



Free-motion quilting

With free-motion quilting, lower the feed dogs (using the drop feed lever) so that the fabric can be moved freely in any direction.

The quilting foot is needed for free-motion quilting.




1 Remove the presser foot and the presser foot holder.

- Refer to “Removing the presser foot holder” (page 41).


2 Secure the quilting foot with the presser foot holder screw.

The pin on the quilting foot should be positioned over the needle clamp screw.



- ① Pin on quilting foot
- ② Presser foot holder screw
- ③ Needle clamp screw

3 Hold the quilting foot in place with your right hand, and then tighten the presser foot holder screw using the screwdriver in your left hand.




- ① Presser foot holder screw

! CAUTION

- Be sure to securely tighten the screws with the screwdriver, otherwise the needle may touch the presser foot, causing it to bend or break.

4 Slide the drop feed lever, located at the rear of the machine on the base, to (to the left as seen from the rear of the machine).



- ① Feed dog position switch (as seen from the rear of the machine)


► The feed dogs are lowered.

5 Turn on the sewing machine, and then select a stitch.

- For details, refer to “Selecting stitching” (page 70).


6 Use both hands to hold the fabric taut, and then move the fabric to follow the pattern.

Reinforcement stitches are sewn at the beginning and end of sewing.



- ① Pattern

7 After sewing is finished, slide the drop feed lever to (to the right as seen from the rear of the machine) to raise the feed dogs.



- ① Drop feed lever (as seen from the rear of the machine)

- Normally, the drop feed lever is positioned at the right.


Satin stitching using the sewing speed controller

A decorative stitch can be sewn by changing the stitch width of a satin stitch. If the sewing machine is set so that the stitch width can be adjusted using the sewing speed controller, the stitch width can quickly and easily be adjusted. In this case, the sewing speed is adjusted with the foot controller.

1 Connect the foot controller.

- For details, refer to “Starting to sew” (page 50).

2 Attach zigzag foot “J”.




- For details, refer to “Replacing the presser foot” (page 39).

3 Turn on the sewing machine, and then press (Settings key) in the operation panel.

- ▶ The settings screen appears.



4 Press or (Stitch length keys) until is displayed.





- ▶ The screen for specifying that the stitch width can be controlled with the sewing speed controller appears.



5 Press or (Stitch width keys) to select ON.

To return to OFF, press  or  (Stitch width keys).



- ▶ The machine is now set so that the stitch width can be controlled with the sewing speed controller.

6 Press (OK key) or (Cancel/clear key).


- ▶ The initial stitch screen appears again.

7 Select stitch .

- For details, refer to “Selecting stitching” (page 70).

8 While sewing, slide the sewing speed controller to adjust the stitch width.

Slide the controller to the left to make the width narrower. Slide the controller to the right to make the width wider.



- Adjust the sewing speed with the foot controller.

-
-
- 9** When you are finished sewing, set the stitch width control setting back to OFF.



Memo

- Although the stitching result differs depending on the type of fabric being sewn and the thickness of the thread being used, for best results, adjust the stitch length to between 0.3 and 0.5 mm (1/64 and 1/32 inch).
-

Reinforcement Stitching


Reinforce points that will be subject to strain, such as sleeve holes, inseams and pocket corners.

Stitch Name	Pattern	Numeric Key	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
				Auto	Manual	Auto	Manual	
Triple stretch stitch	04 		Reinforcing the seams of sleeves and inseams	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.5–4.0 (1/16–3/16)	J
Bar tack stitch	60 	–	Reinforcing the ends of openings, such as the corners of pockets	2.0 (1/16)	1.0–3.0 (1/16–1/8)	0.4 (1/64)	0.3–1.0 (1/64–1/16)	A
Darning stitch	58 	–	Darning medium weight fabrics	7.0 (1/4)	2.5–7.0 (3/32–1/4)	2.0 (1/16)	0.4–2.5 (1/64–3/32)	
	59 	–	Darning thick fabrics	7.0 (1/4)	2.5–7.0 (3/32–1/4)	2.0 (1/16)	0.4–2.5 (1/64–3/32)	

Triple stretch stitching

Use triple stretch stitching to reinforce sleeve holes and inseams.

1 Attach zigzag foot “J”.



- For details, refer to “Replacing the presser foot” (page 39).

2 Select stitch 04 .

- For details, refer to “Selecting stitching” (page 70).


3 Start sewing.

- For details, refer to “Starting to sew” (page 50).

Bar tack stitching


Bar tacks are used to reinforce points subject to strain, such as pocket corners and openings.

As an example, the procedure for sewing bar tacks at pocket corners is described below.



1 Determine the desired length of the bar tack.

Set the button guide plate on buttonhole foot “A” to the desired length. (The distance between the markings on the presser foot scale is 5 mm (3/16 inch).)



- Presser foot scale
- Length of bar tack
- 5 mm (3/16 inch)

- A bar tack with a maximum length of about 28 mm (1–1/8 inches) can be sewn.


2 Attach buttonhole foot "A".

- For details, refer to "Replacing the presser foot" (page 39).

3 Select stitch ⁶⁰ .

- For details, refer to "Selecting stitching" (page 70).



4 Position the fabric so that the opening of the pocket faces toward you, and then lower the presser foot lever so that the needle drops 2 mm (1/16 inch) in front of the pocket opening.



① 2 mm (1/16 inch)


Pass the upper thread down through the hole in the presser foot.

- When lowering the presser foot, do not push in the front of the presser foot, otherwise the bar tack will not be sewn with the correct size.




① Do not reduce the gap.

5 Pull down the buttonhole lever as far as possible.



① Buttonhole lever


The buttonhole lever is positioned behind the bracket on the buttonhole foot.



① Buttonhole lever

② Bracket

6 Gently hold the end of the upper thread in your left hand, and then start sewing.



- ▶ Once sewing is completed, the machine automatically sews reinforcement stitches, then stops.

7 Cut the threads, raise the presser foot lever, and then remove the fabric.

8 Raise the buttonhole lever to its original position.




Memo

- If the fabric does not feed, for example, because it is too thick, increase the stitch length. For details, refer to "Adjusting the stitch length" (page 58).


Darning

Fabric that has been torn can be darned.
Darning is sewn as shown below.



① Reinforcement stitching

- Determine the desired length of the darning.**
Set the button guide plate on buttonhole foot "A" to the desired length. (The distance between the markings on the presser foot scale is 5 mm (3/16 inch).)



- ① Presser foot scale
- ② Length of darning
- ③ 5 mm (3/16 inch)
- ④ 7 mm (1/4 inch)


- Attach buttonhole foot "A".**

- For details, refer to "Replacing the presser foot" (page 39).

- Select stitch 58 or 59.**

- For details, refer to "Selecting stitching" (page 70).



- Position the fabric so that the needle is 2 mm (1/16 inch) in front of the area to be darned, and then lower the presser foot lever.**



- ① Tear
- ② 2 mm (1/16 inch)


Pass the upper thread down through the hole in the presser foot.

- When lowering the presser foot, do not push in the front of the presser foot, otherwise the darning will not be sewn with the correct size.




- ① Do not reduce the gap.

- 5 Pull down the buttonhole lever as far as possible.**




- ① Buttonhole lever

The buttonhole lever is positioned behind the bracket on the buttonhole foot.



- ① Buttonhole lever
② Bracket

- 6 Gently hold the end of the upper thread in your left hand, and then start sewing.**



- Once sewing is completed, the machine automatically sews reinforcement stitches, then stops.

- 7 Cut the threads, raise the presser foot lever, and then remove the fabric.**

- 8 Raise the buttonhole lever to its original position.**



Memo


- If the fabric does not feed, for example, because it is too thick, increase the stitch length. For details, refer to “Adjusting the stitch length” (page 58).

Eyelet Stitching

Eyelets, such as those on belts, can be sewn. Three sizes of eyelets are possible: 7 mm, 6 mm and 5 mm (1/4, 15/64 and 3/16 inch).

Stitch Name	Pattern 	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
			Auto	Manual	Auto	Manual	
Eyelet stitch	62 	Sewing eyelets, for example, on belts	7.0 (1/4)	7.0, 6.0 or 5.0 (1/4, 15/64 or 3/16)	–	–	N

1 Attach monogramming foot “N”.



- For details, refer to “Replacing the presser foot” (page 39).

2 Select stitch 62


- For details, refer to “Selecting stitching” (page 70).

3 Adjust either the stitch width or the stitch length to select the desired eyelet size.



- For details, refer to “Adjusting the stitch width” (page 57).


4 Lower the needle into the fabric at the beginning of the stitching, and then lower the presser foot lever.



5 Start sewing.

- ▶ Once sewing is completed, the machine automatically sews reinforcement stitches, then stops.

6 Use the eyelet punch to cut a hole in the center of the eyelet.



- When using the eyelet punch, place thick paper or some other protective sheet under the fabric before punching the hole in the fabric.



Memo


- If light weight thread is used, the stitching may be sparse. If this occurs, sew the eyelet twice before removing the fabric, one on top of the other.

Horizontal Stitching

Horizontal stitching is used to attach appliqués to fabric that cannot be moved around, such as cylindrical pieces. Straight stitches and zigzag stitches that sew to either the left or right are available.

Stitch Name	Pattern	Application	Stitch Width [mm (inch)]	Stitch Length [mm (inch)]	Presser Foot
Horizontal straight stitch	68 	Attaching appliqués to sleeves (straight stitch sewn to the left)	—	—	N
	69 	Attaching appliqués to sleeves (straight stitch sewn to the right)	—	—	
Horizontal zigzag stitch	70 	Attaching appliqués to sleeves (zigzag stitch sewn to the left)	—	—	
	71 	Attaching appliqués to sleeves (zigzag stitch sewn to the right)	—	—	

The illustration below shows the sewing order for the following explanation.




1 Remove the flat bed attachment.

- For details, refer to “Stitching cylindrical pieces” (page 44).

2 Attach monogramming foot “N”.

- For details, refer to “Replacing the presser foot” (page 39).




3 Select stitch .

- For details, refer to “Selecting stitching” (page 70).

4 Lower the needle into the fabric at the beginning of the stitching, and then start sewing.


Lower the needle at the upper-right corner.



- The fabric is fed toward the back of the machine, as usual.

5 After you have sewn to the corner, stop the sewing machine, and then select stitch .

6 Start sewing.




- The fabric is fed to the right.

7 After you have sewn to the corner, stop the sewing machine, and then select stitch .

8 Press  (“Reverse/Reinforcement Stitch” button).


Press and hold the “Reverse/Reinforcement Stitch” button until the stitching reaches the upper-left corner.



► The fabric is fed forward.

9 After you have sewn to the corner, stop the sewing machine, and then select stitch  ⁶⁹ →.

10 Start sewing.



► The fabric is fed to the left.

11 After you have sewn to the corner, stop the sewing machine, and then select stitch  ⁰¹ again.

12 After sewing 3 to 5 stitches at the beginning of the stitching, stop the sewing machine.



Memo

- The feeding direction of the fabric differs depending on the stitch that is selected. Be sure to guide the fabric while it is sewn.

Decorative Stitching

Various decorative stitches can be sewn with this sewing machine.


Stitch Name	Pattern 	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot	
			Auto	Manual	Auto	Manual		
Fagoting stitch	32 	Sewing two pieces of fabric together across an open seam	5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	J	
	33 		5.0 (3/16)	2.5–7.0 (3/25–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)		
Joining stitch	28 	Decorative bridging stitches	4.0 (3/16)	0.0–7.0 (0–1/4)	1.2 (1/16)	0.2–4.0 (1/64–3/16)		
	29 		5.0 (3/16)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)		
	30 		5.0 (3/16)	0.0–7.0 (0–1/4)	1.2 (1/16)	0.2–4.0 (1/64–3/16)		
Shell tuck stitch	20 	Shell tuck stitching on collars and curves	4.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–4.0 (1/64–3/16)		
Smocking stitch	31 	Smocking fabrics to add texture and elasticity	5.0 (3/16)	0.0–7.0 (0–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)		
	32 		5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)		
	33 		5.0 (3/16)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)		
Scallop stitch	27 	Satin scallop stitching	5.0 (3/16)	2.5–7.0 (3/32–1/4)	0.5 (1/32)	0.1–1.0 (1/64–1/16)		
Hemstitching	39 	Lace sewing, decorative hemming, heirloom stitching, etc.	3.5 (1/8)	1.5–7.0 (1/16–1/4)	2.5 (3/32)	1.6–4.0 (1/16–3/16)		N
	40 		6.0 (15/64)	1.5–7.0 (1/16–1/4)	3.0 (1/8)	1.5–4.0 (1/16–3/16)		
	41 	Decorative hemming and heirloom stitching, etc. on thin, medium weight and plain weave fabrics	5.0 (3/16)	1.5–7.0 (1/16–1/4)	3.5 (1/8)	1.5–4.0 (1/16–3/16)		
	42 		5.0 (3/16)	1.5–7.0 (1/16–1/4)	4.0 (3/16)	1.5–4.0 (1/16–3/16)		
	43 		5.0 (3/16)	1.5–7.0 (1/16–1/4)	2.5 (3/32)	1.5–4.0 (1/16–3/16)		
	44 		5.0 (3/16)	1.5–7.0 (1/16–1/4)	2.0 (1/16)	1.5–4.0 (1/16–3/16)		
45 	Decorative hemming, ribbon threading, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	3.0 (1/8)	1.5–4.0 (1/16–3/16)			

Stitch Name	Pattern	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Presser Foot
			Auto	Manual	Auto	Manual	
Hemstitching	46	Heirloom stitching, etc.	6.0 (15/64)	1.5–7.0 (1/16–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	N
	47		5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	
Ladder stitch	35	Decorative stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	3.0 (1/8)	2.0–4.0 (1/16–3/16)	J
Rick-rack stitch	36		4.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	
Decorative stitch	37		5.5 (7/32)	0.0–7.0 (0–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	
Serpentine stitch	38		5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	

Fagoting


Stitching across an open seam is called “fagoting”. It is used on blouses and children's clothing. This stitch is more decorative when thicker thread is used.

- Use an iron to fold the two pieces of fabric along their seams.
- Baste the two pieces of fabric, separated by about 4 mm (3/16 inch), onto thin paper or a sheet of water-soluble stabilizer.
If you draw a line down the middle of the thin paper or water-soluble stabilizer, sewing is easier.



- Thin paper or water soluble stabilizer
- Basting stitching
- 4 mm (3/16 inch)

- Attach zigzag foot “J”.



- For details, refer to “Replacing the presser foot” (page 39).



- Select stitch ³² or ³³

- For details, refer to “Selecting stitching” (page 70).

- Set the stitch width to 7.0 mm (1/4 inch).

- For details, refer to “Adjusting the stitch width” (page 57).

- Sew with the center of the presser foot aligned along the center of the two pieces of fabric.




- After sewing is finished, remove the paper.

Scallop stitching

The wave-shaped repeating pattern that looks like shells is called “scalloping”. It is used on the collars of blouses and to decorate the edges of handkerchiefs.

1 Attach monogramming foot “N”.




- For details, refer to “Replacing the presser foot” (page 39).

2 Select stitch ²⁷.


- For details, refer to “Selecting stitching” (page 70).

3 Stitch along the edge of the fabric, making sure not to sew directly on the edge of the fabric.



- For better results, apply spray starch to the fabric and press with a hot iron before it is sewn.

4 Trim along the stitches.




- Be careful not to cut the stitches.

Smocking

The decorative stitch created by stitching or embroidering over gathers is called “smocking”. It is used to decorate the front of blouses or cuffs. The smocking stitch adds texture and elasticity to fabric.

1 Attach zigzag foot “J”.




- For details, refer to “Replacing the presser foot” (page 39).

2 Select the straight stitch, and then adjust the stitch length to 4.0 mm (3/16 inch) and loosen the thread tension.

- For details, refer to “Adjusting the stitch length” (page 58) and “Thread tension” (page 55).


3 Sew parallel stitching at intervals of 1 cm (3/8 inch).



① 1 cm (3/8 inch)

- It is not necessary to sew reverse/reinforcement stitches or cut the thread.
- At the end of the stitching, the thread is pulled out about 5 cm (2 inches).


4 Pull the bobbin threads to create gathers. Smooth the gathers by ironing them.




5 Select stitch ³¹ , ³²  or ³³ .

- For details, refer to “Selecting stitching” (page 70).

6 Stitch between the straight stitches.




7 Pull out the threads for the straight stitches.




Shell tuck stitching

The gathers that look like shells are called “shell tucks”. They are used to decorate trims, the front of blouses or cuffs made of thin fabrics.

1 Fold the fabric along the bias.



2 Attach zigzag foot “J”.





- For details, refer to “Replacing the presser foot” (page 39).

3 Select stitch ²⁰ , and then increase the thread tension.


- For details, refer to “Selecting stitching” (page 70).

4 Sew while making sure that the needle drops slightly off the edge of the fabric.



① Needle drop point


5 Unfold the fabric, and then iron the tucks down to one side.



Joining


Decorative bridging stitches can be sewn over the seam allowance of joined fabrics. This is used when making a crazy quilt.

1 Attach zigzag foot “J”.



- For details, refer to “Replacing the presser foot” (page 39).

2 Sew together the right sides of the two pieces of fabric, and then open up the seam allowances.




- ① Wrong side of fabric
- ② 7.0 mm (1/4 inch) seam allowance
- ③ Straight stitch

3 Select stitch ²⁸ , ²⁹ or ³⁰ .

- For details, refer to “Selecting stitching” (page 70).

4 Turn the fabric over so that the right side faces up, and then sew over the seam with the center of the presser foot aligned with the seam.



- ① Right side of fabric

Heirloom stitching


When sewing with the wing needle, the needle holes are enlarged, creating a lace-like decorative stitch. This is used to decorate hems and tablecloths on thin or medium weight fabrics in addition to plain weave fabrics.



Note


- If the thread becomes tangled, use stabilizer material.

1 Install the wing needle.



- Use a 130/705H 100/16 wing needle.
- For details on installing a needle, refer to “Replacing the needle” (page 37).
- The needle threader cannot be used with the wing needle, otherwise the sewing machine may be damaged. Manually pass the thread through the eye of the needle from the front to the back.

2 Attach monogramming foot “N”.



- For details, refer to “Replacing the presser foot” (page 39).


3 Select a stitch.

The stitches that can be used are ³⁹ , ⁴⁰ ,

⁴¹ , ⁴² , ⁴³ , ⁴⁴ , ⁴⁵ , ⁴⁶  or ⁴⁷ .

- For details, refer to “Selecting stitching” (page 70).
- Select a stitch width of 6.0 mm (15/64 inch) or less.

4 Start sewing.




CAUTION


- Select a stitch width of 6.0 mm (15/64 inch) or less, otherwise the needle may bend or break.
- After adjusting the stitch width, slowly turn the handwheel toward you (counterclockwise) and check that the needle does not touch the presser foot. If the needle hits the presser foot, the needle may bend or break.

Partially removing threads is called “drawnwork”. This gives a beautiful result with fabrics that have a loose weave. Two ways to create drawnwork are described below.


■ Drawnwork (Example 1)



1 Pull out several threads from the fabric.




2 Attach monogramming foot “N”.




- For details, refer to “Replacing the presser foot” (page 39).

3 Select stitch 39.



- For details, refer to “Selecting stitching” (page 70).

4 With the right side of the fabric facing up, sew along the right edge of the frayed section.




5 Press  (Settings key) in the operation panel.


- ▶ The settings screen appears.



6 Press  or  (Stitch length keys) until  is displayed.




- ▶ The screen for mirror imaging the pattern appears.




- 7** Press ◀ or ▶ (Stitch width keys) to select **ON**.

To return to **OFF**, press ◀ or ▶ (Stitch width keys).



▶ The pattern is flipped.




- 8** Press **OK** (OK key) or **↵** (Cancel/clear key).

▶ The initial stitch screen appears again.




- 9** Sew along the other edge of the frayed section so that it looks like the previous stitching.




- 10** Set the mirror image pattern setting back to **OFF**.

■ Drawnwork (Example 2)




- 1** Pull out several threads from two sections of the fabric, separated by an unfrayed section of about 4 mm (3/16 inch).



① 4 mm (3/16 inch)

- 2** Attach monogramming foot "N".




- For details, refer to "Replacing the presser foot" (page 39).

- 3** Select stitch **42** .

- For details, refer to "Selecting stitching" (page 70).

- 4** Sew along the center of the unfrayed section.



Sewing the Various Built-In Decorative Patterns

Satin stitches, cross-stitches and decorative satin stitches can be sewn. All are sewn with monogramming foot “N”.

Sewing beautiful patterns

In order to sew the patterns correctly, the following must be considered.

■ Fabric

Before sewing stretch or thin fabrics or fabrics with a coarse weave, affix the optional stabilizer material to the wrong side of the fabric or place a thin sheet of paper, such as tracing paper, under the fabric. Since material puckering or bunched stitches may occur when satin stitches are sewn, be sure to affix stabilizer material to the fabric.

■ Needles and threads


When sewing thin, medium weight or stretch fabrics, use the ball point needle. When sewing thick fabrics, use a 90/14 home sewing machine needle. In addition, 50 to 60 weight thread should be used.

■ Trial sewing

Depending on the type and thickness of the fabric being sewn and whether or not stabilizer material is used, the desired result may not be achieved. Be sure to sew a trial piece of fabric before sewing your project. In addition, while sewing, be sure to guide the fabric with your hands in order to prevent the fabric from slipping.

Sewing patterns

1 Attach monogramming foot “N”.





- For details, refer to “Replacing the presser foot” (page 39).

2 Select a stitch.

- For details, refer to steps 4 through 6 of “Selecting stitching” (page 70).

3 Start sewing.



- The stitching is sewn in the direction indicated by the arrow.

4 Sew reinforcement stitches.

When sewing with a character stitch, reinforcement stitches are automatically sewn after each character.

- When sewing a pattern with a stitch other than a character stitch, it is useful to first set the automatic reverse/reinforcement stitching setting. For details, refer to “Automatically sewing reverse/reinforcement stitches” (page 59).

5 When you are finished sewing, use scissors to trim off any excess threads at the beginning of the stitching and between the patterns.



Combining patterns

Multiple patterns can be combined and sewn together.

Decorative stitches and character stitches (stitches selected with  and ) can be combined.

However, utility stitches (stitches selected with  and ) cannot be combined.

1 Select the first pattern.

- ▶ The first pattern is selected and appears in the LCD.




- When the sewing is started, the selected pattern is sewn repeatedly until the sewing machine is stopped.

2 Select the next pattern.

Use the numeric keys to type in the number for the desired stitch.

To change the stitch type, press  (Decorative stitch key) or  (Character stitch key). After the icon for the desired stitch mode appears in the lower-left corner of the screen, type in the number for the desired stitch.



- ▶ The combined patterns appear in the LCD.



- To remove a selected pattern, press  (Cancel/clear key) in the operation panel. The pattern that was selected last is removed.

3 Repeat steps 2.



4 After all of the desired patterns are selected, start sewing.



- ① Sewing direction

- ▶ The order that the patterns appear in the LCD is the order that they will be sewn.



Note

- When the combined pattern is sewn at least one time, sewing of the combined pattern is temporarily stopped. Typing in the number of a stitch after sewing clears the combined pattern and selects the new stitch, instead of adding the new stitch to the combined pattern.
- If you do not wish to clear the pattern, save it before typing in the number of the new stitch. For details on saving patterns, refer to "Saving patterns" (page 128).

Memo

- Up to 70 patterns can be combined.
- If multiple patterns have been combined, the sewing machine stops once all the selected patterns displayed in the LCD have been sewn. To repeatedly sew the combined pattern, refer to "Repeat sewing patterns".
- The combined pattern can be saved for later use. For details, refer to "Saving patterns" (page 128).

Repeat sewing patterns

To repeatedly sew the combined pattern, follow the procedure described below.

1 Select the pattern.


- For details, refer to “Combining patterns” (page 121).

2 Press (Settings key) in the operation panel.

- The settings screen appears.



3 Press or (Stitch length keys) until is displayed.




- The screen for specifying repeat sewing appears.




4 Press or (Stitch width keys) to select (repeat sewing).

To return to  (single sewing), press  or  (Stitch width keys).



5 Press (OK key) or (Cancel/clear key).

- The initial stitch screen appears again, and the machine is set to repeatedly sew the selected pattern.



- ① Single
- ② Repeated

Note

- If repeated sewing is set, the pattern is repeatedly sewn until the sewing machine is stopped.
- If the sewing machine is turned off, the repeated/single sewing setting returns to its default setting.

Checking the selected pattern


Up to 70 patterns can be combined. If all of the selected patterns cannot be displayed in the LCD at the same time, the pattern can be checked according to the following procedure.

1 Press (Settings key) in the operation panel.

- The settings screen appears.




- 2 Press or (Stitch length keys) until is displayed.



- The screen for checking the pattern appears.



- 3 Press or (Stitch width keys) to scroll through the pattern and check it.



- Press to scroll through the pattern to the left. If the key is pressed while the leftmost (first) pattern is displayed, a beep sounds.
- Press to scroll through the pattern to the right. If the key is pressed while only the rightmost (last) pattern is displayed, a beep sounds.

- 4 Press (OK key) or (Cancel/clear key).

- The initial stitch screen appears again.

Changing the pattern size

The size of decorative stitches and decorative satin stitches (selected with) and character stitches in the Gothic font (selected with) and outline style (selected with) can be switched between large and small. However, the size of other patterns cannot be changed. For details on the stitch patterns whose size can be changed, refer to “Other stitches” (page 138).


- 1 **Select a stitch.**
Select a pattern whose size can be changed.

- 2 Press (Settings key) in the operation panel.

- The settings screen appears.



- 3 Press or (Stitch length keys) until is displayed.




- The screen for changing the pattern size appears.



- 4 Press ◀ or ▶ (Stitch width keys) until the desired size is selected.

Select  for the small size or select  for the large size.



▶ The pattern size is changed.

- 5 Press  (OK key) or  (Cancel/clear key).

▶ The initial stitch screen appears again.

- 6 Repeat steps 1 through 5.



LEAF
LEAF
LEAF
LEAF
LEAF
LEAF
LEAF
LEAF
LEAF
LEAF



Memo

- The large pattern size is the default. If the small pattern size is selected, small patterns can be combined and connected.
- If multiple patterns have been combined, the size of each selected pattern can be specified.

Changing the stitch density


If a decorative satin stitch has been selected, the stitch density can be changed.

- 1 Select a decorative satin stitch (No. 69–79 of , selected with ).




- 2 Press  (Settings key) in the operation panel.


▶ The settings screen appears.



- 3 Press  or  (Stitch length keys) until  is displayed.





▶ The screen for specifying the stitching density of the decorative satin stitch appears.



- 4 Press ◀ or ▶ (Stitch width keys) until the desired density is selected.

Select  for sparse stitching or select  for compact stitching.



- 5** Press **OK** (OK key) or **↵** (Cancel/clear key).
- ▶ The initial stitch screen appears again, and the stitching density is changed.


! CAUTION

- If the stitching density is too compacted, depending on the needle, the stitches may be bunched together, causing the needle to break.

Changing the pattern length

The length of one part of a satin stitch can be set to one of five sizes.

- 1** Select a satin stitch (No. 41–56 of , selected with ).




- 2** Press **ⓘ** (Settings key) in the operation panel.

▶ The settings screen appears.




- 3** Press **▲** or **▼** (Stitch length keys) until  is displayed.




▶ The screen for changing the length of a satin stitch appears.



- 4** Press **◀** or **▶** (Stitch width keys) until the desired ratio is selected.
- The length can be set within the range of $\times 1$ and $\times 5$.




- Press **◀** to reduce the length. If the key is pressed while the smallest setting ($\times 1$) is displayed, a beep sounds.
- Press **▶** to increase the length. If the key is pressed while the largest setting ($\times 5$) is displayed, a beep sounds.



▶ The satin stitch length is changed.

- 5** Press **OK** (OK key) or **↵** (Cancel/clear key).

▶ The initial stitch screen appears again.



Shifting patterns

Satin stitches (No. 41–56 of , selected with ) can be shifted to the left or right by half the width of the pattern, allowing you to create a step-shaped pattern. This is called a “step pattern”.

Select  (No. 57 of , selected with ) once to move the stitch pattern to the left by half the width of the stitch pattern.


Select  (No. 58 of , selected with ) once to move the stitch pattern to the right by half the width of the stitch pattern.

As an example, the procedure for creating the following pattern is described below.



- 1 Select  (No. 50 of , selected with ).


Press  (Decorative stitch key), and then use the numeric keys to type in “50”.



- 2 Using the numeric keys, type in “58” to select  (No. 58 of , selected with ).



- ▶ The next pattern selected is moved half a width to the right.



- 3 Using the numeric keys, type in “50” to select  (No. 50 of , selected with ) again.



- 4 Using the numeric keys, type in “57” to select  (No. 57 of , selected with ).




- ▶ The next pattern selected is moved half a width to the left.



- 5 Specify that the patterns will be sewn repeatedly.

- For details, refer to “Repeat sewing patterns” (page 122).

Examples of step patterns



Mirror imaging the pattern

The pattern can be mirror imaged along a vertical axis.


1 Select a stitch.

2 Press  (Settings key) in the operation panel.

▶ The settings screen appears.



3 Press  or  (Stitch length keys) until  is displayed.




▶ The screen for mirror imaging the pattern appears.



4 Press  or  (Stitch width keys) to select ON.

To return to OFF, press  or  (Stitch width keys).




▶ The pattern is mirror imaged.



5 Press  (OK key) or  (Cancel/clear key).

▶ The initial stitch screen appears again.



- ① Normal
- ② Mirror-imaged



Memo

- Some of the utility stitches, most of the decorative stitches, and all of the character stitches can be mirror imaged.
- Mirror imaged patterns can also be combined with other patterns.



Saving patterns

Combined patterns can be saved for later use. Since saved patterns are not lost after the sewing machine is turned off, they can be retrieved at any time. This is convenient for patterns, such as names, that will be used often. Utility stitches can also be saved. Up to ten patterns can be saved.

1 Create the combined pattern that you wish to save. Otherwise, display the pattern to be saved.

- For details, refer to “Combining patterns” (page 121).



2 Press (Memory key) in the operation panel.

- The machine enters pattern memory mode, and  appears in the upper-left corner of the screen.



3 Press the numeric key (0 through 9) for the pocket where the pattern is to be saved.

- The saved contents of the pocket for the selected number are displayed.
- If nothing has been saved, nothing appears in the bottom of the screen.



- If the pocket contains a pattern, the pattern is displayed. To leave this pattern in the pocket, select a different pocket.



4 Check the contents, and then press (OK key).

The contents saved in the selected pocket are overwritten.

- “Saving...” appears while the pattern is being saved in the pocket.
- After the pattern is saved, a beep is sounded, and the initial stitch screen appears again.

Note

- Do not turn off the sewing machine while a pattern is being saved, otherwise the pattern data may be lost.

Memo

- The pattern saved in the pocket can be erased by performing the save operation with no pattern selected.

Retrieving a pattern

1 Press (Preset utility stitch/saved pattern key) in the operation panel.

- After  appears in the center of the screen, the machine enters retrieve pattern mode, and  appears in the lower-left corner of the screen.



Memo

- Each time  (Preset utility stitch/saved pattern key) is pressed, the machine switches between the preset utility stitch mode and the saved pattern mode. (For details on the preset utility stitch mode, refer to “Selecting stitch types and patterns” (page 68).

2 Press the numeric key (0 through 9) for the pocket where the pattern is saved.

- ▶ The saved contents of the pocket for the selected number are retrieved.



- If nothing was saved in the selected pocket, a beep is sounded, and the screen displayed before the numeric key was pressed appears again.
- To select a different pocket, use the numeric keys to type in the number of a different pocket.




Memo

- After a decorative stitch or character stitch pattern is retrieved, press (Decorative stitch key) or (Character stitch key) to combine additional patterns with it or edit it.

Realigning the pattern

The pattern may not be sewn correctly, depending on the type of fabric being sewn or the sewing speed. If this occurs, adjust the pattern while sewing on a piece of scrap fabric that is the same as that used for your project.

1 Attach monogramming foot “N”.



- For details, refer to “Replacing the presser foot” (page 39).

2 Select (No. 31 of , selected with).

Press (Decorative stitch key), and then use the numeric keys to type in “31”.

- ▶ The pattern alignment stitch is selected.

3 Start sewing.



- ▶ The pattern for making the adjustment is sewn.
- ▶ The sewing machine stops after it has finished sewing the pattern.

4 Check the sewn pattern.

If the part of the pattern indicated in the illustration is sewn uniformly, the pattern is correctly aligned.



If the pattern appears as shown below, the stitching is misaligned in the vertical direction.




If the pattern appears as shown below, the stitching is misaligned in the horizontal direction.



If the pattern is not sewn correctly, follow the steps below to adjust the sewing.


5 Press (Settings key) in the operation panel.

- ▶ The settings screen appears.



- 6** Press \uparrow or \downarrow (Stitch length keys) until \updownarrow or \leftrightarrow is displayed.

To adjust the vertical position, select \updownarrow . To adjust the horizontal position, select \leftrightarrow .



- The screen for adjusting the pattern appears.


■ Vertical pattern adjustment



■ Horizontal pattern adjustment



- 7** Press \leftarrow or \rightarrow (Stitch width keys).



- Make the necessary adjustments according to how the pattern is sewn.

■ Vertical pattern adjustment



Press \rightarrow (Stitch width key) to increase the adjustment setting.



Press \leftarrow (Stitch width key) to decrease the adjustment setting.



■ Horizontal pattern adjustment



Press \rightarrow (Stitch width key) to increase the adjustment setting.



Press \leftarrow (Stitch width key) to decrease the adjustment setting.



- 8** Start sewing again, and then check the pattern. Continue adjusting the pattern until it is sewn correctly.

- 9** When the pattern is sewn correctly, press OK (OK key) or \rightarrow (Cancel/clear key).

- The initial stitch screen appears again.



4

APPENDIX

The various maintenance and troubleshooting procedures are described in this chapter.

- Stitch Settings..... 132**
 - Utility stitches 132
 - Other stitches..... 138
- Care and Maintenance 143**
 - Cleaning the machine surface..... 143
 - Cleaning the race 143
- Troubleshooting 145**
 - Error messages 149
 - Nothing appears in the LCD..... 150
 - Operation beep 150
 - Cancelling the operation beep..... 150
- Index 152**

Stitch Settings

Applications, stitch lengths and widths and whether the twin needle can be used are listed for utility stitches in the following table.

Utility stitches

Stitch Name	Pattern 	Presser Foot	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Twin Needle	Reverse/ Reinforcement Stitching	Programmed Thread-Cutting	Walking Foot
				Auto	Manual	Auto	Manual				
Straight stitch	Left 01 	J	Basic stitching, sewing gatherers or pintucks, etc.	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	Yes (J)	Reverse	Reverse + thread-cutting	No
	02 	J	Basic stitching and sewing gatherers or pintucks	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	Yes
	Center 03 	J/I	Attaching zippers, basic stitching, sewing gatherers or pintucks, etc.	3.5 (1/8)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	Yes (J)	Reverse	Reverse + thread-cutting	No
Triple stretch stitch	04 	J	Attaching sleeves, sewing inseams, sewing stretch fabrics and decorative stitching	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.5–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Stretch stitch	05 	J	Sewing stretch fabrics and decorative stitching	1.0 (1/16)	1.0–3.0 (1/16–1/8)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Basting stitch	06 	J	Temporarily securing	0.0 (0)	0.0–7.0 (0–1/4)	20 (3/4)	5–30 (3/16– 1–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
Zigzag stitch	Center 07 	J	Overcasting and attaching appliques	3.5 (1/8)	0.0–7.0 (0–1/4)	1.4 (1/16)	0.0–4.0 (0–3/16)	Yes (J)	Reverse	Reverse + thread-cutting	No
	Right 08 	J	Beginning sewing from the right needle position	3.5 (1/8)	2.5–5.0 (3/32–3/16)	1.4 (1/16)	0.3–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	Yes
2-point zigzag stitch	09 	J	Overcasting on medium weight or stretch fabrics, attaching elastic, darning, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	Yes
3-point zigzag stitch	10 	J	Overcasting on medium weight or stretch fabrics, attaching elastic, darning, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No

Stitch Name	Pattern 	Presser Foot	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Twin Needle	Reverse/Reinforcing Stitching	Programmed Thread-Cutting	Walking Foot
				Auto	Manual	Auto	Manual				
Overcasting stitch		G	Overcasting on thin or medium weight fabrics	3.5 (1/8)	2.5–5.0 (3/32–3/16)	2.0 (1/16)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
		G	Overcasting on thick fabrics	5.0 (3/16)	2.5–5.0 (3/32–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
		G	Preventing fraying in thick fabrics and fabrics that fray easily	5.0 (3/16)	3.5–5.0 (1/8–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
		J	Overcasting on stretch fabrics	5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.5–4.0 (1/32–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
		J	Overcasting on thick or stretch fabrics	5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.5–4.0 (1/32–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
		J	Overcasting on stretch fabrics and decorative stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	4.0 (3/16)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Blind hem stitch		R	Blind hem stitching on medium weight fabrics	00 (0)	3← – 3→	2.0 (1/16)	1.0–3.5 (1/16–1/8)	No	Reinforcement	Reinforcement + thread-cutting	No
		R	Blind hem stitching on stretch fabrics	00 (0)	3← – 3→	2.0 (1/16)	1.0–3.5 (1/16–1/8)	No	Reinforcement	Reinforcement + thread-cutting	No
Appliqué stitch		J	Appliqué stitching	3.5 (1/8)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.6–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Shell tuck stitch		J	Shell tuck stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Piecing straight stitch		J	Piecing straight stitching (with a seam allowance of 6.5 mm(1/4 inch) from the right edge of the presser foot)	5.5 (7/32)	0.0–7.0 (0–1/4)	2.0 (1/16)	0.2–5.0 (1/64–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
		J	Piecing straight stitching (with a seam allowance of 6.5 mm(1/4 inch) from the left edge of the presser foot)	1.5 (1/16)	0.0–7.0 (0–1/4)	2.0 (1/16)	0.2–5.0 (1/64–3/16)	No	Reinforcement	Reinforcement + thread-cutting	Yes
Straight stitch that looks hand-sewn (for quilting)		J	Straight stitch quilting that looks hand-sewn	0.0 (0)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
Zigzag stitch (for quilting)		J	Appliqué quilting, free-motion quilting, satin stitching	3.5 (1/8)	0.0–7.0 (0–1/4)	1.4 (1/16)	0.0–4.0 (0–3/16)	No	Reinforcement	Reinforcement + thread-cutting	Yes
Appliqué stitch (for quilting)		J	Attaching appliques and binding	1.5 (1/16)	0.5–5.0 (1/32–3/16)	1.8 (1/16)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
Quilting stitch (for stippling)		J	Quilting background stitching (stippling)	7.0 (1/4)	1.0–7.0 (1/16–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
Satin scallop stitch		N	Scallop stitching	5.0 (3/16)	2.5–7.0 (3/32–1/4)	0.5 (1/32)	0.1–1.0 (1/64–1/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No

Stitch Name	Pattern 	Presser Foot	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Twin Needle	Reverse/Reinforcement Stitching	Programmed Thread-Cutting	Walking Foot
				Auto	Manual	Auto	Manual				
Joining stitch	28 	J	Patchwork stitching and decorative stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	1.2 (1/16)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
	29 	J	Patchwork stitching, decorative stitching and sewing overcasting on both pieces of fabric, such as with tricot	5.0 (3/16)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
	30 	J	Patchwork stitching and decorative stitching	5.0 (3/16)	0.0–7.0 (0–1/4)	1.2 (1/16)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Smocking stitch	31 	J	Smocking stitching and decorative stitching	5.0 (3/16)	0.0–7.0 (0–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Fagoting stitch	32 	J	Fagoting and decorative stitching	5.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
	33 	J	Fagoting and decorative stitching	5.0 (3/16)	2.5–7.0 (3/32–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Elastic-attaching stitch	34 	J	Attaching elastic to stretch fabrics	4.0 (3/16)	0.0–7.0 (0–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Ladder stitch	35 	J	Decorative stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	3.0 (1/8)	2.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
Rick-rack stitch	36 	J	Decorative stitching	4.0 (3/16)	0.0–7.0 (0–1/4)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Decorative stitch	37 	J	Decorative stitching	5.5 (7/32)	0.0–7.0 (0–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No
Serpentine stitch	38 	N	Decorative stitching and elastic-attaching	5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.0 (1/16)	0.2–4.0 (1/64–3/16)	Yes (J)	Reinforcement	Reinforcement + thread-cutting	No

Stitch Name	Pattern 	Presser Foot	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Twin Needle	Reverse/Reinforcement Stitching	Programmed Thread-Cutting	Walking Foot
				Auto	Manual	Auto	Manual				
Hem-stitching	39 	N	Lace sewing, decorative hemming, heirloom stitching, etc.	3.5 (1/8)	1.5–7.0 (1/16–1/4)	2.5 (3/32)	1.6–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	40 	N	Decorative hemming, heirloom stitching, etc.	6.0 (15/64)	1.5–7.0 (1/16–1/4)	3.0 (1/8)	1.5–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	41 	N	Decorative hemming on thin, medium weight and plain weave fabrics, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	3.5 (1/8)	1.5–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	42 	N	Decorative hemming on thin, medium weight and plain weave fabrics, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	4.0 (3/16)	1.5–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	43 	N	Decorative hemming on thin, medium weight and plain weave fabrics, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	2.5 (3/32)	1.5–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	44 	N	Decorative hemming on thin, medium weight and plain weave fabrics, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	2.0 (1/16)	1.5–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	45 	N	Decorative hemming, ribbon threading, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	3.0 (1/8)	1.5–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	46 	N	Decorative stitching, smocking stitching, heirloom stitching, etc.	6.0 (15/64)	1.5–7.0 (1/16–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	47 	N	Decorative stitching, smocking stitching, heirloom stitching, etc.	5.0 (3/16)	1.5–7.0 (1/16–1/4)	1.6 (1/16)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No

Stitch Name	Pattern 	Presser Foot	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Twin Needle	Reverse/Reinforcing Stitching	Programmed Thread-Cutting	Walking Foot
				Auto	Manual	Auto	Manual				
Buttonhole stitch	48 	A	Horizontal buttonholes on thin and medium weight fabrics	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
	49 	A	Horizontal buttonholes on areas that are subject to strain	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
	50 	A	Horizontal buttonholes on thick fabrics	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
	51 	A	Secured buttonholes for fabrics that have backings	5.0 (3/16)	3.0–5.0 (1/8–3/16)	0.4 (1/64)	0.2–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
	52 	A	Buttonholes for stretch or knit fabrics	6.0 (15/64)	3.0–6.0 (1/8– 15/64)	1.0 (1/16)	0.5–2.0 (1/32–1/16)	No	Automatic reinforcement	Thread-cutting	No
	53 	A	Buttonholes for stretch fabrics	6.0 (15/64)	3.0–6.0 (1/8– 15/64)	1.5 (1/16)	1.0–3.0 (1/16–1/8)	No	Automatic reinforcement	Thread-cutting	No
	54 	A	Bound buttonholes	5.0 (3/16)	0.0–6.0 (0–15/64)	2.0 (1/16)	0.2–4.0 (1/64–3/16)	No	Automatic reinforcement	Thread-cutting	No
	55 	A	Keyhole buttonholes for thick or furry fabrics	7.0 (1/4)	3.0–7.0 (1/8–1/4)	0.5 (1/32)	0.3–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
	56 	A	Keyhole buttonholes for medium weight and thick fabrics	7.0 (1/4)	3.0–7.0 (1/8–1/4)	0.5 (1/32)	0.3–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
57 	A	Horizontal buttonholes for thick or furry fabrics	7.0 (1/4)	3.0–7.0 (1/8–1/4)	0.5 (1/32)	0.3–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No	
Darning stitch	58 	A	Darning medium weight fabrics	7.0 (1/4)	2.5–7.0 (3/32–1/4)	2.0 (1/16)	0.4–2.5 (1/64–3/32)	No	Automatic reinforcement	Thread-cutting	No
	59 	A	Darning thick fabrics	7.0 (1/4)	2.5–7.0 (3/32–1/4)	2.0 (1/16)	0.4–2.5 (1/64–3/32)	No	Automatic reinforcement	Thread-cutting	No
Bar tack stitch	60 	A	Reinforcing openings and areas where the seam easily comes loose	2.0 (1/16)	1.0–3.0 (1/16–1/8)	0.4 (1/64)	0.3–1.0 (1/64–1/16)	No	Automatic reinforcement	Thread-cutting	No
Button-sewing stitch	61 	M	Button sewing	3.5 (1/8)	2.5–4.5 (3/32–3/16)	–	–	No	Automatic reinforcement	Reinforcement + thread-cutting	No
Eyelet stitch	62 	N	Sewing eyelets, for example, on belts	7.0 (1/4)	7.0, 6.0, 5.0 (1/4, 15/64, 3/16)	7.0 (1/4)	7.0, 6.0, 5.0 (1/4, 15/64, 3/16)	No	Automatic reinforcement	Thread-cutting	No

Stitch Name	Pattern 	Presser Foot	Application	Stitch Width [mm (inch)]		Stitch Length [mm (inch)]		Twin Needle	Reverse/Reinforcement Stitching	Programmed Thread-Cutting	Walking Foot
				Auto	Manual	Auto	Manual				
Side cutter	63 	S	Sewing straight stitches while cutting the fabric	0.0 (0)	0.0–2.5 (0–3/32)	2.5 (3/32)	0.2–5.0 (1/64–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	64 	S	Sewing zigzag stitches while cutting the fabric	3.5 (1/8)	3.5–5.0 (1/8–3/16)	1.4 (1/16)	0.0–4.0 (0–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	65 	S	Overcasting on thin and medium weight fabrics while cutting the fabric	3.5 (1/8)	3.5–5.0 (1/8–3/16)	2.0 (1/16)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	66 	S	Overcasting on thick fabrics while cutting the fabric	5.0 (3/16)	3.5–5.0 (1/8–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
	67 	S	Overcasting on medium weight and thick fabrics while cutting the fabric	5.0 (3/16)	3.5–5.0 (1/8–3/16)	2.5 (3/32)	1.0–4.0 (1/16–3/16)	No	Reinforcement	Reinforcement + thread-cutting	No
Horizontal straight stitch	68 	N	Attaching appliqués to sleeves (straight stitch sewn to the left)	–	–	–	–	No	Reinforcement	Reinforcement + thread-cutting	No
	69 	N	Attaching appliqués to sleeves (straight stitch sewn to the right)	–	–	–	–	No	Reinforcement	Reinforcement + thread-cutting	No
Horizontal zigzag stitch	70 	N	Attaching appliqués to sleeves (zigzag stitch sewn to the left)	–	–	–	–	No	Reinforcement	Reinforcement + thread-cutting	No
	71 	N	Attaching appliqués to sleeves (zigzag stitch sewn to the right)	–	–	–	–	No	Reinforcement	Reinforcement + thread-cutting	No

Other stitches

Stitch Type	Pattern										Presser Foot	Twin Needle	Pattern Size	Adjustable Stitching Density	Adjustable Pattern Length/width	Left/Right Flipping
	01	02	03	04	05	06	07	08	09	10						
Decorative stitches	11	12	13	14	15	16	17	18	19	20	N	No	Large, Small (*Large)	No	Large: No Small: Yes (*Not possible)	Yes
	21	22	23	24	25	26	27	28	29*	30*						
	31**	32	33	34*	35*	36*	37*	38*	39	40						
	41	42	43	44	45	46	47	48	49	50						
Satin stitches	51	52	53	54	55	56					N	Yes (J)	Large	No	Yes	Yes
	57**	58**														
Step patterns	59	60	61	62	63	64*	65*	66*	67*	68*	N	No	Large	No	Yes (*Not possible)	Yes
Cross-stitches	69	70	71	72	73	74	75	76	77	78	N	No	Large, Small	Yes	Yes (length only)	Yes
	79															

** Pattern for making adjustment



Memo

- To select , press  (Decorative stitch key) once.

Stitch Type	Pattern										Presser Foot	Twin Needle	Pattern Size	Adjustable Stitching Density	Adjustable Pattern Length/width	Left/Right Flipping	
	01	02	03	04	05	06	07	11	12	13							
Utility decorative stitches	16	17	18*	20	21	22	23	24	25	26	J**	Yes (*Not possible) (J)	No	No	Yes	No	
	27*	28	29														
	08	09	10														C**
	14	15									R**	No					No
	19*	30*	31	32	33	34	35	36	37	38	N	No (*Not impossible)					Yes
	39																

** Use monogramming foot "N" when combined with other patterns.



Memo

- To select , press  (Decorative stitch key) twice.

Stitch Type	Pattern										Presser Foot	Twin Needle	Pattern Size	Adjustable Stitching Density	Adjustable Pattern Length/width	Left/Right Flipping
	 															
Character stitches (Gothic font)	01	02	03	04	05	06	07	08	09	10	N	No	Large, Small	No	No	Yes
	A	B	C	D	E	F	G	H	I	J						
	11	12	13	14	15	16	17	18	19	20						
	K	L	M	N	O	P	Q	R	S	T						
	21	22	23	24	25	26	27	28	29	30						
	U	V	W	X	Y	Z	&	?	!	_						
	31	32	33	34	35	36	37	38	39	40						
	0	1	2	3	4	5	6	7	8	9						
	41	42	43	44	45	46	47	48	49	50						
	'	,	.	()	—	Ä	Å	Æ	Ñ						
51	52	53	54	55	56	57	58	59	60							
Ö	Ø	Ç	Ü	ß	α	b	c	d	e							
61	62	63	64	65	66	67	68	69	70							
f	g	h	i	j	k	l	m	n	o							
71	72	73	74	75	76	77	78	79	80							
p	q	r	s	t	u	v	w	x	y							
81	82	83	84	85	86	87	88	89	90							
z	ä	å	ä	æ	ë	è	é	ê	ñ							
91	92	93	94	95	96	97										
ö	ò	ø	i	ç	ü	ù										



Memo

- To select  (Gothic font), press  (Character stitch key) once.

Stitch Type	Pattern										Presser Foot	Twin Needle	Pattern Size	Adjustable Stitching Density	Adjustable Pattern Length/width	Left/Right Flipping
	 															
Character stitches (Script font)	01	02	03	04	05	06	07	08	09	10	N	No	Large	No	No	Yes
	<i>A</i>	<i>B</i>	<i>C</i>	<i>D</i>	<i>E</i>	<i>F</i>	<i>G</i>	<i>H</i>	<i>I</i>	<i>J</i>						
	11	12	13	14	15	16	17	18	19	20						
	<i>K</i>	<i>L</i>	<i>M</i>	<i>N</i>	<i>O</i>	<i>P</i>	<i>Q</i>	<i>R</i>	<i>S</i>	<i>T</i>						
	21	22	23	24	25	26	27	28	29	30						
	<i>U</i>	<i>V</i>	<i>W</i>	<i>X</i>	<i>Y</i>	<i>Z</i>	<i>&</i>	<i>?</i>	<i>!</i>	<i>_</i>						
	31	32	33	34	35	36	37	38	39	40						
	<i>0</i>	<i>1</i>	<i>2</i>	<i>3</i>	<i>4</i>	<i>5</i>	<i>6</i>	<i>7</i>	<i>8</i>	<i>9</i>						
	41	42	43	44	45	46	47	48	49	50						
	<i>'</i>	<i>,</i>	<i>.</i>	<i>(</i>	<i>)</i>	<i>-</i>	<i>À</i>	<i>Á</i>	<i>Â</i>	<i>Ã</i>						
51	52	53	54	55	56	57	58	59	60							
<i>Ö</i>	<i>Ø</i>	<i>Ë</i>	<i>Ü</i>	<i>ß</i>	<i>a</i>	<i>b</i>	<i>c</i>	<i>d</i>	<i>e</i>							
61	62	63	64	65	66	67	68	69	70							
<i>f</i>	<i>g</i>	<i>h</i>	<i>i</i>	<i>j</i>	<i>k</i>	<i>l</i>	<i>m</i>	<i>n</i>	<i>o</i>							
71	72	73	74	75	76	77	78	79	80							
<i>p</i>	<i>q</i>	<i>r</i>	<i>s</i>	<i>t</i>	<i>u</i>	<i>v</i>	<i>w</i>	<i>x</i>	<i>y</i>							
81	82	83	84	85	86	87	88	89	90							
<i>z</i>	<i>ä</i>	<i>ã</i>	<i>ä</i>	<i>œ</i>	<i>ë</i>	<i>è</i>	<i>é</i>	<i>ê</i>	<i>ñ</i>							
91	92	93	94	95	96	97										
<i>ö</i>	<i>ø</i>	<i>ø</i>	<i>ï</i>	<i>ÿ</i>	<i>ù</i>	<i>û</i>										

 **Memo**

- To select  (Script font), press  (Character stitch key) twice.

Stitch Type	Pattern										Presser Foot	Twin Needle	Pattern Size	Adjustable Stitching Density	Adjustable Pattern Length/width	Left/Right Flipping
	 															
Character stitches (Outline style)	01	02	03	04	05	06	07	08	09	10	N	No	Large, Small	No	No	Yes
	A	B	C	D	E	F	G	H	I	J						
	11	12	13	14	15	16	17	18	19	20						
	K	L	M	N	O	P	Q	R	S	T						
	21	22	23	24	25	26	27	28	29	30						
	U	V	W	X	Y	Z	&	?	!	_						
	31	32	33	34	35	36	37	38	39	40						
	0	1	2	3	4	5	6	7	8	9						
	41	42	43	44	45	46	47	48	49	50						
	'	,	.	()	-	Ä	À	Æ	Ñ						
	51	52	53	54	55	56	57	58	59	60						
ö	ø	ç	ù	ß	a	b	c	d	e							
61	62	63	64	65	66	67	68	69	70							
f	g	h	i	j	k	l	m	n	o							
71	72	73	74	75	76	77	78	79	80							
P	q	r	s	t	u	v	w	x	y							
81	82	83	84	85	86	87	88	89	90							
z	ä	à	á	æ	ë	è	é	ê	ñ							
91	92	93	94	95	96	97										
ö	ò	ó	ì	ç	ù	ù										

 **Memo**

- To select  (Outline style), press  (Character stitch key) three times.

Care and Maintenance

Simple sewing machine maintenance operations are described below.

Cleaning the machine surface

If the surface of the machine is dirty, lightly soak a cloth in neutral detergent, squeeze it out firmly, and then wipe the surface of the machine. After cleaning it once with a wet cloth, wipe it again with a dry cloth.


CAUTION

- Unplug the power cord before cleaning the machine, otherwise injuries or an electric shock may occur.

Cleaning the race

Sewing performance will suffer if dust collects in the bobbin case; therefore, it should be cleaned periodically.

- 1 Turn off the sewing machine.




- 2 Unplug the power cord from the power supply jack on the right side of the sewing machine.

CAUTION

- Unplug the power cord before cleaning the machine, otherwise injuries or an electric shock may occur.

- 3 Remove the flat bed attachment.

- 4 Grasp both sides of the needle plate cover, and then slide it toward you.




① Needle plate cover


- ▶ The needle plate cover is removed.

5 Remove the bobbin case.

Grasp the bobbin case, and then pull it out.





① Bobbin case

6 Use the cleaning brush or a vacuum cleaner to remove any lint and dust from the race and its surrounding area.

① Cleaning brush


② Race

- Do not apply oil to the bobbin case.


7 Insert the bobbin case so that the projection on the bobbin case aligns with the spring.

① Projection

② Spring



① Bobbin case

8 Insert the tabs on the needle plate cover into the needle plate, and then slide the cover back on.

① Needle plate cover

9 Install the flat bed attachment in its original position.**! CAUTION**

- Never use a bobbin case that is scratched, otherwise the upper thread may become tangled, the needle may break or sewing performance may suffer. For a new bobbin case (part code: XC3153-151), contact your nearest authorized service center.
- Be sure that the bobbin case is correctly installed, otherwise the needle may break.

Troubleshooting

If the machine stops operating correctly, check the following possible problems before requesting service. If the problem persists, contact your retailer or the nearest authorized service center.

Symptom	Probable Cause	Remedy	Reference
The sewing machine does not operate.	The machine is not turned on.	Turn on the machine.	page 15
	The "Start/Stop" button was not pressed.	Press the "Start/Stop" button.	page 50
	The presser foot lever is raised.	Lower the presser foot lever.	–
	The "Start/Stop" button was pressed, even though the foot controller is connected.	Do not use the "Start/Stop" button when the foot controller is connected. To use the "Start/Stop" button, disconnect the foot controller.	page 50
The needle breaks.	The needle is incorrectly installed.	Correctly install the needle.	page 37
	The needle clamp screw is loose.	Use the screwdriver to firmly tighten the screw.	
	The needle is bent or blunt.	Replace the needle.	
	The combination of fabric, thread and needle is not correct.	Select a thread and needle that are appropriate for the type of fabric being sewn.	page 36
	The presser foot that is used is not appropriate for the type of stitch that you wish to sew.	Attach the presser foot that is appropriate for the type of stitch that you wish to sew.	page 132
	The upper thread tension is too tight.	Loosen the upper thread tension.	page 55
	The fabric is pulled too much.	Lightly guide the fabric.	–
	The spool is incorrectly installed.	Correctly install the spool.	page 26
	The area around the hole in the needle plate is scratched, or has a burr on it.	Replace the needle plate. Contact your retailer or the nearest authorized service center.	–
	The area around the hole in the presser foot is scratched, or has a burr on it.	Replace the presser foot. Contact your retailer or the nearest authorized service center.	–
	The bobbin case is scratched, or has a burr on it.	Replace the bobbin case. Contact your retailer or the nearest authorized service center.	–
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	page 20

Symptom	Probable Cause	Remedy	Reference
The upper thread breaks.	The upper thread was not threaded correctly (for example, the spool is not installed correctly, the spool cap is too big for the spool being used, or the thread has come out of the needle bar thread guide).	Correct the upper threading.	page 26
	There are knots or tangles in the thread.	Remove any knots or tangles.	–
	The selected needle is not appropriate for the thread being used.	Select a needle that is appropriate for the type of thread being used.	page 36
	The upper thread tension is too tight.	Loosen the upper thread tension.	page 55
	The thread is tangled, for example, in the bobbin case.	Remove the tangle thread. If the thread is tangled in the bobbin case, clean the race.	page 143
	The needle is bent or blunt.	Replace the needle.	page 37
	The needle is incorrectly installed.	Correctly install the needle.	
	The area around the hole in the needle plate is scratched, or has a burr on it.	Replace the needle plate. Contact your retailer or the nearest authorized service center.	–
	The area around the hole in the presser foot is scratched, or has a burr on it.	Replace the presser foot. Contact your retailer or the nearest authorized service center.	–
	The bobbin case is scratched, or has a burr on it.	Replace the bobbin case. Contact your retailer or the nearest authorized service center.	–
A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	page 20	
The lower thread is tangled or breaks.	The bobbin thread is incorrectly installed.	Correctly install the bobbin thread.	page 24
	The bobbin is scratched or does not rotate smoothly, or has a burr on it.	Replace the bobbin.	–
	The thread is tangled.	Remove the tangled thread and clean the race.	page 143
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	page 20

Symptom	Probable Cause	Remedy	Reference
The thread tension is incorrect.	The upper thread was not threaded correctly.	Correct the upper threading.	page 26
	The bobbin thread is incorrectly installed.	Correctly install the bobbin thread.	page 24
	The combination of fabric, thread and needle is not correct.	Select a thread and needle that are appropriate for the type of fabric being sewn.	page 36
	The presser foot holder is incorrectly installed.	Correctly install the presser foot holder.	page 41
	The thread tension is incorrect.	Adjust the tension of the upper thread.	page 55
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	page 20
The fabric is wrinkled.	The upper thread was not threaded correctly, or the bobbin is incorrectly installed.	Correctly thread the upper thread and correctly install the bobbin thread.	page 24, page 26
	The spool is incorrectly installed.	Correctly install the spool.	page 26
	The combination of fabric, thread and needle is not correct.	Select a thread and needle that are appropriate for the type of fabric being sewn.	page 36
	The needle is bent or blunt.	Replace the needle.	page 37
	If thin fabrics are being sewn, the stitch is too long.	Shorten the stitch length or sew with stabilizer material under the fabric.	page 58
	The thread tension is incorrect.	Adjust the tension of the upper thread.	page 55
Stitches are skipped.	The upper thread was not threaded correctly.	Correct the upper threading.	page 26
	The combination of fabric, thread and needle is not correct.	Select a thread and needle that are appropriate for the type of fabric being sewn.	page 36
	The needle is bent or blunt.	Replace the needle.	page 37
	The needle is incorrectly installed.	Correctly install the needle.	page 37
	Dust has accumulated under the needle plate or in the bobbin case.	Remove the needle plate cover and clean the race.	page 143

Symptom	Probable Cause	Remedy	Reference
A high-pitched noise is made while sewing.	Dust has accumulated in the feed dogs or in the bobbin case.	Clean the race.	page 143
	The upper thread was not threaded correctly.	Correct the upper threading.	page 26
	The bobbin case is scratched, or has a burr on it.	Replace the bobbin case. Contact your retailer or the nearest authorized service center.	–
	A bobbin designed specifically for this machine is not used.	Incorrect bobbins will not work properly. Only use a bobbin designed specifically for this machine.	page 20
The needle threader cannot be used.	The needle has not been raised to the correct position.	Press the “Needle Position” button.	page 29
	The needle is incorrectly installed.	Correctly install the needle.	page 37
The stitch is not sewn correctly.	The presser foot that is used is not appropriate for the type of stitch that you wish to sew.	Attach the presser foot that is appropriate for the type of stitch that you wish to sew.	page 132
	The thread tension is incorrect.	Adjust the tension of the upper thread.	page 55
	The thread is tangled, for example, in the bobbin case.	Remove the tangle thread. If the thread is tangled in the bobbin case, clean the race.	page 143
The fabric does not feed.	The feed dogs are lowered.	Slide the drop feed lever to the right (as seen from the rear of the machine).	page 103
	The stitch is too short.	Lengthen the stitch length.	page 58
	The presser foot that is used is not appropriate for the type of stitch that you wish to sew.	Attach the presser foot that is appropriate for the type of stitch that you wish to sew.	page 132
	The pressure of the presser foot is weak.	Turn the presser foot pressure dial to the left to increase the pressure of the presser foot.	page 41
	The thread is tangled, for example, in the bobbin case.	Remove the tangle thread. If the thread is tangled in the bobbin case, clean the race.	page 143
The sewing lamp does not come on.	The sewing lamp is damaged.	Contact your retailer or the nearest authorized service center.	–
Nothing appears in the LCD.	The brightness of the LCD is either too light or too dark.	Adjust the brightness of the LCD.	page 150

Error messages


If  /  “Start/Stop” button is pressed before the sewing machine is correctly set up or if an operation is performed incorrectly, an error message appears in the LCD. Follow the instructions that appear. The message may disappear if the operation is performed correctly. The message will disappear if  (OK key) or  (Cancel/clear key) is pressed while the message is displayed.

Error Message	Probable Cause
 Can not change.	The selected setting cannot be changed with the selected pattern.
 Change speed controller mode to “OFF”.	The “Start/Stop” button was pressed without connecting the foot controller while the setting for adjusting the stitch width using the sewing speed controller is set to [ON].
 Delete the selected pattern.  Cancel  Delete	The stitch mode was changed. This message appears when the current pattern is to be deleted.
 Disconnect foot control.	The “Start/Stop” button was pressed while the foot controller was connected.
 Lift buttonhole lever.	A stitch other than the buttonhole, bar tack or darning stitch was selected and the “Start/Stop” button was pressed while the buttonhole lever is lowered.
 Lower buttonhole lever.	The buttonhole, bar tack or darning stitch was selected and the “Start/Stop” button was pressed while the buttonhole lever is raised.
 Lower presser foot lever.	The “Start/Stop” button, “Reverse/Reinforcement Stitch” button or “Thread Cutter” button was pressed while the presser foot was raised.
 No more stitches can be combined.	You tried to combine more than 70 decorative stitches, stain stitches, cross stitches or combined utility stitches.
 Release twin needle setting.	The twin needle setting is selected while a pattern that cannot be sewn with the twin needle is selected.
 Return bobbin winding shaft to left.	The “Reverse/Reinforcement Stitch” button, “Needle Position” button or “Thread Cutter” button was pressed while the bobbin winder shaft is moved to the right.
Saving...	A pattern is being saved. Otherwise, the stitch settings are being saved.
 Select pattern.	The “Start/Stop” button or “Reverse/Reinforcement Stitch” button was pressed after a stitch has been deleted.
 The safety device has been activated.	The motor locked up because the thread is tangled.
Winding bobbin thread.	The bobbin winder is winding the bobbin.

Nothing appears in the LCD


If nothing appears in the LCD when the sewing machine is turned on, the brightness of the LCD is either too light or too dark. If this is the case, perform the following operation.

- 1 Turn off the sewing machine.



- 2 While pressing  (Cancel/clear key) in the operation panel, turn on the sewing machine.

- 3 Press  or  (Stitch width keys). Adjust the brightness of the LCD so that the screens can be seen.



- 4 Turn off the sewing machine, then turn it on again.

Operation beep


Each time a key is pressed or an incorrect operation is performed, a beep is sounded.

- **For a correct operation**
One beep is sounded.
- **If an incorrect operation is performed**
Two or four beeps are sounded.
- **If the machine locks up, for example, because the thread is tangled**
The sewing machine continues to beep for four seconds. The machine automatically stops.
Be sure to check for the cause of the error, and correct it before continuing to sew.

Cancelling the operation beep

When the sewing machine is purchased, it is set to beep each time an operation panel key is pressed. This setting can be changed so that the machine does not beep.

- 1 Turn on the sewing machine.




▶ The LCD comes on.

- 2 Press  (Settings key) in the operation panel.



▶ The settings screen appears.

- 3 Press  or  (Stitch length keys) until  is displayed.





▶ The screen for changing the beep setting appears.



- 4** Press ◀ or ▶ (Stitch width keys) to select OFF.

To return to ON, press ◀ or ▶ (Stitch width keys).



- ▶ The machine is now set so that it will not beep.

- 5** Press ⏪ (Cancel/clear key) or OK (OK key).

- ▶ The initial stitch screen appears again.

Index

Numerics

1/4 inch quilting foot	8, 101
1/4 inch quilting foot with guide	8
2-point zigzag stitch	75
3-point zigzag stitch	75

A

accessories	7
accessory bag	8
adjustable zipper/piping foot	8, 94
air vent	10
appliqué	99
automatic reinforcement stitching	59
automatic reverse stitching	59
automatic reverse/reinforcement stitch key	12
automatic thread cutting key	12
automatic thread-cutting	6, 61

B

bar tack	106
baseline	79
basic stitching	79
basting	78
blind hem stitch	80
blind stitch foot	8
bobbin	8, 24
bobbin case	24, 143
bobbin cover	10, 25
bobbin thread	24
pulling up	34
bobbin winder	9
bobbin winder shaft spring	21
bobbin winding thread guide and pretension disk	9, 22
bobbin-winding	6, 20
brightness	19
built-in stitches	6
button fitting foot	8
button sewing	82, 87
buttonhole foot	8, 86
buttonhole lever	10, 84, 107, 109
buttonhole stitching	82

C

cancel/clear key	12
care	143
changing machine settings	17
changing sewing direction	64
changing the settings	17
character stitch key	12
character stitches	69, 120, 140
checking patterns	122
cleaning	143
cleaning brush	8, 144
combining patterns	121

crazy quilt stitching	100
cross-stitch	120
cross-stitches	69, 120, 138
curves	64
cylindrical pieces	44

D

darning	108
decorative satin stitches	69, 120, 138
decorative stitch key	12
decorative stitches	69, 120, 138
decorative stitching	113
direct selection	68
disc-shaped screwdriver	8

E

elastic tape	96
electrical outlet	15
error messages	149
even seam allowance	66
extension table	8, 44
extra spool pin	8, 32
eyelet	110
eyelet punch	8, 85, 110

F

fagoting	114
features	6
feed dog position switch	10, 103
feed dogs	10, 103
flat bed attachment	9
flipping	127
foot controller	8, 50
foot controller jack	10
free-arm sewing	44
free-motion quilting	103

H

handle	10
handwheel	10, 49
hard case	8
heirloom stitching	117
horizontal stitching	111

I

included accessories	7
Inserting a piping	95

J

joining	117
joining stitch	98

K

knee lifter 6, 8, 63
knee lifter mounting slot 9

L

language 19
LCD 12, 16, 19, 150
 brightness 19, 150
leather/vinyl fabrics 66
lower threading 6, 24

M

machine settings 17
main power switch 10, 15
maintenance 143
manual memory key 12
memory key 12
mirror image 127
monogramming foot 8

N

needle 35
needle bar thread guide 10
needle clamp screw 38
needle mode selection key 12
needle plate 10, 66
needle plate cover 10, 143
needle position 57, 79
needle position button 11
needle set 8
needle stop position 59
needle stop position key 12
needle threader lever 9
needle threading 29
non stick foot 8, 66
number selection 68
numeric keys 12

O

OK key 12
open toe foot 8
openings 106
operation beep 150
operation buttons 9, 11
operation manual 8
operation panel 9, 12
optional accessories 8
overcasting foot 8
overcasting stitches 74

P

patchwork stitching 100
pattern length 125
pattern size 123
patterns 120
piecing 100
piping inserting 95

pocket corners 106
positioning fabric 49
power supply 14
power supply jack 10, 15
preset utility stitch/saved pattern key 12
presser foot 10, 39
presser foot dial 10, 41
presser foot holder 10, 41
presser foot lever 10
presser foot pressure 41
programmed thread-cutting 61

Q

quick reference guide 8
quilting 102
quilting foot 8, 103
quilting guide 8, 102

R

race 143
realigning 129
realigning patterns 129
reinforcement stitching 52, 59, 106
repeat sewing 122
replacing the needle 35, 37
reset key 12
retrieving a pattern 128
reverse/reinforcement stitch button 11

S

safety instructions 1
satin stitches 69, 120, 138
satin stitching 104
saving patterns 128
saving stitch settings 62
scallop stitching 115
screwdriver 8, 38
seam ripper 8, 85
selecting stitching 70
settings key 12, 17
sewing machine needles 35
sewing speed 50
sewing speed controller 11, 104
shell tuck stitch 116
shifting patterns 126
side cutter 8, 76
size 123
sleeves 106
smocking 115
spool cap 8, 21, 27
spool net 8
spool pin 9, 21, 27
start/stop button 11, 50
starting to sew 50
step pattern 126
stitch density 124
stitch guide foot 8, 66
stitch length 58
stitch length keys 12
stitch mode 68

stitch pattern plate	8
stitch settings	132
stitch width	57
controlling	104
stitch width keys	12
straight stitch	132
stretch fabrics	65, 96

T

thick fabrics	65
thin fabrics	65
thread cutter	9, 54
thread cutter button	11, 53
thread guide cover	9
thread guide disk	10
thread guide plate	9
thread tension	56
thread tension adjustment	55, 56
thread tension keys	12
top cover	9
trial sewing	64
triple stretch stitch	106
troubleshooting	145
twin needle	8, 31, 38

U

upper thread	26
upper thread tension	6, 56
upper threading	6, 26
utility decorative stitches	69, 120, 139
utility stitch key	12
utility stitches	68, 132

W

walking foot	8, 42, 102
wing needle	117

Z

zigzag foot	8
zipper foot	8
zipper stitching	89, 94

