

Baby Lock Regalia Machine Software Update Instructions

Using Original 7" Regalia Display

From time to time Baby Lock releases a software update for our machines and displays. This update feature enables you to take advantage of the latest new capabilities added to machines and displays.

When an update is released, download the updated file(s) using a computer that is connected to the Internet. The update files may be zipped in a file or folder to include installation instructions. **Be sure to extract the files and save only the machine software update file to a formatted USB drive.**


Touch the **Tools** button in the Toolbar on the front display. Then touch the **Update** button along the bottom of the screen.




After downloading the updated software to a formatted USB drive, insert the drive in the designated USB port on the bottom of the front display. Look for the message in the bottom bar that confirms a USB drive has been inserted. If it doesn't appear, reinsert the USB drive.




Touch the machine icon to update the machine's software.



You will be prompted to choose the file you want to use to update the machine software. Touch the **Select Version** box and then select the file name of the update file you downloaded and saved to the USB.



Be patient as this will take a few minutes.



When complete, the machine will beep.
Remove the USB and restart the machine.