



## How to Turn Off the On-Screen Keyboard on Windows 10 ProStitcher Premium Tablets (for Alpha 12 and Alpha 3 Tablets)


1. Either minimize the ProStitcher Premium screen or select File/Shutdown/Exit to Windows:




2. Touch the bottom of the tablet's screen to pull up the tray of icons. Select the Windows icon and then the Settings icon on the lower left side of the screen.



3. On the next screen, select "Devices":



4. On the next screen, select "Typing":



5. On the next screen, scroll down to the bottom and ensure that "Show the touch keyboard..." is switched to "Off":

