ProStitcher software is specific to the ProStitcher tablet you use. Be sure to select the correct version based upon your tablet.

Tablet Name	Compatibility	What it Looks Like	Side View
Acer Switch 3	Pro-Stitcher Premium		
Acer Alpha Switch 12	Pro-Stitcher Premium		
Aspire Switch 11	Pro-Stitcher Premium Pro-Stitcher Standard		
Acer W700	Pro-Stitcher Premium Pro-Stitcher Standard		
HP Omni	Pro-Stitcher Standard ProStitcher Premium is not available for this tablet – Contact your Baby Lock Retailer for options.		
Acer W500	Pro-Stitcher Standard ProStitcher Premium is not available for this tablet – Contact your Baby Lock Retailer for options.		

EEEPC	Pro-Stitcher Standard Pro-Stitcher Classic ProStitcher Premium is not available for this tablet – Contact your Baby Lock Retailer for options.		

To check ProStitcher software version currently installed:

- In ProStitcher Standard, select Settings, Advanced, and About.
- In ProStitcher Premium, select the "*i*" tab, then select About.

If you already have ProStitcher Premium installed (the version number is higher than 17.03.0209), please follow these steps:

- Download the 18.02.0012 PreInstall file and the Premium update version 19.07.0506 update file.
- If the update file is zipped, you must extract and save only the update file(s) to a USB.
- Install the 18.02.0012 PreInstall file following the procedures explained in the PreInstall Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the ProStitcher Premium update (select File tab, then select "Update" icon).

A File Explorer window will open. Select the USB drive (D), select the update file you have saved to the USB, then select "Run".

Select Start when this screen appears:

Select Confirm when this screen appears:

When prompted, select the type of Baby Lock machine you have and press Next.

When you see the Installation Completed message, press the Close button.

Reboot the computer to complete the installation process. To restart the tablet computer, select Shutdown, then Reboot under the File tab.

If you have ProStitcher Standard installed on a Switch 11 or Acer W700 tablet, and the version number is at 17.03.0209, please follow these steps:

- Download the 18.02.0012 PreInstall file and the Premium update version 19.07.0506 update file.
- If the update file is zipped, you must extract and save only the update file(s) to a USB.
- Install the 18.02.0012 PreInstall file following the procedures explained in the PreInstall Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the ProStitcher Premium update (select File tab, then select “Update” icon).

A File Explorer window will open. Select the USB drive (D), select the update file you have saved to the USB, then select "Run".

Select Start when this screen appears:

Select Confirm when this screen appears:

When prompted, select the type of Baby Lock machine you have and press Next.

When you see the Installation Completed message, press the Close button.

Reboot the computer to complete the installation process. To restart the tablet computer, select Shutdown, then Reboot under the File tab.

If you have ProStitcher Standard installed on a Switch 11 or Acer W700 tablet, and the version number is below 17.03.0209, please follow these steps:

- Download the 17.03.0209 update file, the 18.02.0012 PreInstall file, and the Premium update version 19.07.0506 update file.
- If the update file is zipped, you must extract and save only the update file(s) to a USB.
  Install the 17.03.0209 file following the procedures explained in the accompanying Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the 18.02.0012 PreInstall file following the procedures explained in the PreInstall Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the ProStitcher Premium update (select File tab, then select “Update” icon).

- A File Explorer window will open. Select the USB drive (D), select the update file you have saved to the USB, then select "Run".

- Select Start when this screen appears:

- Select Confirm when this screen appears:

- When prompted, select the type of Baby Lock machine you have and press Next.

- When you see the Installation Completed message, press the Close button.

- Reboot the computer to complete the installation process. To restart the tablet computer, select Shutdown, then Reboot under the File tab.

If you have ProStitcher Standard installed on an EEEPC, HP Omni or Acer W500 tablet, the latest update you can install is 16.01.0092.