

# BABY LOCK SEWING ACCESSORIES

## Bias Binder Foot

(ESG-BB)

### Instructions



#### MACHINE SETTINGS

Stitch:	Straight, zigzag or all forward decorative stitches
Stitch length:	Pre-set
Stitch width:	Pre-set
Tension:	Pre-set

When you want to apply binding to either home decorating projects or garments, the Baby Lock Bias Binder Foot allows you to do this with ease.

The Baby Lock Bias Binder Foot is great to use when attaching unfinished bias that is cut 1-1/8" wide. Pre-folded tape should be pressed flat. Cut the end of the bias at a 45° angle before inserting it into the foot. Be sure any seams in your bias are pressed toward you to prevent any bunching or catching in the seam allowance.

Sew using a small zigzag stitch or guide the bias into the cone, feeding the bias tape straight into the binder so the same amount of tape is sewn on the top and bottom. Insert fabric (that will be finished) into the cone center from the left to right. As you sew, the cone will wrap the bias around the unfinished edge of the fabric. Move your needle to the position where you would like to have your straight stitch placed.

**Note:** Use the width control to move your needle from the left needle position.

**Note:** This foot will fit Quilter's Choice Professional (BLQP) and Jane (BL500A) if master bracket (BLQP-MB) is used.



**FOR THE LOVE OF SEWING**