


BABY LOCK SEWING ACCESSORIES

Cording Foot - 3 Cord

(BLG-CF3)

Instructions



Attaching decorative cords and threads is a snap. This foot eliminates tangling to ensure that cords lie flat and perfectly parallel to each other. The cording foot controls threads so both hands can guide the fabric. Use this foot to create decorative stitching over cording on single and double layers of fabric.


INSTRUCTIONS:

1. Remove presser foot and attach snap-on cording foot.
2. Select a stitch. Some suggested stitches are:




Triple Cording Stretch

Select dotted zig zag stitch and sew at a maximum stitch width of 5 mm.



Single Cording


The zig zag stitch may be positioned in the center or to the right. Verify position of stitch and determine the appropriate guide to be followed. Set stitch width slightly greater than width of string.




Stitch Length

Select desired stitch length. Remember that the results of the decorative stitch will vary based on the stitch length you have selected.

3. Feed cords, one by one, from the right side of the cording foot spring into their respective guides.



4. Using your foot controller will help you to have both hands free for easier fabric handling.
5. Draw cording under foot and extend the cord 4-5 mm behind foot. When using 2 or 3 cords, be careful to make sure that cords are not trampled under the front of foot.
6. Place cloth under foot. Lower foot and sew.



FOR THE LOVE OF SEWING