

READ FIRST

Baby Lock Regalia Display and Machine Software Update Precaution

Quilters who have the original Regalia display screen(s) attached typically use the Update icon in the Tool menu of the Regalia console to install the machine software AND display software updates.

However, **the most current display update will require a different procedure.**

Based on your machine set-up, please select just one of the options below, and follow the instructions in that box.



If you have **ProStitcher Premium** installed on your Regalia AND you do NOT have the rear handlebars and display screen installed, you will need to:

1. Open ONLY the Machine folder to save the installation instructions and the actual update file. You will NOT need to open the Display folder.
2. Follow the installation instructions to install the machine update file (QM51057-v463NG.s19).
3. You will NOT install the display update, as this file is ONLY for the original machine displays.

If you have **ProStitcher Premium** installed on your Regalia AND you DO have the rear handlebars and display screen installed, you will need to:

1. Open the Machine folder (to save the installation instructions and the actual update file).
2. Open the Display folder (to save the installation instructions and the actual update file).
3. Open, print, and CAREFULLY follow the instructions for installing the display update for the rear display. **The process is unique to this particular update file** (Regalia.18.05.72.apk).
1. Follow the installation instructions for installing the machine update file (QM51057-v463NG.s19) using either the rear display or your ProStitcher Premium tablet. If you have installed machine updates in the past, the procedure will be familiar.

If you **do NOT** have **ProStitcher Premium** installed on your Regalia AND you have the front and/or rear handlebars and display screen(s) installed, you will need to:

1. Open the Machine folder (to save the installation instructions and the actual update file).
2. Open the Display folder (to save the installation instructions and the actual update file).
3. Open, print, and CAREFULLY follow the instructions for installing the display update for the machine display screen(s). **The process is unique to this particular update file** (Regalia.18.05.72.apk).
4. Follow the installation instructions for installing the machine update file (QM51057-v463NG.s19) using the machine display screen. If you have installed machine updates in the past, the procedure will be familiar.