


Updating the Babylock Regalia™ Display Software from Version 066 or earlier to Version 067 or later


1. Download the appropriate display update from the Babylock web site and **save** to a USB flash drive.
2. Insert the **USB flash drive** into the **USB port** located on the bottom of the 7" display.
3. Press on the **lower right corner** of the task bar.




4. On the pop-up menu, select the **settings icon**.




5. Select **Settings** on the next pop-up menu.




6. In the settings menu, select **Apps**, then select the **Regalia** application.




7. Select **Uninstall**.



8. Select **OK** when prompted “Do you want to uninstall this app?”




9. When the app has uninstalled, select the **Home** button from the task bar.




10. Select the **Apps icon** on the A20 Screen.




11. Select **File Manager** from the **APPS** screen.




12. Select the **USB tab** at the top of the screen.




13. Select the **usbhost1** folder.



14. Select the **tablet update**.




15. Select **Install** from the pop-up box.



16. When the app has finished installing, select **Done**.


NOTE: If you selected "OPEN" instead, continue to follow the steps, even though the program has started.




17. Select the **Home** button on the task bar.



18. Under “**Complete action using**”, select the **Regalia** app.



19. There will be a blue square around the app. Select **Always** below the app.



20. Select the **Information** button in the top right corner of the Regalia display to check that the new software version is installed.



Once the display has been manually updated to version 067 or later, the quilter can use the update screen in the Tools menu for future updates.