

UPGRADING YOUR MACHINE'S SOFTWARE

You can use USB media to upgrade software for your machine.


When an upgrade program is available on "www.babylock.com", please download the files following the instructions on the website and steps below.

Note

- When using USB media to upgrade the software, check that no data other than the upgrade file is saved on the USB media being used before starting to upgrade.

1 While pressing  (Automatic threading button), turn the main power to ON.

2 Press  .



3 Insert the USB media into the primary (top) USB port on the machine.



4 Press  .

→ When upgrading is finished, the completion message appears.

5 Turn the machine off, remove the USB media, and turn the machine on again.